Mercedes Benz 2110058

Mercedes-Benz Trunk Lid Star Emblem Badge 2110058 Instruction Manual

Product Overview

This document provides comprehensive instructions for the installation and maintenance of the Mercedes-Benz Trunk Lid Star Emblem Badge, part number 2110058. This genuine original emblem is designed to replace or upgrade the existing badge on compatible Mercedes-Benz E-Class vehicles, restoring the vehicle's aesthetic integrity.



Image: This image displays the Mercedes-Benz three-pointed star emblem, designed for trunk lid installation. It features a glossy chrome finish and is shown against a white background, highlighting its detailed design and reflective surface.

Compatibility

This emblem (part number 2110058) is compatible with various Mercedes-Benz E-Class models. Please verify your vehicle's VIN (Vehicle Identification Number) with a Mercedes-Benz service center or parts specialist to ensure exact fitment before installation.

Known Compatible Models and Years:

- 2007 - 2009 E280
- 2008 - 2009 E300
- 2003 - 2009 E320
- 2006 - 2009 E350
- 2004 - 2009 E500
- 2004 - 2006 E55 AMG
- 2007 - 2009 E550
- 2007 - 2009 E63 AMG

Package Contents

- 1 x Mercedes-Benz Trunk Lid Star Emblem Badge (Part No. 2110058)

Installation Instructions

Tools Required (Recommended)

- Plastic trim removal tool
- Clean microfiber cloth
- Mild adhesive remover (if applicable for old emblem residue)
- Protective gloves

Procedure

1. **Preparation:** Park the vehicle on a level surface and ensure the trunk lid is clean and dry. Open the trunk lid.
2. **Access Mounting Points:** Carefully remove the interior trunk lid carpet or liner to expose the emblem's mounting points from the inside. This typically involves removing plastic clips or fasteners with a trim removal tool.
3. **Remove Old Emblem:** From the inside of the trunk lid, locate the anchors or clips holding the old emblem in place. Gently push or release these anchors to detach the old emblem. Avoid excessive force to prevent damage to the trunk lid.
4. **Clean Surface:** Once the old emblem is removed, thoroughly clean the area on the exterior of the trunk lid where the new emblem will be installed. Remove any adhesive residue or dirt using a mild adhesive remover and a clean microfiber cloth. Ensure the surface is completely dry.
5. **Install New Emblem:** Align the new Mercedes-Benz Trunk Lid Star Emblem Badge with the mounting holes on the exterior of the trunk lid. From the inside, carefully push the emblem's prongs through the holes until they are securely seated. Ensure the emblem is flush with the trunk surface.
6. **Secure Emblem:** Re-attach any clips or anchors from the inside to firmly secure the new emblem.

7. **Reassemble Interior:** Reinstall the trunk lid carpet or liner, ensuring all clips and fasteners are properly secured.
8. **Final Check:** Close the trunk lid and visually inspect the new emblem for proper alignment and secure fitment.

Maintenance

To maintain the appearance of your Mercedes-Benz Trunk Lid Star Emblem Badge, follow these guidelines:

- **Cleaning:** Clean the emblem regularly with mild automotive soap and water. Use a soft sponge or microfiber cloth to avoid scratching the chrome finish.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong solvents, or harsh chemicals, as these can damage the emblem's finish.
- **Drying:** Dry the emblem immediately after washing to prevent water spots, especially in hard water areas.

Troubleshooting

Fitment Issues

If the emblem does not fit correctly or appears misaligned:

- **Verify Compatibility:** Double-check that the part number 2110058 is indeed the correct emblem for your specific Mercedes-Benz model and year. Refer to the compatibility section or consult your vehicle's manual.
- **Inspect Mounting Points:** Ensure that the mounting holes on your trunk lid are clear of debris or previous adhesive, which could obstruct proper seating.
- **Professional Assistance:** If issues persist, it is recommended to seek assistance from a certified Mercedes-Benz service technician or an experienced automotive professional.

Specifications

Feature	Detail
Brand	Mercedes Benz
Model Number	2110058
Color	Silver
Exterior Finish	Glossy
Vehicle Service Type	Car
Item Weight	0.317 ounces
UPC	852671963463
Manufacturer	MERCEDES-BENZ GENUINE ORIGINAL

Support and Warranty

For specific warranty information, please refer to the documentation provided with your purchase or contact the authorized Mercedes-Benz parts dealer from whom you purchased this emblem. For technical support or further inquiries, please reach out to your Mercedes-Benz service center or the seller directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question