

[manuals.plus](#) /

› [Goodyear](#) /

› [Goodyear 77600 Rain Master Flat Wiper Blade 330mm Instruction Manual](#)

## Goodyear 77600

# Goodyear 77600 Rain Master Flat Wiper Blade 330mm Instruction Manual

## PRODUCT OVERVIEW

---

The Goodyear 77600 Rain Master Flat Wiper Blade is a 330mm windshield wiper designed for effective and quiet operation. This flat blade technology provides consistent pressure across the windshield for clear visibility in various weather conditions, utilizing new technology for enhanced performance.



Image: Goodyear 77600 Rain Master Flat Wiper Blade in its retail packaging, highlighting the 330mm size.

## PACKAGE CONTENTS

---

Verify that all components are present before proceeding with installation:

- 1 x Goodyear Rain Master Flat Wiper Blade (330mm)
- Assorted Wiper Arm Adapters (for various vehicle types)

MARCA	ANNO	LATO GUIDA	LATO PASS.
<b>ABARTH</b>			
500/C	2008>	600	350
PUNTO	2010>	650	380
<b>ALFA ROMEO</b>			
147	11.00>05.05	550	410
147	10.05>2010	550	410
155	02.92>04.96	530	480
164	09.92>10.98	530	530
166	10.98>10.07	530	480
145/146	04.97>12.00	550	480
145/146	04.94>04.97	550	510
155/166	02.92>10.07	530	480
156/Cross W. Q4/SW	10.97>12.05	550	510
159 e Sport Wagon	06.05>2011	550	450
33 / 33 SW	83>94	450	450
75	10.86>12.93	450	450
Brera/Spider	01.06>2011	550	450
Giulietta	05.10>	550	450
GT	10.03>2010	550	410
Mito	08.08>	650	380
Spider (Duetto)	01.90>12.94	450	450
<b>AUDI</b>			
90	03.92>06.95	530	530
100 /Avant	12.90>07.94	550	510
80/Avant	09.91>07.95	530	510
A1/A1 Sportback	05.10>	600	380
A2	09.99>06.01	700	
A2	07.01>08.05	700	
A3 cabrio	04.08>	600	450
A3/S3	09.96>06.03	530	480
A3/Sportback	12.04>2012	600	480
A3/Sportback	2012>	600	480
A4/A4 Avant	11.94>09.01	530	530
A4/avant/cabrio	11.03>06.08	550	550
A4/avant/Allroad	11.07>	600	510
A5/Sportback/cabrio	06.07>	600	510
A6/Avant	06.94>05.01	550	530
A6/Avant/Allroad	06.01>05.12	550	550
A6 Avant/Allroad	01.12>	650	530
A6/A6 Avant	06.94>12.97	550	530
A6/Avant /Allroad	2011>	650	530
A7 Sportback	07.10>	600	510
A8 / S8	94>02	550	530
A8 / S8	11.09>	650	510
Cabriolet	06.91>08.00	550	530
Q3	06.11>	600	510
Q5	06.2008>	600	510
Q7	03.06>02.15	650	600
S1	01.11>	600	380
S3	08.98>06.03	530	480
S3/Sportback	11.06>	600	480
S4/Avant	08.98>09.01	530	530
S4/Avant/Cabrio	03.09>	550	550
S5 tutte	11.07>	600	510
S6	06.94>10.97	550	530
S6/Avant	04.12>	650	530
TT Coupé/ TT Roadster	07.98>04.03	550	530
TT Coupé/ TT Roadster	07.06>	550	530
TT Coupé/ TT Roadster	10.03>06.06	530	530
<b>BMW</b>			
Serie 1 (E81/E82/E88/E87)	09.04> 09.11	510	510
Serie 1 (F20/F21)	09.11>	550	450
Serie 3 (E36) berlina/cabrio/touring	09.90>12.98	530	510
Serie 3 (E46) berlina/cabrio/touring	04.98>09.05	600	480
Serie 3 berlina (E90) e Touring (E91)	03.05>2011	600	480
Serie 3 Compact (E46)	06.01>12.04	600	480
Serie 3 Compact (E36)	03.94>09.00	510	510
Serie 3 berlina (F30) e touring (F31)	2012>	600	480
Serie 3 Coupé (E92)	09.09>	600	410

APPLICATIVO SPAZZOLE  
TERGIVETRO

MARCA	ANNO	LATO GUIDA	LATO PASS.
Serie 5 (E34) berlina e touring	01.88>12.95	600	600
Serie 5 berlina (E60) e touring (E61)	07.03>02.10	600	550
Serie 5 GT (F07)	10.09>	650	450
Serie 5 Touring (F11)	09.10>	650	450
Serie 5 (F10)	03.10>	650	450
Serie 6/Cabrio (E63/E64)	04.04>2010	600	550
Serie 6 (F12)	03.11>	650	410
Serie 7 (E38-E65-E66)	06.94>10.08	600	600
Serie 7 (F01)	11.08>	650	450
Serie M (E60/E63)	11.04>2008	600	550
Serie M /cabrio/coupè (E36)	09.92>12.99	530	510
Serie M Cabrio (E64)	11.06>02.08	600	550
Serie M Cabrio/Coupé (E46)	09.00>08.06	550	510
Serie M Touring (E34)	04.92>12.95	600	600
X1 (E84)	11.09>	600	480
X3 (E83)	01.04>2010	550	510
X3 (F25)	09.10>	650	510
X5 (E53)	03.99>10.06	600	550
X5 (E70)	11.06>2013	600	510
X6 (E71)	03.08>10.14	600	510
Z3 (E36/37) / Z3 coupé (E36/38)	03.95>09.02	510	510
Z4 (E85) / Z4 coupé (E86)	10.02>07.07	530	510
Z4 (E89)	04.09>	530	530
<b>CADILLAC</b>			
SRX	09.03>08.09	550	530
Escalade	09.06>	550	530
<b>CHEVROLET</b>			
Aveo/Kalos (Daewoo)	04.08>2011	550	410
Aveo	06.2011>	650	380
Captiva	10.06>	600	410
Cruze/SW	2010>	600	450
Epica / Evanda	06.06>2010	550	510
Kalos	02.05>2008	550	410
Lacetti (Daewoo)	02.05>2010	550	480
Lanos	01.04>2006	480	480
Matiz	02.05>2009	550	350
Nubira/SW	02.05>2010	550	480
Orlando	10>	600	480
Spark	12.09>	550	380
Tacuma	09.00>02.05	600	450
Trax	2013>	650	350
Trailblazer	01>2008	550	550
Volt	10.11>	650	650
<b>CHRYSLER</b>			
300/300C - 300C Touring	10.04>	550	530
300L	01.05>	550	550
300M	06.98>12.04	600	480
Crossfire Coupé/Roadster	03.02>2008	550	510
Grand Voyager	09.07>	650	510
PT Cruiser/Cabrio	06.00>2008	530	510
Sebring Coupé	95>00	600	550
Sebring/Cabrio	10.00>12.06	550	530
Sebring/Cabrio	01.07>	600	550
Stratus/Cabrio	08.95>04.01	550	530
Voyager	01.96>2008	700	700
Voyager	2009>	650	510
<b>CITROEN</b>			
AX	06.90>12.98	550	
Berlingo	05.08>	650	410
Berlingo	07.96>04.08	550	530
C1	06.05>2014	650	
C2	09.03>2009	600	450
C3	01.02>2009	600	410
C3	09.09>	650	410
C3 Picasso	02.09>03.10	600	410
C3 Picasso	04.10>	600	410
C3 Pluriel	05.03>2009	550	450
C3 XTR	02>2009	600	450
C4 / C4 Coupé	11.04>2010	700	600

Image: Goodyear Rain Master Flat Wiper Blade shown with a selection of included adapters for different vehicle wiper arm types.

## SETUP AND INSTALLATION

---

Proper installation is crucial for optimal performance and safety. Refer to your vehicle's owner's manual for specific wiper blade removal instructions if needed.

### **Compatibility Check**

Before installation, confirm that the 330mm wiper blade is the correct size for your vehicle's passenger side (or driver's side if applicable) and that the appropriate adapter is selected. The following charts provide a general guide for vehicle compatibility. Locate your vehicle's make and model to determine the correct wiper blade length for both driver (Lato Guida) and passenger (Lato Pass) sides.

MARCA	ANNO	LATO GUIDA	LATO PASS.	MARCA	ANNO	LATO GUIDA	LATO PASS.
C4 Aircross	2012>	600	530	Croma	06.05>2011	600	410
C4	09.10>	700	650	Croma	05.91>12.96	510	480
C4 Picasso/Grand Picasso	04.08>	700	700	Doblò	10.09>	600	410
C5 - C5 Tourer	04.08>	700	550	Doblò	07.00>2009	550	450
C5/Break	06.01>11.03	650	450	Ducato	03.94>08.06	550	530
C5/Break	12.03>03.08	650	480	Ducato	06.06>	650	550
C6	11.05>2012	700	700	Fiorino	09.93>12.01	450	
C8	08.05>	650	650	Fiorino	12.07>	650	450
C-Crosser	09.07>	600	530	Freemont	2011>	600	480
CX	>92	600		Grande Punto	10.05>	650	350
C Zero	10.10>	700		Idea	04.08>2012	550	380
DS3	11.09>	600	510	Idea	01.06>03.08	550	380
DS4	03.11>	700	650	Idea	01.04>12.05	550	410
DS5	09.11>	700	650	Marea/Marengo/weekend	10.96>2002	550	480
Jumper	02.94>05.06	550	530	Marengo	02.90>12.96	510	510
Jumper	06.06>	650	530	Marengo	01.97>09.02	550	480
Jumpy	10.95>2007	650	510	Multipla	01.06>2011	600	550
Jumpy	02.07>	700	510	Multipla	01.99>12.05	600	530
Nemo	02.08>	650	480	Palio/Weekend	09.97>2003	550	450
Saxo	02.96>09.03	510	450	Panda / 4x4	80>03	410	
Xantia/Break	01.93>11.01	600	510	Panda Classic/4x4	10.03>2011	550	410
XM	91>98	550		Panda/Panda 4x4/Panda Trekking	2012>	600	350
Xsara Picasso	01.00>2013	650	650	Punto 3/5p / Punto Van	07.99>2010	530	450
Xsara/coupé/break	07.97>2010	550	510	Punto e Van	08.93>08.99	550	410
ZX/Break	03.91>02.98	550		Punto Evo	10.09>	650	380
<b>DACIA</b>				Qubo	09.08>	650	450
Duster/Logan I/MCV/Sandero I	07.04>	510	510	Scudo	09.95>04.98	700	510
Dokker/Lodgy	08.12>	550	410	Scudo	05.98>01.07	650	510
Sandero II/Logan II	08.12>	550	510	Scudo	01.07>	700	510
<b>DAEWOO</b>				Sedici	05.06>2013	650	350
Kalos - 3/5p.	09.02>01.05	550	410	Seicento	03.98>2010	480	480
Leganza/Evanda	03.97>01.05	550	510	Siena	05.98>12.01	550	450
Matiz	04.98>01.05	530	380	Stilo/Multi W	10.01>06.05	530	480
Nubira s.w.	10.99>06.03	550	480	Stilo/Multi W	07.05>12.07	550	480
Nubira/SW	09.97>09.99	510	510	Tempra/SW	02.90>12.96	510	510
Lanos	96>03	480	480	Tipo	07.87>03.93	480	480
Tacuma	04.00>01.05	600	480	Ulysse	09.94>09.02	650	510
<b>DAIHATSU</b>				Ulysse	11.05>12.10	650	650
Charade - 3/5p.	01.93>09.00	480	410	Uno	83>95	450	
Copen	03>2010	450	410	<b>FORD</b>			
Cuore	10.98>03.03	450	380	B-Max	2012>	700	600
Cuore	03.03>	530		C-Max	03.07>07.10	650	480
Materia	09.06>	510	480	C-Max/Grand C-Max	08.10>	700	600
Feroza	10.88>10.99	410	410	Cougar	08.98>12.00	550	510
Rocky	84>02	410	410	Escort/SW	07.90>07.00	510	510
Sirion	04.98>07.04	480	410	Escort/S.W.	06.85>10.90	450	450
Sirion	10.04>	510	410	Fiesta	11.01>07.08	550	410
Terios	03.97>12.05	510	380	Fiesta	03.89>12.02	480	480
Terios	01.06>	530	450	Fiesta	07.08>	650	380
Trevis	08.06>	510	410	Focus	07.04>2011	650	410
<b>DODGE</b>				Focus e sw	07.04>10.08>	650	410
Avenger	01.07>2011	600	550	Focus s.w.	11.08>2011	650	410
Caliber	01.06>2011	600	410	Focus/SW	08.98>05.05	550	480
Journey	03.08>2011	600	450	Focus/Wagon	01.2011>	700	700
Nitro	01.07>2011	480	480	Fusion	10.02>2010	550	410
<b>FERRARI</b>				Galaxy	04.01>08.06	700	700
348	02.90>04.94	510	510	Galaxy	03.06>	700	650
360 Modena	03.99>2006	600	530	Ka	09.96>09.08	480	410
F355	95>1999	530	510	Ka	09.08>	600	350
<b>FIAT</b>				Kuga	02.08>2012	600	410
126	87>00	330	330	Kuga	11.2012>	700	700
500	07.07>	600	350	Mondeo I/II 4/5p	01.93>09.00	530	510
500X	2015>	650	350	Mondeo III/SW	10.00>03.07	550	510
500L	09.12>	650	380	Mondeo IV/SW	02.07>	650	480
Barchetta	01.95>02.05	480	480	Puma	06.97>12.01	480	480
Brava/Bravo	10.95>09.01	550	510	Ranger	94>09	450	450
Bravo	03.07>	600	450	Ranger	09.11>	600	410
Cinquecento	07.91>07.98	480	480	Scorpio/SW	02.92>12.98	510	510
Coupé	02.94>09.00	530	480	S-Max	03.06>	750	650

APPLICATIVO SPAZZOLE  
TERGIVETRO

Image: Compatibility chart for various car brands (Abarth, Alfa Romeo, Audi, BMW) showing recommended wiper blade lengths for driver and passenger sides.



MARCA	ANNO	LATO GUIDA	LATO PASS.
Tourneo Connect/Transit Connect	05.02>	550	510
Transit	08.91>08.00	550	530
Transit Tourneo/Transit	01.00>	700	600
Transit Tourneo	08.91>08.00	550	530
<b>GREAT WALL</b>			
Hover	02.07>	510	480
Steed	12.06>	550	480
Voleex	2013>	600	380
<b>HONDA</b>			
Accord/Accord Tourer	07.08>	600	550
Accord 3/Sp.	10.98>02.03	550	480
Accord 4p.	01.90>02.03	550	480
Accord Aerodeck/Coupè	91>98	550	510
Accord e Acc. Tourer	02.03>08.08	650	410
Civic Aerodeck	03.98>02.01	510	450
Civic	10.95>02.01	510	450
Civic	02.01>12.05	600	380
Civic	01.06>08.11	700	550
Civic	09.11>	650	450
Civic (TUTTE)	91>2000	510	450
Civic 4p.	09.05>2012	650	550
Civic 4p/Coupè	02.01>01.06	530	480
Civic Coupè	09.92>08.00	510	450
Civic CRX	03.92>12.98	510	450
Civic Fastback	09.94>02.01	510	450
Civic Hybrid	01.06>12.07	700	550
Civic Hybrid	01.08>	650	550
Civic/4p/Aerodeck	10.95>02.01	510	450
CR-V	10.95>02.02	480	480
CR-V	03.02>09.06	530	510
CR-V	01.07>2012	650	410
CR-V	2013>	650	410
CR-Z	03.10>	650	510
FR-V	01.05>2010	650	450
HR-V	12.98>12.05	510	450
Insight	08.00>12.06	510	450
Insight	04.09>	650	410
Jazz	03.02>12.08	530	380
Jazz	11.08>	650	350
Legend	01.96>12.04	510	480
Logo	10.96>06.01	510	450
Prelude	02.92>09.96	530	480
Shuttle	01.95>05.01	550	550
Stream	05.01>2009	600	350
S2000	04.99>06.09	510	410
<b>HUMMER</b>			
H2 e H3	04>10	410	410
<b>HYUNDAI</b>			
Accent 3/4/Sp.	04.06>01.11	550	410
Accent 3/Sp.	08.94>03.06	510	450
Accent Blue	01.11>	650	410
Atos/Atos Prime	09.97>03.08	510	410
Coupè	05.96>2008	550	450
Elantra	10.90>2011	510	450
Gallopèr	98>2005	450	450
Genesis coupè	10.08>	600	510
Getz	09.02>2009	550	350
H-1	10.97>05.07	650	510
H-1	03.08>	600	510
H100	05.05>	450	450
i10	03.08>	550	410
i20	01.09>	600	410
ix20	2010>	650	350
i30 - i30 CW	09.07>03.10	600	450
i30 - i30 CW	04.10>	600	450
ix35	03.10>	600	410
i40 / wagon	2012>	650	410
Lantra/sw	10.90>09.00	510	450
Matrix	08.01>2009	550	410

#### APPLICATIVO SPAZZOLE TERGIVETRO

MARCA	ANNO	LATO GUIDA	LATO PASS.
Pony	07.94>07.99	510	450
Santa Fé	09.99>12.05	550	510
Santa Fé	11.05>2012	600	450
Santa Fé	06.12>	650	330
Sonata	03.98>03.01	510	510
Sonata	04.01>11.04	550	510
Sonata	12.04>2008	600	510
Terracan	07.01>2006	550	510
Trajet	01.00>06.07	650	550
Tucson	08.04>2010	600	410
Veloster	06.11>	650	450
<b>INFINITI</b>			
FX	10.08>	550	510
EX	04.08>	600	450
<b>INNOCENTI</b>			
Elba	08.91>03.96	450	
Mille	07.94>11.97	450	450
<b>ISUZU</b>			
D-Max	05.02>	550	480
Trooper	08.92>09.04	510	510
<b>JAGUAR</b>			
S-Type	10.98>04.02	550	550
S-Type	2002>2008	600	450
XF/SportBrake	03.08>	600	480
XJ	08.10>	600	480
XJ8 / XJR8	09.97>01.03	530	
XJS	>96	380	380
XK 8	01.99>2008	530	530
XKR 8	01.99>2008	530	530
X-Type / X-Type s.w.	03.01>2010	550	480
<b>JEEP</b>			
Cherokee	03.01>12.07	480	480
Compass	10.06>	550	510
Grand Cherokee	09.91>04.99	510	510
Grand Cherokee	04.99>2010	530	530
Grand Cherokee	2010>	550	530
Patriot	10.06>	530	530
Renegade	2015>	550	510
Wrangler	01.97>2007	380	380
Wrangler	01.07>	380	380
<b>KIA</b>			
Carens	04.99>12.06	600	450
Carens	04.06>2010	650	450
Carnival	06.98>2006	600	600
Carnival	01.06>	650	450
Cee'd/SW/Pro Cee'd	11.06>06.09	600	450
Cee'd/SW	2009>	600	450
Cerato	03.04>2008	600	410
Magentis	09.00>12.05	550	510
Picanto	05.04>	550	410
Pride	05.90>02.00	450	450
Rio	03.05>2011	550	410
Rio s.w.	09.02>02.05	530	450
Rio	2011>	650	410
Shuma	01.98>08.04	530	480
Sorento	07.02>2008	600	450
Sorento / Soul	09.08>	600	510
Sportage	05.93>08.04	510	510
Sportage	08.04>2010	600	410
Sportage	2010>	600	450
Venga	12.09>	650	350
<b>LADA</b>			
Niva	09.02>	510	510
<b>LANCIA</b>			
Dedra SW/Delta	01.93>10.99	530	480
Delta	07.08>	600	450
Flavia	06.12>	600	550
Kappa / SW	11.94>12.00	600	510
Lybra/SW	10.99>11.06	550	530

Image: Compatibility chart for various car brands (Cadillac, Chevrolet, Chrysler, Citroen, Dacia, Daewoo, Daihatsu, Dodge, Ferrari, Fiat, Ford) showing recommended wiper blade lengths for driver and passenger sides.

MARCA	ANNO	LATO GUIDA	LATO PASS.
Musa	01.06>09.07	550	380
Musa	10.07>2012	550	380
Musa	10.04>12.05	550	410
Phedra	10.05>2011	650	650
Thema / SW	05.92>11.94	510	510
Thema	2012>	600	530
Thesis	04.02>2011	650	510
Thesis / Zeta	09.94>06.02>	650	510
Voyager	2011>	650	510
Y	01.96>06.03	550	410
Y10	85 > 96	450	450
Ypsilon	06.03>2011	600	410
Ypsilon	2011>	600	380
Zeta	09.94>06.02	650	510
<b>LAND ROVER</b>			
Defender 90/110	85>	330	330
Discovery I/II	09.89 > 12.04	450	450
Discovery III/IV	10.04>	550	530
Evoque	2011>	600	530
Freelander I	09.97>03.07	550	530
Freelander II	10.06>	600	480
Range Rover I	11.88>04.96	450	450
Range Rover II	09.94>09.02	550	550
Range Rover	09.11>	600	530
Range Rover Sport	03.05>2013	550	530
<b>LEXUS</b>			
CT200	2010>	650	450
ES	03.06>	600	480
GS	08.97>2012	600	510
IS	01.99>07.05	550	480
IS/C	08.05>	550	510
LS	08.00>2010	600	410
LX	11.07>	600	550
LX 470	98>2007	510	510
RX	02.03>	650	550
RX	01.98>02.03	600	530
<b>MAZDA</b>			
2	06.07>	600	330
2	02.03>06.07	600	410
3	07.03>12.08	530	480
3	12.08>	600	480
5	02.05>	650	410
6/Wagon	08.07>05.2013	600	410
6/Wagon	2013>	600	450
323	05.98>09.03	530	450
6/berlina/W	02.02>08.07	550	480
626/SW	05.97>09.99	530	450
626 Fastback	08.99>04.02	530	450
B Serie/BT-50	03.96>03.06	450	450
CX-5	04.2012>	600	450
CX-7	12.06>	650	410
CX-9	09.06>	650	410
MPV	06.99>08.04	600	600
MX-3	05.91>01.99	530	450
MX-5	89>	450	450
Premacy	03.99>05.05	600	410
RX-7 Coupé	08.93>02.96	510	510
RX-8	04.03>2011	510	450
Tribute	02.01>2010	480	480
<b>MAZDA</b>			
CL	03.00>	650	650
CLA	03.13>	650	600
A	10.97>08.04	650	600
A	09.04>2012	650	550
A	06.12>	600	480
B	09.04>2011	650	550
B	2012>	650	480
C (W202)	03.93>04.00	600	
C (W203)	05.00>06.03	600	530
C (W204)	03.07>	600	600
C S.W. (S202)	05.96>02.01	600	
C S.W. (S203)	01.01>06.03	600	530
C S.W. (S204)	09.07>	600	600
C Sportcoupé (W203)	01.01>06.03	600	530
C Coupe	03.11>	600	600
E (W124)	02.92>07.95	600	
E (W210)	06.95>01.03	650	
E (W211)	03.02>2008	650	650
E (W212)	08.08>	600	600
E cabrio/coupé	03.93>06.98	600	
E cabrio/coupé	02.09>	600	600
E S.W. (S124)	07.93>05.96	600	
E S.W. (S210)	05.96>01.03	650	
E S.W. (S211)	02.03>08.09	650	650
E S.W. (S212)	08.09>	600	600
G (tutte)	79>	410	410
GL (164)	02.06>	700	530
GLA	02.14>	600	480
GLK (204)	06.08>	550	450
ML (163)	03.98>06.05	550	530
ML/GL (164)	07.05>2011	700	530
ML (166)	09.11>	650	550
R (251)	02.06>	700	530
S	03.00>	650	650
Citan (fix. a gancio e spina)	07.12>	550	530
CLK (C208)	01.97>06.02	600	
CLS (C219)	06.04>2010	650	650
CLS (C218)/Shooting Brake	10.10>	600	600
SL (129)	07.93>08.01	600	
SL (230)	10.01>	650	650
SLK	09.96>03.04	550	530
SLK	04.04>	550	550
SLR	04.04>	650	650
Sprinter	02.95>05.06	600	530
Sprinter	04.06>	650	600
Vaneo	02.04>08.05	650	550
Vaneo	02.02>01.04	650	600
Vario	01.96>09	600	
Viano	09.05>	700	650
Vito	10.03>	700	650
<b>MINI</b>			
Clubman	11.07>	450	450
Mini/Cabrio	06.01 >2014	450	450
Contryman	2010>	480	510
Coupé/Roadster	2011>	510	510
Paceman	2013>	480	510
<b>MITSUBISHI</b>			
ASX	04.10>	600	530
Carisma	05.96>12.03	530	510
Colt	11.95>06.03	530	480
Colt	04.04>2010	650	300
Eclipse	01.90>03.94	510	510
Galant / SW	10.96>09.02	530	450
Galant 3/5p.	11.92>10.96	530	480
Galoper	05.98>12.01	450	450
Grandis	01.04>2010	700	550
L200	12.05>10.09	530	480
L200	11.09>	550	450
L410	12.94>03.01	650	650
Lancer	03.07>	600	410
Lancer	11.95>05.01	530	480
Lancer/SW	12.00>04.10	600	450
Outlander	02.07>2012	600	550
Outlander	04.12>	650	450
Pajero	06.00>10.06	510	510
Pajero	12.90>06.00	480	480
Pajero	10.06>	550	510
Pajero Pinin	06.98>2008	480	480

APPLICATIVO SPAZZOLE  
TERGIVETRO

Image: Compatibility chart for various car brands (Honda, Hummer, Hyundai, Isuzu, Jaguar, Jeep, Kia, Lada, Lancia, Land Rover, Lexus, Mazda, Mercedes-Benz, Mini, Mitsubishi, Nissan, Opel) showing recommended wiper blade lengths for driver and passenger sides.

MARCA	ANNO	LATO GUIDA	LATO PASS.
Pajero Sport	07.96>02.09	510	510
Pajero Sport	07.08>	550	450
Space Wagon	06.92>11.00	550	510
Spacestar	06.98>	530	450
<b>NISSAN</b>			
350 Z Cabrio/Coupé	07.03>2010	510	450
Almera	01.00>11.06	550	410
Almera	07.95>04.00	530	480
Almera Tino	05.00>12.05	650	450
Cabstar	10.98>08.06	450	450
Cabstar	09.06>	510	510
Cube	08.09>	510	510
Evalia	01.11>	550	410
Kubistar (con port.post.)	07.03>	510	510
Maxima QX	10.94>01.00	530	530
Maxima QX	01.00>01.06	650	450
Micra	08.92>10.02	510	450
Micra / Micra CC	11.02>05.05	530	450
Micra	06.05>2010	530	450
Micra	2010>	530	330
Murano	09.04>12.08	650	450
Murano	06.08>	650	410
Navara	06.00>2005	480	480
Navara / Pathfinder	05.05>	600	480
Note	01.06>2013	600	350
NV200	08.09>	550	410
Pathfinder	10.97>12.04	550	510
Pathfinder/Navara	01.05>	600	480
Patrol	89>98	480	480
Patrol GR	08.97>	510	510
Patrol GR	08.87>11.97	480	480
Pick-up	08.87>05.98	480	480
Pixo	03.09>	550	350
Primastar (c/porta post.)	07.02>	600	530
Primera 4/5p	06.96>12.01	530	510
Primera 4/5p/W	06.90>06.96	530	480
Primera 4/5p/W	12.01>2010	650	450
Primera Wagon	01.98>12.01	530	510
Primera Wagon	12.01>2010	650	450
Qashqai - Qashqai+2	12.06>2013	600	380
Juke	2010>	550	350
Serena	12.01>05.05	550	410
Vanette	07.92>11.01	600	600
Sunny 3/4/5p/W	10.90>05.95	530	480
Terrano	86>96	450	450
Terrano II	05.96>12.06	530	510
Vanette Cargo	07.92>11.01	600	600
X-Trail	06.01>	600	410
<b>OPEL</b>			
Adam	13>	650	410
Agila	00>08	510	450
Agila	03.08>	550	410
Ampera	2012>	650	650
Antara	05.06>	600	410
Astra/SW	09.91>02.98	450	450
Astra/GTC/Twin Top/SW	03.04>08.09	550	450
Astra/S.Tourer/4 porte/GTC	09.09>	700	600
Astra (TUTTE)	09.97>12.05	510	480
Combo (con port. post. diviso)	10.01>2011	510	450
Combo	2012>	510	410
Corsa B 3p/5p.	03.93>09.00	450	450
Corsa C	09.00>09.06	510	450
Corsa D	07.06>	650	410
Frontera	10.98>2005	480	480
Insignia/Sports Tourer	09.08>	600	450
Meriva	04.10>	700	550
Meriva	03.03>03.10	600	600
Mokka	09.12>	650	350
Movano	04.10>	650	650

#### APPLICATIVO SPAZZOLE TERGIVETRO

MARCA	ANNO	LATO GUIDA	LATO PASS.
Omega B	09.93>09.03	600	480
Signum	05.03>09.08	600	480
Tigra	09.94>08.99	450	450
Tigra TwinTop	06.04>2009	510	450
Vectra	88>2003	480	480
Vectra C / SW	09.01>10.08	600	480
Vectra S.W.	09.95>09.03	480	480
Vivaro (con port post.)	03.01>	600	530
Zafira	07.05>2011	700	550
Zafira	03.99>07.05	600	600
<b>PEUGEOT</b>			
106	07.95>05.05	510	450
107	06.05>	650	
205	10.87>09.98	450	450
206/Plus/CC/SW	06.98>	650	410
208	01.12>	650	410
306/ Break	01.93>10.03	550	510
406 Tutte	10.95>03.04	600	550
806	06.94>08.02	650	510
807	08.05>	650	650
1007	04.05>2010	600	450
4007	09.07>	600	530
4008	03.12>	600	530
206 - tutte	06.98>02.09	650	410
207 - tutte	05.06>	650	410
307 - 307 S.W.	08.00>2008	700	650
307 CC	10.03>05.05	700	600
307 CC	06.05>2009	700	650
308/SW/CC	2008>	700	650
405 / SW	01.87>10.96	550	550
406 / SW	10.95>06.04	600	550
406 coupé	03.97>02.05	650	510
406 S.W.	10.96>06.04	600	550
407 - tutte	05.04>2010	700	700
408	05.10>	700	650
508/SW	2010>	650	650
Bipper	02.08>	650	480
Boxer	02.94>06.06	550	530
Boxer	06.06>	650	550
Expert	05.98>01.07	650	510
Expert	09.95>2008	700	510
Ion	10.10>	700	
Partner	05.08>	650	410
Partner (2 porte)	07.96>04.08	550	530
Ranch (2 porte)	07.97>2008	550	530
RCZ	01.10>	650	650
<b>PORSCHE</b>			
911	09.93>08.97	450	410
928/944 /968	08.91>11.95	480	480
911 e GT2	09.97>09.05	550	530
911 GT3	08.04>	550	530
Cayman	11.05>01.09	550	530
Panamera	03.09>	600	530
Macan	2014>	600	500
Boxter	10.96>2012	550	530
Carrera 2 (966)	97>	550	550
Cayenne	09.02>	650	650
<b>RENAULT</b>			
Captur	2013>	650	330
Clio I	03.94>02.98	510	510
Clio II	03.98>05.09	530	450
Clio II Storia	06.09>	510	450
Clio III	06.07>2013	600	410
Clio IV/Grandtour	04.13>	650	350
Espace IV	11.02>	700	650
Express	03.86>10.97	450	450
Fluence	11.09	600	410
Kangoo I (con porta post.)	10.97>12.07	510	480
Kangoo II (fiss. gancio)	01.08>	550	530

Image: Compatibility chart for various car brands (Peugeot, Porsche, Renault, Rover, Saab, Ssangyong, Seat, Skoda, Smart, Subaru, Suzuki, Toyota, Volkswagen, Volvo) showing recommended wiper blade lengths for driver and passenger sides.

## Installation Steps

- 1. Remove Old Wiper Blade:** Lift the wiper arm away from the windshield. Locate the release tab or button on the old wiper blade assembly. Press or slide the tab and slide the old blade off the wiper



arm hook.

2. **Select Correct Adapter:** Identify the adapter that matches your vehicle's wiper arm type from the provided assortment. Attach the chosen adapter securely to the new Goodyear wiper blade.
3. **Install New Wiper Blade:** Slide the new wiper blade, with the correct adapter attached, onto the wiper arm hook until it clicks into place. Gently lower the wiper arm back onto the windshield.
4. **Test Operation:** Before driving, activate your vehicle's wipers to ensure proper installation and full contact with the windshield. Check for any streaks or missed areas.

## OPERATING INSTRUCTIONS

The Goodyear Rain Master Flat Wiper Blade operates automatically with your vehicle's wiper system. For optimal performance, use the wipers only when the windshield is wet. Operating wipers on a dry windshield can cause premature wear to both the blade and the windshield surface.

## MAINTENANCE

Regular maintenance extends the life and effectiveness of your wiper blades:

- **Clean Blades Regularly:** Wipe the rubber edge of the wiper blades with a damp cloth or a mild glass cleaner to remove dirt, grime, and road film.
- **Inspect for Damage:** Periodically check the rubber blade for cracks, tears, or hardening. Damaged blades should be replaced immediately.
- **Avoid Harsh Chemicals:** Do not use petroleum-based cleaners or solvents on the wiper blades, as these can degrade the rubber.
- **Clear Windshield:** Ensure your windshield is free of ice and heavy snow before operating wipers to prevent damage.

## TROUBLESHOOTING

If you experience issues with your wiper blades, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Streaking or Smearing	Dirty blade, worn rubber, or incorrect blade angle.	Clean the blade with a damp cloth. Inspect for wear and replace if necessary. Check wiper arm for proper tension and angle.
Chattering or Skipping	Dry windshield, bent wiper arm, or blade not making full contact.	Ensure windshield is wet. Check wiper arm for bends or damage. Verify blade is securely attached and making even contact.
Incomplete Wipe Area	Incorrect blade length or worn blade.	Confirm correct blade length for your vehicle. Replace blade if worn.
Noise during Operation	Dry windshield, dirty blade, or worn blade.	Ensure windshield is wet. Clean the blade. Replace if worn.

Problem	Possible Cause	Solution
Blade Detaches from Arm	Improper adapter selection or insecure installation.	Re-attach blade, ensuring the correct adapter is used and it clicks securely into place.
Wiper Arm Damage	Forcing blade onto incorrect adapter or arm.	Always use the correct adapter and avoid excessive force during installation. Consult a professional if the wiper arm is damaged.

## SPECIFICATIONS

---

- **Brand:** Goodyear
- **Model Number:** 77600
- **Type:** Flat Wiper Blade (Rain Master, New Technology)
- **Length:** 330 mm
- **Installation Type:** Latch (Loquet)
- **Color:** Black
- **Item Weight:** Approximately 89.7 grams (3.17 ounces)
- **Manufacturer:** BOTTARI
- **Country of Origin:** China

## WARRANTY AND SUPPORT

---

For warranty information or technical support regarding your Goodyear 77600 Rain Master Flat Wiper Blade, please refer to the documentation included with your purchase or contact Goodyear customer service directly. Keep your proof of purchase for any warranty claims.