

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [MaxMate](#) /

› [MaxMate WB2C33807 3-inch Stainless Steel Nerf Bars Installation and User Manual](#)

MaxMate WB2C33807

MaxMate 3-inch Stainless Steel Nerf Bars

MODEL: WB2C33807

User Manual

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your MaxMate 3-inch Stainless Steel Nerf Bars (Model WB2C33807). These side step rails are designed to enhance vehicle accessibility and appearance. Please read this manual thoroughly before installation and use to ensure proper function and safety.

Product Compatibility

The MaxMate WB2C33807 Nerf Bars are compatible with the following vehicle models:

- 1988-1998 Chevy/GMC C/K Pickup Regular Cab
- 1992-1994 Chevy Blazer 2-Door (Exclude ZR2)
- 1995-1999 Chevy Tahoe 2-Door
- 1992-1999 GMC Yukon 2-Door

Note: Not compatible with vehicles equipped with power retracting boards.



Figure 1: Vehicle Cab Type Compatibility. Ensure your vehicle is a Regular Cab (2 doors only) for proper fitment. Extended Cab and Double Cab models are not compatible.

Product Features

- **Elegant Curved Tube Design:** Captivating round tubes wrap along the contour of the vehicle's rocker panels for a stylish look. The curved design provides a wider profile for safer entry and exit.
- **Polished Stainless Steel Finish:** Constructed from heavy-duty 3-inch round polished stainless steel tubes, offering rust and corrosion resistance.
- **UV Resistant Non-Slip Step Pads:** Features wide step pads designed to provide secure footing in various weather conditions.
- **Durable Construction:** Engineered for long-lasting performance and durability.



Figure 2: Close-up of the durable stainless steel construction and non-slip step pads.

Setup and Installation

Installation of the MaxMate Nerf Bars is designed to be straightforward and typically takes approximately 20 minutes. No drilling is required for most installations.

Package Contents:

- Driver side step bar (1)
- Passenger side step bar (1)
- Mounting bracket kit (includes all necessary brackets and hardware)



Figure 3: Product as received in its original packaging.

Installation Steps:

1. **Unpack Components:** Carefully remove all components from the packaging and verify that all parts listed above are present.
2. **Identify Mounting Points:** Locate the factory mounting points on your vehicle's rocker panel. These are typically pre-drilled holes in the vehicle's frame or body.
3. **Attach Brackets:** Secure the mounting brackets to the vehicle's frame using the provided hardware. Ensure all bolts are hand-tightened initially.
4. **Position Nerf Bars:** Attach the nerf bars to the installed brackets. The brackets are adjustable, allowing you to position the step bars closer to the body or slightly lower, depending on preference and vehicle height.
5. **Final Tightening:** Once the nerf bars are correctly positioned and level, fully tighten all bolts to the manufacturer's recommended torque specifications. Refer to the specific hardware instructions for torque values.

For a visual guide on installation and usage, please refer to the video below:

[Your browser does not support the video tag.](#)

Video 1: DNA MOTORING Running Boards. This video demonstrates the installation and functionality of running boards on a truck, providing a general overview of the process and benefits.

Operating Instructions

To use your MaxMate Nerf Bars:

1. **Step onto the Bar:** Place your foot firmly on the non-slip step pad of the nerf bar. Ensure your entire foot is on the pad for maximum stability.
2. **Enter/Exit Vehicle:** Use the nerf bar as a stable step to assist in entering or exiting your vehicle.



Figure 4: Proper foot placement on the nerf bar for safe entry into the vehicle.

Maintenance

To ensure the longevity and appearance of your MaxMate Nerf Bars:

- **Regular Cleaning:** Clean the stainless steel surfaces and non-slip pads regularly with mild soap and water. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspect Fasteners:** Periodically check all mounting bolts and fasteners to ensure they remain tight. Re-tighten if necessary to prevent loosening due to vehicle vibration or road conditions.
- **Check for Damage:** Inspect the nerf bars for any signs of damage, such as dents, cracks, or corrosion. Address any issues promptly to maintain structural integrity and appearance.

Troubleshooting

- **Loose or Wobbly Step Bars:** If the step bars feel loose, check all mounting bolts and brackets. Ensure they are securely tightened. Over time, bolts can loosen due to vibrations.
- **Difficulty with Installation:** If you encounter difficulties during installation, double-check the compatibility with your specific vehicle model and cab type. Ensure you are using the correct mounting points and hardware. Some users have reported needing slightly longer bolts for lifted trucks; verify if this applies to your setup.
- **Corrosion or Rust Spots:** While made of stainless steel, prolonged exposure to harsh elements or certain chemicals can cause surface discoloration. Clean immediately with appropriate stainless steel cleaner and avoid prolonged contact with road salts or strong acids.

Specifications

Brand	MaxMate
Model Number	WB2C33807
Material	Stainless Steel
Exterior Finish	Stainless Steel
Color	Stainless Steel
Item Dimensions (L x W x H)	50.75 x 3 x 9.72 inches
Item Weight	28.66 Pounds
Vehicle Service Type	Sport Utility Vehicle
Automotive Fit Type	Vehicle Specific Fit

Warranty Information

MaxMate offers a Limited 5 Year Warranty against manufacturer defects for customers in the US. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty documentation included with your product or contact MaxMate customer support.

Support

For further assistance, technical support, or to inquire about replacement parts, please visit the official MaxMate website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's online store.

