

[Manuals.plus](#) /

› [Puig](#) /

› Puig 7070N Black WindShield (V-Techline Touring BMW C600S 12-13) - Instruction Manual

Puig 7070N

Puig 7070N Black WindShield Instruction Manual

MODEL: 7070N

Brand: Puig

1. INTRODUCTION

This instruction manual provides essential information for the proper installation, operation, maintenance, and troubleshooting of your Puig 7070N Black WindShield. This windshield is specifically designed for BMW C600S models from 2012-2013, offering enhanced wind protection and a sleek aesthetic. It is constructed from high-impact acrylic for durability and flexibility.

2. PRODUCT OVERVIEW

The Puig 7070N WindShield is a V-Techline Touring model, engineered to integrate seamlessly with your motorcycle's design while providing superior aerodynamic performance. Its black finish complements various bike styles.



Figure 1: Puig 7070N Black WindShield. This image displays the Puig 7070N Black WindShield, showcasing its sleek design and black

finish. The windshield is made of high-impact acrylic, designed to offer increased protection against windblast for motorcycles.

3. SETUP AND INSTALLATION

Proper installation is crucial for the performance and safety of your new windshield. It is recommended to have this product installed by a qualified technician if you are not familiar with motorcycle component installation.

3.1. Required Tools

- Appropriate wrenches or sockets for existing windshield fasteners.
- Screwdriver set (Phillips and/or flathead, as required).
- Clean, soft cloth.
- Protective gloves (optional).

3.2. Installation Steps

1. **Preparation:** Ensure the motorcycle is stable and turned off. Place a soft cloth over the front fairing to prevent scratches during installation.
2. **Remove Existing Windshield:** Carefully locate and remove the fasteners securing the original windshield. Keep all original hardware organized, as some components may be reused.
3. **Clean Mounting Area:** Thoroughly clean the area where the new windshield will be mounted to ensure a secure fit and prevent debris from scratching the new windshield.
4. **Position New Windshield:** Align the Puig 7070N WindShield with the mounting points on your motorcycle. Ensure all holes are properly aligned.
5. **Secure Windshield:** Using the provided hardware (if any) or the original fasteners, carefully attach the new windshield. Start all fasteners by hand to avoid cross-threading, then tighten them evenly and progressively. Do not overtighten, as this can crack the acrylic.
6. **Final Check:** Once secured, gently check the windshield for any looseness. Ensure it is firmly in place and does not obstruct any controls or visibility.

4. OPERATING CONSIDERATIONS

The Puig 7070N WindShield is designed to deflect wind and debris, improving rider comfort and safety. While installed, it requires no active operation. Its effectiveness is dependent on proper installation and maintaining its condition.

- **Wind Protection:** The V-Techline Touring design is optimized to reduce windblast on the rider, especially at higher speeds.
- **Visibility:** Ensure the windshield is always clean and free from obstructions to maintain clear visibility.

5. MAINTENANCE

Regular maintenance will prolong the life and clarity of your Puig windshield.

5.1. Cleaning

- Use only mild soap and water with a soft, non-abrasive cloth or sponge.
- Avoid harsh chemicals, ammonia-based cleaners, or abrasive materials, as these can scratch or damage the acrylic.
- Rinse thoroughly with clean water and dry with a soft, lint-free cloth to prevent water spots.

5.2. Inspection

- Periodically check all mounting fasteners to ensure they remain tight. Retighten if necessary, but do not overtighten.
- Inspect the windshield for any cracks, deep scratches, or signs of damage that could impair visibility or structural integrity. Replace if significant damage is present.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your windshield.

Problem	Possible Cause	Solution
Windshield feels loose or vibrates.	Loose mounting fasteners.	Check and gently tighten all mounting fasteners. Do not overtighten.
Reduced visibility.	Dirty surface or scratches.	Clean the windshield using recommended methods. If scratches are severe, consider replacement.
Excessive wind noise or buffeting.	Improper installation or specific rider/bike aerodynamics.	Verify installation is correct and secure. While the design is optimized, individual results may vary.

7. SPECIFICATIONS

Feature	Detail
Brand	Puig
Model	7070N
Color	Black
Material	High-Impact Acrylic (3mm thickness)
Style	V-Techline Touring
Auto Part Position	Front
Number of Pieces	1
Item Weight	8.8 ounces
Product Dimensions	14 x 10 x 6 inches
Compatibility	BMW C600S (2012-2013)

8. WARRANTY INFORMATION

Specific warranty details for the Puig 7070N WindShield are typically provided by the manufacturer or the authorized seller at the time of purchase. Please refer to your purchase documentation or contact the seller directly for comprehensive warranty terms and conditions.

9. CUSTOMER SUPPORT

For technical assistance, installation queries, or any other support related to your Puig 7070N WindShield, please contact the retailer from whom you purchased the product or visit the official Puig website for manufacturer support resources.
Note: Always ensure to use genuine Puig replacement parts if any components need to be replaced.

