

AFI AR8616111

Atlantic Furniture AFI Madison Twin XL Storage Platform Bed Instruction Manual

Model: AR8616111

1. PRODUCT OVERVIEW

The AFI Madison Twin XL Storage Platform Bed is designed for durability and functionality, featuring a solid hardwood construction and integrated underbed storage drawers. This platform bed eliminates the need for a box spring, providing direct support for your mattress with its slat kit. Its clean lines and espresso finish offer a versatile aesthetic suitable for various room decors.



Figure 1: Fully assembled AFI Madison Twin XL Storage Platform Bed.

2. SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Keep all hardware and small parts out of reach of children.
- Assemble the bed on a soft, clean surface to prevent scratching.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten hardware as needed.
- Do not exceed the maximum weight capacity of 800 pounds.
- This product contains wood and may be subject to Proposition 65 warnings.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Headboard
- Footboard
- Side Rails
- Slat Kit (Hardwood Slats and Support Rails)
- Underbed Storage Drawers (2 units for Twin XL)
- Hardware Pack (bolts, screws, washers, Allen wrench)

4. SETUP AND ASSEMBLY

Assembly typically requires two adults. Follow these steps for a fast and easy setup.

4.1 Pre-Assembly

- Unpack all components and lay them out on a clean, soft surface.
- Identify all parts and hardware using the provided parts list (if available).
- Ensure you have the necessary tools (typically an Allen wrench, which is usually included, and a Phillips head screwdriver).



Figure 2: Product dimensions for assembly reference.

4.2 Frame Assembly

1. Attach the side rails to the headboard and footboard using the provided bolts and washers. Do not fully tighten yet.
2. Ensure the bed frame is square and level, then fully tighten all bolts.



Figure 3: Bed frame components prior to slat installation.

4.3 Slat Kit Installation

1. Place the support rails (if separate) onto the ledges inside the side rails.
2. Evenly space the hardwood slats across the bed frame. Secure them to the side rails using the provided screws.
3. Ensure all slats are firmly attached to create a stable mattress foundation.



Figure 4: Bed frame with hardwood slats installed.

4.4 Drawer Assembly and Placement

1. Assemble the storage drawers according to their specific instructions, typically involving attaching the front, back, and side panels, and then the bottom panel.
2. Install any handles or pulls onto the drawer fronts.
3. Slide the assembled drawers into the designated spaces under the bed frame.

5. OPERATING INSTRUCTIONS

The underbed storage drawers are designed for easy access and organization.

- To open a drawer, gently pull the handle outwards.
- To close a drawer, push it inwards until it is flush with the bed frame.

- Avoid overloading the drawers to ensure smooth operation and prevent damage.



Figure 5: Underbed storage drawer in use.

6. MAINTENANCE

Proper care will extend the life and appearance of your bed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the espresso finish.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Hardware:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten as necessary to maintain stability.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Moisture:** Protect the bed from excessive moisture and humidity.

7. TROUBLESHOOTING

Refer to these common issues and solutions before contacting support.

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose hardware connections.	Check and tighten all bolts and screws on the frame. Ensure the bed is on a level surface.

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Overloaded drawer, debris in tracks, or misaligned.	Reduce drawer contents. Clean any debris from the drawer glides. Check if drawers are properly seated in their tracks.
Squeaking noises.	Loose connections, friction between wood parts or slats.	Tighten all hardware. If squeaking persists, apply a small amount of furniture wax or silicone spray to contact points between slats and side rails.

8. SPECIFICATIONS

Feature	Detail
Model Number	AR8616111
Size	Twin XL
Material	Solid Hardwood (Wood)
Color	Espresso
Style	Platform Bed with Storage
Item Dimensions (L x W x H)	83.63 x 43.63 x 44.25 inches
Item Weight	138 pounds
Maximum Weight Recommendation	800 pounds
Included Components	Headboard, Footboard, Side Rails, Slat Kit, 2 Storage Drawers
Manufacturer	Atlantic Furniture
UPC	782219179806

9. WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation included with your purchase or visit the Atlantic Furniture official website. If you require assistance with assembly, missing parts, or have any questions regarding your AFI Madison Twin XL Storage Platform Bed, please contact Atlantic Furniture customer support.

Manufacturer: Atlantic Furniture

Website: www.atlanticfurniture.com (Please check for current contact information)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question