

[Manuals.plus](#) /

› [WGGE](#) /

› WGGE WG-011 Multimeter Test Lead Kit with Soft Silicone Leads and Safety Alligator Clips - User Manual

WGGE WG-011

WGGE WG-011 Multimeter Test Lead Kit User Manual

Model: WG-011 | Brand: WGGE

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your WGGE WG-011 Multimeter Test Lead Kit. This kit is designed to connect a compatible electrical test meter to a device for testing, offering versatility and safety for various electrical measurements. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: WGGE WG-011 Multimeter Test Lead Kit components.

2. PRODUCT OVERVIEW

2.1 Components Included

- 2 x Soft Silicone Test Leads (Red and Black)
- 2 x Threaded Safety Alligator Clips (Red and Black)
- 2 x Threaded Alligator Clips (Red and Black)

2.2 Key Features

- **Soft Silicone Insulation:** Ensures durability, flexibility, and resistance to extreme temperatures (-68°F to heat).
- **Threaded Connections:** Provides secure attachment for alligator clips to the test probes.
- **High Safety Rating:** International Electrotechnical Commission (IEC) certified for CAT III 1000V and CAT IV 600V installations.

- **Versatile Attachments:** Includes both safety and standard threaded alligator clips for various testing needs.
- **Optimal Length:** Test lead wire is 40 inches, with a total test lead length of 47 inches, featuring shrouded 4mm banana plugs.

MEETS SAFETY STANDARDS

Meets International Electrotechnical Commission (IEC) Safety Standard 61010




Figure 2: Test leads and alligator clips highlighting safety standards.

3. SAFETY INFORMATION

Always prioritize safety when working with electrical equipment. Failure to follow these safety guidelines may result in injury or damage to equipment.

- **Voltage Ratings:** This kit is rated for CAT III 1000V and CAT IV 600V. Do not exceed these voltage limits.
- **Inspect Before Use:** Before each use, inspect the test leads and clips for any signs of damage, such as cracked insulation, exposed metal, or loose connections. Do not use damaged equipment.
- **Proper Connection:** Ensure all connections are secure and fully inserted into the multimeter and test points.
- **Use Appropriate PPE:** Always wear appropriate personal protective equipment (PPE), such as safety glasses and

insulated gloves, when performing electrical measurements.

- **Avoid Wet Conditions:** Do not use the test leads in wet or damp environments.
- **Disconnect Power:** Whenever possible, disconnect power to the circuit before making connections.

4. SETUP

Follow these steps to set up your WGGE WG-011 Test Lead Kit with a compatible multimeter.

4.1 Connecting Test Leads to a Multimeter

1. Identify the input jacks on your multimeter. Typically, the black lead connects to the 'COM' (common) jack, and the red lead connects to the 'VΩmA' (voltage, resistance, current) jack.
2. Insert the shrouded 4mm banana plugs of the black and red test leads firmly into the corresponding multimeter input jacks.

4.2 Attaching Alligator Clips

The WGGE WG-011 kit includes threaded alligator clips for secure attachment to the test probes.

1. Remove the protective cap from the tip of the test probe.
2. Align the threaded end of the desired alligator clip (safety or standard) with the threaded tip of the test probe.
3. Gently screw the alligator clip onto the test probe until it is securely fastened. Do not overtighten.
4. To remove, unscrew the alligator clip from the probe tip.




Figure 3: Illustration of threaded alligator clip attachment.

4.3 Setup Demonstration Video

Video 1: Demonstration of WGGE WG-011 test lead setup and use with a multimeter.

5. OPERATING INSTRUCTIONS

Once the test leads are connected to your multimeter and the appropriate accessories are attached, you can proceed with your measurements. Always refer to your multimeter's specific operating instructions for detailed measurement procedures.

5.1 General Measurement Tips

- **Select Correct Function:** Ensure your multimeter is set to the correct function (e.g., voltage, current, resistance, continuity) and range before making contact with the circuit.
- **Maintain Contact:** Ensure firm and stable contact between the test probes/clips and the circuit points being measured.

- **Readings:** Observe the readings on your multimeter display.

Professional tools for your DMM

Interchangeable Probe with multiple sharp tips to maximize contact with SMD test points.



Figure 4: WGGE WG-011 test probes compatible with various multimeters.

Alligator clips

Category III 1000V | 15A




Figure 5: Alligator clips in use for electrical measurement.

5.2 Product Usage Demonstration

Video 2: Overview of the WGGE WG-011 Test Lead Set and its application.

6. MAINTENANCE

Proper maintenance ensures the longevity and reliable performance of your test lead kit.

- **Cleaning:** Clean the test leads and clips with a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring the leads are completely dry before storage or next use.
- **Storage:** Store the test lead kit in a clean, dry place, away from direct sunlight and extreme temperatures. Avoid sharp objects that could damage the silicone insulation.
- **Regular Inspection:** Periodically inspect the leads and clips for any wear, cuts, or damage. Replace the kit if any damage is found to maintain safety and accuracy.

7. TROUBLESHOOTING

If you experience issues with your test lead kit, consider the following common troubleshooting steps:

- **Intermittent Readings:** If readings are inconsistent or intermittent, ensure all connections (multimeter jacks, probe tips, alligator clips) are clean and securely fastened. Dirt or loose connections can cause poor contact.
- **No Reading:** Verify that the multimeter is set to the correct function and range. Check the continuity of the leads by touching the probe tips together (or connecting alligator clips) to ensure a closed circuit.
- **Damaged Leads:** If the insulation is compromised or the metal tips are bent/broken, the leads must be replaced immediately for safety.

8. SPECIFICATIONS

Model Number	WG-011
Safety Rating	CAT III 1000V, CAT IV 600V
Lead Material	Soft Silicone Insulation
Lead Length	47 inches (total), 40 inches (wire)
Plug Type	Shrouded 4mm Banana Plugs
Safety Alligator Clip Jaw Opening	0.5 inches
Threaded Alligator Clip Jaw Opening	0.31 inches (7.9mm) Max
Threaded Alligator Clip Rating	10 Amps
Operating Temperature	Resistant to freezing (-68°F) and heat
Product Dimensions	7 x 3.5 x 0.6 inches
Item Weight	4.7 ounces

9. WARRANTY AND SUPPORT

The WGGE WG-011 Multimeter Test Lead Kit comes with a **24-month manufacturer warranty**. For any product inquiries, technical assistance, or warranty claims, please contact WGGE customer service. Our support team is available 24/7 to assist you.

Contact Information: Refer to the product packaging or the official WGGE website for the most up-to-date customer service contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question