

Puig 9719W

Puig 9719W Touring Windscreen Instruction Manual

Model: **9719W** | Brand: **Puig**

INTRODUCTION

Thank you for choosing the Puig 9719W Touring Windscreen. This manual provides essential information for the correct installation, safe operation, and proper maintenance of your new motorcycle accessory. Please read these instructions thoroughly before proceeding with installation or use to ensure optimal performance and rider safety.

PRODUCT FEATURES

- **High-Impact Acrylic Construction:** Manufactured from high-impact acrylic, typically 3 or 4 mm thick, ensuring durability and resistance.
- **Enhanced Protection and Comfort:** Designed with increased height compared to standard windscreens, significantly improving wind protection, rider safety, and overall comfort during rides.
- **TÜV Compliant Design:** Features a rounded contour of 2mm, adhering to strict German TÜV regulations for safety and quality.
- **Aerodynamic Design:** Each windscreen is developed with an aerodynamic study (model-dependent) to optimize airflow and reduce turbulence.
- **Model-Specific Compatibility:** Always verify compatibility with your specific motorcycle model to ensure a perfect fit and function.

SETUP AND INSTALLATION

The Puig 9719W Touring Windscreen is designed for straightforward installation. Detailed, model-specific mounting instructions are included with your product. Please follow these instructions carefully.

1. **Preparation:** Ensure your motorcycle is stable and turned off. Gather all necessary tools as indicated in the included mounting guide.
2. **Remove Existing Windscreen (if applicable):** Carefully detach your motorcycle's original windscreen, retaining any original hardware such as rubber washers, as these may be required for the new installation.
3. **Position the Puig Windscreen:** Align the Puig 9719W windscreen with the mounting points on your motorcycle.
4. **Secure the Windscreen:** Use the provided hardware and any necessary original components (e.g., rubber washers) to securely fasten the new windscreen. Do not overtighten screws.

5. **Final Check:** After installation, gently shake the windscreen to ensure it is firmly attached and does not wobble. Verify that all screws are tightened appropriately.



www.puighitechparts.com

Image: Puig Touring Windscreen mounted on a motorcycle, demonstrating its fit and appearance.



Image: Close-up view of the transparent Puig 9719W Touring Windscreen.

OPERATING THE WINDSCREEN

The Puig 9719W Touring Windscreen is designed to enhance your riding experience by redirecting airflow over and around the rider. This reduces wind buffeting, noise, and fatigue, especially during long journeys or at higher speeds. Its transparent finish ensures clear visibility.

- **Visibility:** The transparent material provides an unobstructed view of the road. Keep the windscreen clean for optimal visibility.
- **Aerodynamics:** The touring design is engineered to create a calmer air pocket for the rider, improving comfort.

Maintenance

Proper maintenance will prolong the life and clarity of your Puig Touring Windscreen.

- **Cleaning:** Use a soft cloth and mild soap with lukewarm water to clean the acrylic surface. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the material and cause hazing. Rinse thoroughly and dry with a clean, soft cloth.
- **Inspection:** Regularly inspect the windscreen for any cracks, scratches, or signs of wear. Check all mounting hardware for tightness and ensure no components are loose.
- **Storage:** When not in use for extended periods, store the motorcycle in a covered area to protect the windscreen from prolonged exposure to direct sunlight and extreme weather conditions.

Troubleshooting

If you encounter any issues with your Puig 9719W Touring Windscreen, consider the following:

- **Excessive Vibration:** Ensure all mounting screws are securely tightened. Loose hardware can cause vibrations.
- **Reduced Wind Protection:** Verify that the windscreen is installed correctly and is not obstructed. Ensure it is the correct model for your motorcycle.
- **Poor Visibility:** Clean the windscreen thoroughly using the recommended cleaning methods. If hazing or scratches persist, the windscreen may need replacement.

Specifications

Model Number	9719W
Brand	Puig
Material	High-Impact Acrylic
Color	Transparent
Style	Touring
Dimensions (L x W x H)	54.74 x 8.24 x 45.24 cm (21.55 x 3.24 x 17.81 inches)
Weight	680 g (1.5 lbs)
Number of Pieces	1
Compliance	TÜV certified (2mm rounded contour)
Vehicle Service Type	Motorcycle
Fit Type	Universal Fit (verify specific model compatibility)

Warranty and Support

Puig products are manufactured to high-quality standards. For any warranty claims, technical support, or inquiries regarding your Puig 9719W Touring Windscreen, please refer to the contact information provided with your purchase or visit the official Puig website. Keep your proof of purchase for warranty purposes. For further information, you may visit the official Puig website:www.puig.tv

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question