

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Barkbusters](#) /

› [Barkbusters B-025 Bar End Mounting Kit User Manual](#)

Barkbusters B-025

Barkbusters B-025 Bar End Mounting Kit User Manual

For 10mm ID Handlebars with Alloy Inserts

INTRODUCTION

This manual provides detailed instructions for the proper installation, use, and maintenance of your Barkbusters B-025 Bar End Mounting Kit. This kit is designed to securely mount accessories to handlebars with a 10mm internal diameter (ID) using alloy inserts. Please read this manual thoroughly before beginning installation to ensure correct assembly and safe operation.

For specific fitment information, this kit is compatible with Husqvarna models featuring tapered handlebars from 2008 onwards.

PACKAGE CONTENTS

Verify that all components listed below are present in your kit before proceeding with installation:

- 2 x Alloy Bar End Inserts (cylindrical, slotted)
- 2 x Threaded Inserts (for securing components)
- Required fasteners (not explicitly listed in product data, but implied for a kit)



Figure 1: Components of the Barkbusters B-025 Bar End Mounting Kit. The image displays two silver-colored, cylindrical alloy inserts with slotted ends, and two smaller, silver-colored threaded inserts designed to fit within them.

IMPORTANT SAFETY INFORMATION

Always prioritize safety during installation and use. Failure to follow these instructions may result in damage to the product, motorcycle, or personal injury.

- Ensure the motorcycle is stable and turned off before beginning any work.
- Wear appropriate personal protective equipment (PPE), such as gloves and eye protection.
- If you are unsure about any step, consult a qualified mechanic.
- Do not overtighten fasteners, as this can strip threads or damage components. Refer to torque specifications if available for your specific application.
- Regularly check the security of all mounted components, especially after the first ride and periodically thereafter.

INSTALLATION INSTRUCTIONS

Follow these steps carefully to install the Barkbusters B-025 Bar End Mounting Kit:

1. **Prepare Handlebars:** Ensure the internal diameter of your handlebars is 10mm. Remove any existing bar end weights or accessories from the handlebar ends. Clean the inside of the handlebar thoroughly to remove any debris or corrosion.
2. **Insert Alloy Sleeve:** Carefully slide one of the alloy bar end inserts (the cylindrical, slotted component) into the open end of the handlebar. The slotted end should face inwards, allowing for expansion.
3. **Position Threaded Insert:** Place one of the threaded inserts into the alloy sleeve. Ensure it aligns correctly with the internal threads of the sleeve.
4. **Secure Assembly:** Insert the appropriate bolt (not included in the provided product data, but necessary for assembly) through your desired accessory (e.g., handguard, mirror mount) and into the threaded insert.

5. **Tighten Bolt:** Gradually tighten the bolt. As the bolt is tightened, it will pull the threaded insert outwards, causing the slotted alloy sleeve to expand and grip the inside of the handlebar. Tighten until the assembly is firm and secure, but do not overtighten.
6. **Repeat for Other Side:** Repeat steps 2-5 for the other handlebar end.
7. **Final Check:** After installation, firmly check both bar end mounts to ensure they are securely fastened and do not rotate or move.

USAGE AND COMPATIBILITY

The Barkbusters B-025 Bar End Mounting Kit provides a stable and secure anchor point for various motorcycle accessories. Once installed, these inserts allow for the attachment of handguards, bar-end mirrors, or other compatible accessories that utilize a bar-end mounting system. This kit is specifically designed for handlebars with a 10mm internal diameter. Verify your handlebar's internal diameter before attempting to install this kit to ensure proper fitment and safety.

MAINTENANCE

Regular maintenance ensures the longevity and safety of your Barkbusters B-025 Bar End Mounting Kit:

- **Periodic Inspection:** Regularly inspect the bar end mounts for any signs of loosening, wear, or damage. This is especially important after off-road riding or long trips.
- **Tightness Check:** Re-tighten the mounting bolts if any movement or looseness is detected. Do not overtighten.
- **Cleaning:** Clean the components with a mild soap and water solution. Avoid harsh chemicals that may damage the finish or material.
- **Corrosion Prevention:** If riding in wet or corrosive environments, consider applying a light coat of anti-corrosion spray to exposed metal parts, avoiding areas that require friction for grip.

TROUBLESHOOTING

If you encounter issues during installation or use, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mount will not fit into handlebar.	Handlebar ID is not 10mm, or internal obstruction.	Verify handlebar internal diameter. Remove any internal obstructions. Do not force the insert.
Mount feels loose after tightening.	Insufficient tightening, or incorrect handlebar ID.	Ensure the bolt is tightened sufficiently to expand the alloy sleeve. Re-check handlebar ID. If still loose, the kit may not be compatible with your specific handlebar.

Problem	Possible Cause	Solution
Bolt does not engage threaded insert.	Misalignment of threaded insert or incorrect bolt.	Ensure the threaded insert is correctly seated within the alloy sleeve. Verify you are using the correct bolt for the threaded insert.

SPECIFICATIONS

Feature	Detail
Model Number	B-025
Brand	Barkbusters
Handlebar Internal Diameter (ID) Compatibility	10mm
Material	Alloy (inserts)
Approximate Item Weight (Kit)	2.2 pounds (1 kg)
Package Dimensions	17.72 x 15.75 x 15.75 inches (45 x 40 x 40 cm)
ASIN	B07CT37F86

WARRANTY AND SUPPORT

Specific warranty details for the Barkbusters B-025 Bar End Mounting Kit are not provided within the available product information. For warranty claims, technical support, or further assistance, please contact Barkbusters directly or refer to their official website.

Manufacturer: Bark Busters

For additional product information or support, please visit the [Barkbusters Brand Page on Amazon](#).

Related Documents - B-025

	<p>Barkbusters VPS Aluminium Backbone Fitting Instructions for Tapered Handlebars JET-002, BHG-152</p> <p>Detailed fitting instructions for Barkbusters VPS Aluminium Backbone handguards, designed for tapered handlebars. Includes preparation, installation steps, parts list, torque settings, and warnings for models like KTM 790 Adventure/R.</p>
--	--

<p>ANBAUANLEITUNG <small>How to fit the SW-MOTECH STREET-RACK luggage rack and URBAN ABS topcase to your motorcycle. Detailed instructions for the SW-MOTECH STREET-RACK luggage rack and URBAN ABS topcase.</small></p> <p>GP14.506.40000/B GP14.506.16000/B BC-MTA03-07/2000/B</p> <p></p>	<p>SW-MOTECH STREET-RACK Luggage Rack & URBAN ABS Topcase Mounting Instructions</p> <p>Detailed mounting instructions for the SW-MOTECH STREET-RACK Luggage Rack and URBAN ABS Topcase, covering installation, parts lists, torque specifications, and safety guidelines for motorcycle owners.</p>
<p>ANBAUANLEITUNG <small>How to fit the SW-MOTECH KOBRA handguard shells to your motorcycle. Detailed instructions for the SW-MOTECH KOBRA handguard shells.</small></p> <p>HPR.00.666.20400/BK HPR.01.02.0000/B HPR.01.22.2000/B</p> <p></p>	<p>SW-MOTECH KOBRA Handguard Shells Fitting Instructions for BMW G650X Challenge</p> <p>Detailed fitting instructions for SW-MOTECH KOBRA Handguard Shells (HPR.00.666.20400/BK) for BMW G650X Challenge, Moto & Country motorcycles, including preparation, parts list, and installation steps.</p>
<p>KLIPPFISK <small>Design Henrik Peutz</small></p> <p>306.025.04 406.025.08 506.025.17 706.025.02 906.025.01 906.025.15</p> <p></p>	<p>IKEA KLIPPFISK Cookware: Usage, Care, and Cleaning Guide</p> <p>Detailed instructions for IKEA's KLIPPFISK cookware, including before-first-use preparation, cleaning tips, wooden part care, and safe usage guidelines. Features sol-gel ceramic non-stick coating and suitability for induction hobs.</p>
<p></p>	<p>Barkbusters Handguard Fitting Instructions for Yamaha XTZ700 Tenere ('19 on)</p> <p>Detailed fitting instructions and parts list for installing Barkbusters handguards on a Yamaha XTZ700 Tenere (2019 onwards). Includes torque settings, warnings, and disclaimer.</p>
<p>ANBAUANLEITUNG <small>How to fit the SW-MOTECH STREET-RACK luggage rack and URBAN ABS topcase to your motorcycle. Detailed instructions for the SW-MOTECH STREET-RACK luggage rack and URBAN ABS topcase.</small></p> <p>GP14.851.40000/B GP14.851.16000/B BC-MTA03-07/2000/B</p> <p></p>	<p>SW-MOTECH STREET-RACK & URBAN ABS Topcase Mounting Instructions</p> <p>Comprehensive guide for installing the SW-MOTECH STREET-RACK luggage rack and URBAN ABS Topcase. Includes parts lists, step-by-step instructions, safety warnings, and care information.</p>



[R&G Application & Fitting Guide: Motorcycle Accessories](#)

Explore the R&G Application & Fitting Guide for a comprehensive catalog of motorcycle accessories, including paddock stands, tank pads, guards, and more. Find detailed product information and fitting guidance.

lang:en score:26 filesize: 1.3 M page_count: 232 document date: 2018-01-30



[\[pdf\] Catalog](#)

BARKBUSTERS 2021 ZESTAW DZWIGNI HAMULCA SPRZEGLA BRAKTEC HUSQVARNA GASGAS

Moto Master Barkbusters Catalogue v1 1 WEB drive google file d

1B8e02lmwkJL9J6corW2WCzQBrwjjQsQV view |||

ULTIMATE PROTECTION 2021 91 mm 127 mm SOMETIMES, SIZE MATTERS with Aerofoil fitted with Wind De ... D B-045-SL COLOUR Black Blue Gold Orange Red Silver ACCESSORIES SPARE PARTS Spare Parts CODE **B-025** B-026 B-027 B-029 B-051 B-054 B-055 B-056 B-060 B-062 B-064 B-065 B-070 B-071 B-074 B-076-BK B...

lang:en score:22 filesize: 10.35 M page_count: 38 document date: 2020-10-26

Barkbusters® Application Chart									
Barkbusters® Application Chart									
Model	Year	Handlebar	Front Fork	Front Wheel	Front Suspension	Front Tyre	Front Wheel	Front Fork	Handlebar
YAMAHA									
YZ 125	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 250	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 450	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 450F	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 450F	2005-2006	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 450F	2007-2008	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 450F	2009-2010	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 450F	2011-2012	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 450F	2013-2014	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 450F	2015-2016	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 450F	2017-2018	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 450F	2019-2020	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 450F	2021	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 250F	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 250F	2005-2006	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 250F	2007-2008	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 250F	2009-2010	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 250F	2011-2012	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 250F	2013-2014	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 250F	2015-2016	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 250F	2017-2018	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 250F	2019-2020	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 250F	2021	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 125F	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 125F	2005-2006	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 125F	2007-2008	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 125F	2009-2010	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 125F	2011-2012	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 125F	2013-2014	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 125F	2015-2016	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 125F	2017-2018	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 125F	2019-2020	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
YZ 125F	2021	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 125	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 125	2005-2006	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 125	2007-2008	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 125	2009-2010	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 125	2011-2012	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 125	2013-2014	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 125	2015-2016	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 125	2017-2018	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 125	2019-2020	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 125	2021	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250	2005-2006	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250	2007-2008	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250	2009-2010	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250	2011-2012	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250	2013-2014	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250	2015-2016	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250	2017-2018	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250	2019-2020	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250	2021	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450	2005-2006	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450	2007-2008	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450	2009-2010	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450	2011-2012	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450	2013-2014	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450	2015-2016	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450	2017-2018	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450	2019-2020	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450	2021	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450F	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450F	2005-2006	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450F	2007-2008	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450F	2009-2010	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450F	2011-2012	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450F	2013-2014	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450F	2015-2016	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450F	2017-2018	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450F	2019-2020	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 450F	2021	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 500	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 500	2005-2006	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 500	2007-2008	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 500	2009-2010	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 500	2011-2012	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 500	2013-2014	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 500	2015-2016	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 500	2017-2018	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 500	2019-2020	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 500	2021	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 400F	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 400F	2005-2006	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 400F	2007-2008	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 400F	2009-2010	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 400F	2011-2012	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 400F	2013-2014	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 400F	2015-2016	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 400F	2017-2018	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 400F	2019-2020	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 400F	2021	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250F	2002-2004	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250F	2005-2006	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250F	2007-2008	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250F	2009-2010	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250F	2011-2012	41.0	41.0	17.0	41.0	41.0	17.0	41.0	41.0
WR 250F	2013-2014								