

## Canal Toys 222001

# Canal Toys So Bomb DIY Bath Bomb Factory Instruction Manual

Model: 222001

## INTRODUCTION

Welcome to the Canal Toys So Bomb DIY Bath Bomb Factory! This kit allows you to create your own scented bath bombs with surprise figures inside. Please read these instructions carefully before beginning to ensure a safe and enjoyable experience.

## SAFETY INFORMATION

- **WARNING: CHOKING HAZARD** - Small parts. Not for children under 3 years.
- This set contains chemicals that may be harmful if misused. Read cautions on individual containers carefully.
- Not to be used by children except under adult supervision.
- Avoid contact with eyes. In case of contact, rinse thoroughly with water.
- Do not ingest any components.

## WHAT'S INCLUDED

Your Canal Toys So Bomb DIY Bath Bomb Factory includes the following components:

- 1 Mix 'N Mold Workstation
- 1 Round Bath Bomb Mold
- 6 Bags of Scented Baking Soda Powder
- 6 Bags of Citric Acid Powder
- 2 Styles of Decorative Sprinkles
- 4 Surprise Figures
- 1 Spoon

- 1 Pipette
- 1 Sticker Sheet
- Instruction Sheet



Image: All components of the So Bomb DIY Bath Bomb Factory, including the workstation, powders, molds, sprinkles, and surprise figures.

## SETUP

Before you begin making bath bombs, ensure your workstation is assembled and ready.

1. Unpack all components from the box.
2. Assemble the Mix 'N Mold Workstation according to the diagrams on the packaging or included instruction sheet. Ensure all parts are securely connected.
3. Place the workstation on a clean, flat, and stable surface.



Image: The fully assembled So Bomb DIY Bath Bomb Factory workstation, ready for use, with examples of finished bath bombs.

## OPERATING INSTRUCTIONS: MAKING BATH BOMBS

Follow these steps to create your custom bath bombs:

### 1. Step 1: Prepare the Mixture

Open one bag of scented baking soda powder and one bag of citric acid powder. Pour both into the mixing bowl of the workstation. Use the pipette to add a small amount of water, drop by drop, while mixing with the spoon or the workstation's mixer. The mixture should be damp enough to hold its shape when squeezed, but not too wet or fizzy. Mix thoroughly until a consistent texture is achieved.



Image: A hand pouring pink powder from a packet into the mixing bowl of the bath bomb workstation.

## 2. Step 2: Add Surprises and Decorations

Open the round bath bomb mold. Place a surprise figure into one half of the mold. Add decorative sprinkles into the mold as desired. You can also mix sprinkles directly into your powder mixture before molding.



Image: A hand adding colorful sprinkles and a small plastic figure into one half of a bath bomb mold.

### 3. Step 3: Mold the Bath Bomb

Firmly pack the prepared mixture into both halves of the round bath bomb mold, ensuring it is slightly overflowing. Press the two halves of the mold together very firmly. Hold for a few seconds to allow the mixture to compact. Carefully open the mold and gently remove your newly formed bath bomb.



Image: A hand firmly pressing the two halves of a bath bomb mold together to shape the mixture.

**4. Step 4: Drying**

Place the molded bath bomb in a safe, dry place to harden. Allow it to dry completely for at least 30 minutes, or longer if necessary, to ensure it maintains its shape.

**5. Step 5: Usage**

Once dry, your bath bomb is ready for use. Gently place it into a tub of warm water and watch it fizz, releasing its scent and revealing the surprise figure.



Image: A colorful bath bomb fizzing and dissolving in blue bath water, creating bubbles and releasing its contents.

### [Watch the Bath Bomb Creation Process](#)

Your browser does not support the video tag.

Video: An official product video demonstrating the steps to create bath bombs using the So Bomb DIY Bath Bomb Factory, including mixing powders, adding surprises, and the fizzing action in water.

### TIPS FOR BEST RESULTS

- **Thorough Mixing:** Ensure the powders and water are mixed completely and evenly. Skipping the water step or insufficient mixing can result in bath bombs that do not hold their shape well.
- **Moisture Control:** The mixture should be just damp enough to clump together when squeezed. Too much water will cause premature fizzing; too little will prevent it from binding.
- **Firm Packing:** Press the mixture into the molds very firmly to create dense, durable bath bombs.
- **Drying Time:** Allow ample drying time. If bath bombs are removed from the mold too soon or are not fully dry, they may crumble.
- **Color Mixing:** If attempting to create multi-colored bath bombs, prepare each color mixture separately and then layer them carefully in the mold. Mixing different colors directly in the workstation's mixer will blend them into a new single color.

### MAINTENANCE

Proper care will extend the life of your Bath Bomb Factory.

- **Cleaning the Workstation:** After each use, disassemble the mixing bowl and mold components. Wash them with warm, soapy water. Rinse thoroughly and allow to air dry completely before storing.
- **Storage:** Store all components in a clean, dry place away from direct sunlight and moisture. Keep powders sealed in their original packaging or airtight containers to prevent clumping.

## TROUBLESHOOTING

**Problem: Mixer bowl is difficult to open or separate.**

**Solution:** Fine grains of the bath bomb mixture can get into the grooves, making it difficult to open. Ensure the mixer is thoroughly cleaned after each use to prevent residue buildup. If stuck, adult assistance may be required to gently twist and separate the parts.

**Problem: Bath bombs are crumbling or not holding shape.**

**Solution:** This usually indicates insufficient moisture or inadequate compaction. Ensure you add enough water (drop by drop) until the mixture holds together when squeezed. Also, press the mixture very firmly into the mold. Allow sufficient drying time (at least 30 minutes) before handling.

**Problem: Bath bombs are not fizzing.**

**Solution:** Ensure the powders were mixed correctly and not exposed to too much moisture during preparation, which can activate the fizzing prematurely. Also, verify that the bath bomb is fully dry before use.

## SPECIFICATIONS

<b>Brand</b>	Canal Toys
<b>Model Name</b>	So Bomb DIY - Bath Bomb Factory
<b>Item Model Number</b>	222001
<b>UPC</b>	851786007765
<b>Recommended Age</b>	6 - 12 years
<b>Item Dimensions (L x W x H)</b>	13.5 x 3.15 x 12.25 inches
<b>Item Weight</b>	1.98 pounds (0.9 Kilograms)
<b>Material</b>	Plastic

## WARRANTY AND SUPPORT

Specific warranty information for the Canal Toys So Bomb DIY Bath Bomb Factory is not provided in this manual. For warranty details, product support, or to inquire about replacement parts, please contact Canal Toys customer service directly or visit their official website. Keep your purchase receipt as proof of purchase.