

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Rivet](#) /
- › [Rivet Modern Wood Kitchen Counter Barstool \(Model A-0021\) Instruction Manual](#)

Rivet A-0021

Rivet Modern Wood Kitchen Counter Barstool (Model A-0021) Instruction Manual

1. PRODUCT OVERVIEW

The Rivet Modern Wood Kitchen Counter Barstool, Model A-0021, is designed for kitchen counter and home bar use. It features a sturdy solid birch wood construction with a natural finish and a contoured seat for comfortable seating. This barstool offers a minimalist profile without a backrest.



Image 1.1: Two Rivet Modern Wood Kitchen Counter Barstools positioned at a counter.

2. IMPORTANT SAFETY INFORMATION

- **Maximum Weight Recommendation:** Do not exceed the maximum weight recommendation of 330 pounds (150 kg) to prevent damage to the barstool or personal injury.
- **Moisture Exposure:** Avoid exposing the barstool to excessive moisture. Prolonged contact with liquids can damage the wood finish and compromise structural integrity.
- **Stability:** Ensure all screws are tightened securely after assembly and periodically check for any loosening. A wobbly stool can be a safety hazard.
- **Placement:** Place the barstool on a flat, stable surface to prevent tipping.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- 1x Contoured Seat
- 4x Legs

- 4x Footrest Bars
- Hardware Pack (screws, washers, Allen wrench)

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes 15 minutes or less. A Phillips head screwdriver (not included) may be helpful in addition to the provided Allen wrench.





Image 4.1: Front view of the barstool, showing the seat, legs, and footrests.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Legs to Seat:** Identify the four legs. Align each leg with the pre-drilled holes on the underside of the contoured seat. Secure them using the provided screws and washers. Do not fully tighten the screws at this stage.
3. **Install Footrest Bars:** Insert the four footrest bars between the legs. Ensure the holes on the footrest bars align with the holes on the legs. Secure them with the remaining screws and washers. Again, do not fully tighten yet.
4. **Tighten All Screws:** Once all components are loosely assembled, place the barstool upright on a flat surface. Apply gentle downward pressure to ensure all parts are seated correctly. Then, systematically tighten all screws using the Allen wrench until secure. Avoid overtightening to prevent stripping the wood.
5. **Check Stability:** Gently rock the barstool to check for any wobbling. If unstable, loosen the screws slightly, adjust the legs, and retighten.



Image 4.2: Detail of the barstool's leg and footrest construction.

5. USAGE GUIDELINES

The Rivet Modern Wood Kitchen Counter Barstool is designed for seating at kitchen counters, home bars, or similar elevated surfaces. Ensure the barstool is placed on a stable, level floor before use. Sit centrally on the contoured seat for optimal balance and comfort. Avoid standing on the barstool or using it as a step stool.

6. CARE AND MAINTENANCE

- **Cleaning:** Wipe away dust and debris with a soft, dry cloth. For spills, immediately blot with a clean, dry cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the natural wood finish.
- **Moisture Protection:** Protect the barstool from direct exposure to water or high humidity. Use coasters if placing drinks directly on the seat.
- **Sunlight Exposure:** Prolonged exposure to direct sunlight can cause the wood to fade or change color. Position the barstool away from direct sunlight when possible.
- **Periodic Inspection:** Periodically check all screws and connections to ensure they remain tight.

Retighten as necessary to maintain stability and safety.



Image 6.1: Detail of the natural birch wood grain, highlighting the finish.

7. TROUBLESHOOTING

- **Wobbling:** If the barstool wobbles after assembly, loosen all screws slightly, press down firmly on the seat to ensure all legs are evenly touching the floor, then retighten all screws. Ensure the floor surface is level.
- **Loose Screws:** Periodically check and tighten all assembly screws to maintain the barstool's structural integrity and prevent wobbling.
- **Scratches/Dents:** Minor scratches can sometimes be buffed out with a wood repair kit or furniture polish designed for natural wood finishes. For deeper damage, professional repair may be required.

8. PRODUCT SPECIFICATIONS

Model Number	A-0021
--------------	--------

Product Dimensions	14.4"D x 17.3"W x 29.5"H (36.6 cm D x 43.9 cm W x 74.9 cm H)
Seat Height	29.5 Inches (74.9 cm)
Color	Natural
Style	Modern
Frame Material	Solid Birch Wood
Seat Material Type	Wood
Item Weight	9.5 pounds (4.3 kg)
Maximum Weight Recommendation	330 Pounds (150 kg)
Assembly Required	Yes
Manufacturer	Tancheng Meitai Home Products Co., Ltd

9. WARRANTY AND CUSTOMER SUPPORT

This Rivet barstool comes with a **1-year warranty** from the date of purchase, covering manufacturing defects. Additionally, free returns are available for 30 days from the purchase date, subject to the retailer's return policy.

For warranty claims, missing parts, or any other product-related inquiries, please contact the retailer or manufacturer directly. Keep your proof of purchase for warranty validation.

Contact Information: Refer to your purchase receipt or the retailer's website for specific customer support contact details.