

[Manuals.plus](#) /

› [Kuryakyn](#) /

› Kuryakyn Splined Driver Peg Adapter (Model 8946) Instruction Manual

Kuryakyn 8946

Kuryakyn Splined Driver Peg Adapter (Model 8946) Instruction Manual

For '18-'19 Harley-Davidson Softail Models

1. PRODUCT OVERVIEW

The Kuryakyn 8946 splined peg adapters are designed to facilitate the customization of your motorcycle. These adapters are required to mount select Kuryakyn footpegs that are sold without pre-attached adapters. When used with compatible footpegs, they enhance the comfort and style of your ride. This package includes two gloss black splined adapters intended for front applications.



Image showing the Kuryakyn Splined Driver Peg Adapter in gloss black finish. This adapter is used to mount select Kuryakyn footpegs to Harley-Davidson motorcycles.

2. COMPATIBILITY

The Kuryakyn 8946 splined peg adapters are specifically compatible with **driver pegs** on Harley-Davidson Softail models manufactured between **2018 and 2019**. Please verify your motorcycle's model year to ensure proper fitment.

3. WHAT'S INCLUDED

The package contains the following components:

- **(2) Gloss Black Splined Adapters** for front applications.

Note: Snap ring pliers are suggested for installation but are not included with this product.

4. INSTALLATION INSTRUCTIONS

Follow these steps for proper installation of the Kuryakyn Splined Driver Peg Adapters:

1. **Prepare Your Motorcycle:** Ensure your motorcycle is stable and turned off. Allow any hot components to cool down before beginning installation.
2. **Remove Existing Pegs (if applicable):** If you are replacing existing footpegs, carefully remove them from the driver peg mounts. This typically involves removing a retaining pin or snap ring.
3. **Install Splined Adapter:** Position the Kuryakyn splined adapter onto the driver peg mount. Ensure the splines align correctly.
4. **Secure Adapter:** Use a snap ring (not included, typically reused from existing setup or purchased separately) and snap ring pliers to securely fasten the adapter to the mount. Ensure the snap ring is fully seated in its groove.
5. **Mount Footpeg:** Once the adapter is securely in place, you can now mount your desired Kuryakyn footpeg onto the splined adapter. Follow the footpeg's specific instructions for attachment.
6. **Verify Security:** After installation, gently test the adapter and footpeg to ensure they are firmly attached and do not wobble.

Safety Precaution: Always wear appropriate safety gear and consult a professional mechanic if you are unsure about any installation steps.

5. USAGE

Once installed, the Kuryakyn Splined Driver Peg Adapters provide a secure and customizable mounting point for compatible Kuryakyn footpegs. These adapters allow you to achieve the desired comfort and ergonomic positioning for your feet during motorcycle operation. Ensure that any footpegs mounted to these adapters are also securely fastened and regularly checked for tightness.

6. MAINTENANCE

To ensure the longevity and proper function of your Kuryakyn Splined Driver Peg Adapters, consider the following maintenance tips:

- **Regular Inspection:** Periodically check the adapters and mounted footpegs for any signs of wear, damage, or looseness.
- **Cleaning:** Clean the adapters with a mild soap and water solution, then dry thoroughly. Avoid harsh chemicals or abrasive cleaners that could damage the gloss black finish.
- **Fastener Check:** Ensure all retaining pins or snap rings remain securely in place. Re-tighten or replace as necessary.

7. TROUBLESHOOTING

If you encounter issues during installation or use, consider the following:

- **Fitment Issues:** Double-check that your motorcycle is a compatible '18-'19 Harley-Davidson Softail model. While the product description specifies these models, some users have reported successful fitment on other models like the 2022 Harley Fat Bob. However, always prioritize the manufacturer's stated compatibility.
- **Loose Adapter:** Ensure the snap ring or retaining pin is fully seated and secure. A loose adapter can be a safety hazard.
- **Difficulty Mounting Footpeg:** Verify that the footpeg you are attempting to mount is compatible with splined adapters and that the splines are aligned correctly.

8. SPECIFICATIONS

Attribute	Detail
Brand	Kuryakyn
Model Number	8946
Color	Gloss Black
Material	Steel Investment Cast
Vehicle Service Type	Motorcycle
Fit Type	Specific
Orientation	Front
Item Weight	0.19 Pounds
UPC	191209036386

9. WARRANTY INFORMATION

This Kuryakyn product is covered by a **1-year manufacturer warranty**. For specific details regarding warranty claims or coverage, please refer to the official Kuryakyn warranty policy or contact Kuryakyn customer support directly.

10. SUPPORT

For further assistance, technical support, or inquiries not covered in this manual, please visit the official Kuryakyn website or contact their customer service department. Always refer to official Kuryakyn resources for the most accurate and up-to-date information.

You can often find additional support and installation videos on the manufacturer's website or through authorized dealers.

© Kuryakyn. All rights reserved.