

[Manuals.plus](#) /

› [Modway](#) /

› Modway Amira Full Upholstered Bed Frame Instruction Manual

Modway MOD-6000-WHI

Modway Amira Full Upholstered Bed Frame

Model: MOD-6000-WHI

IMPORTANT SAFETY INFORMATION

WARNING: Do not load more than 800 pounds on this bed frame. Ensure proper assembly to prevent instability and potential injury. Always follow all assembly instructions carefully. Keep small parts away from children during assembly.

PRODUCT OVERVIEW

The Modway Amira Full Upholstered Bed Frame features a soft polyester fabric upholstered base and a button-tufted headboard. It includes a durable wood bed frame and legs with non-marking foot caps. A reinforced center beam provides enhanced stability. This bed frame is designed to accommodate memory foam, spring, latex, and hybrid mattresses. A box spring is required for proper mattress support (not included).

Dimensions: 80.5"L x 58"W x 45.5"H

Weight Capacity: 800 lbs



Image: Modway Amira Full Upholstered Bed Frame in White, fully assembled without bedding.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Headboard (1)
- Upholstered Side Rails (2)
- Upholstered Footboard (1)
- Wood Slats (Set)
- Center Support Beam (1)
- Support Legs (for center beam and frame)
- Hardware Pack (Bolts, Washers, Nuts, Allen Wrench)

SETUP AND ASSEMBLY INSTRUCTIONS

For detailed, step-by-step assembly instructions with diagrams, please refer to the official Installation Manual (PDF) available at: [Installation Manual \(PDF\)](#)

General Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.

2. Identify all parts and hardware using the parts list in the PDF manual.
3. Attach the upholstered side rails to the headboard and footboard using the provided hardware. Ensure all connections are secure but do not overtighten until all parts are aligned.
4. Install the center support beam and its adjustable support legs. Ensure the legs are adjusted to make firm contact with the floor.
5. Place the wood slats across the side rails, securing them if necessary with the provided fasteners. Ensure slats are evenly spaced.
6. Tighten all hardware connections securely.



Image: Diagram showing the dimensions of the Modway Amira Full Bed Frame: 80.5" L, 58" W, 45.5" H.



Image: The Modway Amira Full Bed Frame without a mattress, illustrating the internal slat support system and center beam.

Assembly Video Guide

Video: Official Modway video demonstrating the features and assembly of the Amira Full Upholstered Fabric Bed in White. This video highlights the reinforced center beam for stability and its compatibility with various mattress types.

OPERATING INSTRUCTIONS

Ensure the bed frame is placed on a level surface to prevent wobbling and uneven stress on the frame. A box spring is required for proper mattress support and to maintain the bed's structural integrity and warranty. Distribute weight evenly across the bed surface. Avoid standing or jumping on the bed frame, as this can cause damage to the frame or slats and may void the warranty.

MAINTENANCE

Regularly check all bolts and connections to ensure they remain tight. Loose connections can lead to instability and noise. Clean the upholstered fabric with a soft, damp cloth and mild soap, if necessary. Test any cleaning solution on an inconspicuous area first. Avoid harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the fabric and finish.

TROUBLESHOOTING

- Squeaking Noises:** Check all hardware connections and tighten any loose bolts. Ensure the slats are properly seated and not rubbing against the frame. Verify the box spring is correctly positioned and not causing friction.
- Instability/Wobbling:** Confirm all components are correctly assembled according to the manual. Ensure all support legs, especially the center beam legs, are making firm contact with the floor and are adjusted to the correct height.
- Mattress Sagging:** Verify that a box spring is being used as required by the product specifications. Inspect slats for damage or displacement. Ensure the mattress itself is not worn out or defective.

SPECIFICATIONS

Size	Full
Material	Polyester, Wood
Product Dimensions (L x W x H)	80.5" x 58" x 45.5"
Item Weight	50 Pounds
Maximum Weight Recommendation	800 Pounds
Included Components	Headboard, Slats
Model Number	MOD-6000-WHI
UPC	889654132325
Assembly Required	Yes

WARRANTY INFORMATION

This Modway Amira Full Upholstered Bed Frame comes with a one-year warranty against manufacturer defects. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the documentation included with your product or contact Modway customer support.

CUSTOMER SUPPORT

For further assistance, troubleshooting, or to inquire about replacement parts, please visit the official Modway Store on Amazon or contact Modway customer service directly.

Modway Store on Amazon: [Visit the Modway Store](#)