

[Manuals.plus](#) /

> [Modway](#) /

> Modway Amira Full Bed Frame - Azure (Model MOD-6000-AZU) Instruction Manual

Modway MOD-6000-AZU

Modway Amira Full Bed Frame - Azure

MODEL: MOD-6000-AZU

Instruction Manual

Introduction

Thank you for choosing the Modway Amira Full Bed Frame. This manual provides essential information for the safe assembly, proper use, and maintenance of your new bed frame. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Modway Amira Full Bed Frame features a soft polyester fabric upholstered base and a button-tufted headboard, designed for contemporary style and comfort. It is constructed with a wood frame and legs, including non-marking foot caps, and a reinforced center beam for stability. This bed frame is compatible with memory foam, spring, latex, and hybrid mattresses. A box spring is required for proper mattress support (not included).



Image: Modway Amira Full Bed Frame in Azure, fully assembled with bedding.

Safety Information

- **Read all instructions:** Ensure you understand all assembly steps and safety warnings before proceeding.
- **Adult Assembly Required:** This product requires adult assembly. Keep small parts and packaging materials away from children.
- **Weight Capacity:** The bed frame has a maximum weight capacity of 800 lbs (363 kg). Do not exceed this limit.
- **Use a Box Spring:** A box spring is required to provide adequate support for your mattress and ensure the longevity of the bed frame. Failure to use a box spring may void the warranty and compromise structural integrity.
- **Check Connections:** Periodically inspect all bolts and screws to ensure they are tight. Retighten as necessary.
- **Avoid Standing on Frame:** Do not stand or jump on the bed frame.
- **Placement:** Place the bed frame on a level surface.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Parts List

Before assembly, verify that all components listed below are present. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- Headboard (1)
- Footboard (1)
- Side Rails (2)

- Center Support Beam (1)
- Wooden Slats (Quantity may vary, typically 4-6)
- Support Legs for Slats (Quantity may vary)
- Hardware Pack (Bolts, Washers, Allen Wrench, etc.)
- Non-Marking Foot Caps (Pre-attached or separate)



Image: Key components of the Modway Amira Bed Frame, including upholstered fabric, wood frame, slats, and legs.

Assembly Instructions

Estimated Assembly Time: 60 minutes. Two people recommended for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface (like a rug or blanket) to prevent scratches.
2. **Attach Side Rails to Headboard:** Align the side rails with the pre-drilled holes on the headboard. Secure them using the provided bolts and washers. Do not fully tighten bolts until all major components are connected.
3. **Attach Side Rails to Footboard:** Connect the other end of the side rails to the footboard in the same manner. Ensure the bed frame is square and level before tightening all bolts.

4. **Install Center Support Beam:** Position the center support beam along the length of the bed frame, connecting it to the headboard and footboard brackets. Secure with bolts. Attach any support legs to the center beam if provided.
5. **Place Wooden Slats:** Lay the wooden slats across the side rails, distributing them evenly. Secure each slat to the side rails using the provided screws or fasteners. Ensure all slats are firmly attached to prevent movement and provide stable support.
6. **Final Tightening:** Once all components are in place and aligned, fully tighten all bolts and screws using the Allen wrench. Do not overtighten.
7. **Inspect:** Double-check all connections to ensure the bed frame is stable and secure before placing a mattress and box spring.



Image: Assembled Modway Amira Bed Frame without mattress, illustrating the slat support system.

Operating Instructions

Once assembled, your Modway Amira Full Bed Frame is ready for use.

- **Box Spring Placement:** Place your full-size box spring directly onto the wooden slats. Ensure it sits securely within the frame.
- **Mattress Placement:** Place your full-size mattress on top of the box spring.
- **Weight Distribution:** Distribute weight evenly across the bed. Avoid concentrating heavy loads on small areas.
- **Movement:** When moving the bed, lift it rather than dragging it to prevent damage to the frame and floor.



Image: Side view of the Modway Amira Bed Frame with mattress and box spring.

Care and Maintenance

- **Cleaning Fabric:** For general cleaning, vacuum the upholstered fabric regularly using an upholstery attachment. For spills, blot immediately with a clean, dry cloth. For stubborn stains, consult a professional upholstery cleaner or use a fabric-specific cleaning solution, testing on an inconspicuous area first.
- **Cleaning Wood:** Wipe wood surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically check all bolts and screws (every 3-6 months) and tighten them as needed to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading.
- **Avoid Moisture:** Keep the bed frame away from excessive moisture or humidity.

Troubleshooting

- **Bed feels unstable or wobbly:**
 - Ensure all bolts and screws are fully tightened.
 - Verify that the bed frame is placed on a level surface.
 - Check that the center support beam and its legs are properly installed and making contact with the floor.
- **Mattress is sinking or not adequately supported:**
 - Confirm that a box spring is being used. This bed frame requires a box spring for proper mattress support.
 - Ensure all wooden slats are securely fastened to the side rails and are evenly distributed.
 - Check the condition of the slats for any damage or breakage. Replace if necessary.
- **Squeaking noises:**
 - Tighten all hardware connections.

- Ensure the box spring and mattress are properly seated and not rubbing against the frame.

Product Specifications

Model Number	MOD-6000-AZU
Brand	Modway
Size	Full
Color	Azure
Product Dimensions (L x W x H)	80.5" x 58" x 45.5"
Item Weight	50 Pounds
Material	Wood, Polyester Fabric
Weight Capacity	800 lbs
Assembly Required	Yes
Box Spring Required	Yes



Image: Dimensional diagram of the Modway Amira Full Bed Frame.

Warranty Information

This Modway product is covered by a **one-year warranty against manufacturer defects** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper assembly, misuse, abuse, accidents, modifications, or normal wear and tear. Proof of purchase is required for all warranty claims.

Customer Support

If you have any questions, require assistance with assembly, or need to report missing or damaged parts, please contact Modway customer service. Have your model number (MOD-6000-AZU) and proof of purchase ready when contacting support.

For further assistance, please visit the official Modway website or refer to your purchase documentation for contact details.