

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Puig](#) /

› [Puig 9841N Windshield V-Tech Line Supersport Black User Manual](#)

Puig 9841N

Puig 9841N Windshield V-Tech Line Supersport Black User Manual

Model: **9841N** | Brand: **Puig**

INTRODUCTION

This user manual provides essential information for the installation, operation, and maintenance of your Puig 9841N V-Tech Line Supersport Black Windshield. Designed to enhance the sporty aesthetic and aerodynamic performance of your maxiscooter, this windshield offers improved protection at higher speeds. Please read this manual thoroughly before installation and use to ensure proper fitment and safe operation.

PRODUCT OVERVIEW

The Puig V-Tech Line Supersport windshield is engineered with a focus on both aesthetics and performance. Its distinctive angular design, developed through extensive aerodynamic studies, effectively channels airflow to reduce turbulence around the rider.

Key Features:

- Enhances the sporty image of your maxiscooter.
- Improves protection at high speeds.
- Aerodynamically optimized design with angular shapes.
- Channels air to reduce rider turbulence.

Compatibility:

This windshield is compatible with the following Yamaha T-MAX models:

- Yamaha T-MAX 530 (2017, 2018, 2019)
- Yamaha T-MAX 530 DX (2017, 2018, 2019)
- Yamaha T-MAX 530 SX (2017, 2018, 2019)
- Yamaha T-MAX 560 (2020, 2021)
- Yamaha T-MAX 560 DX (2020, 2021)
- Yamaha T-MAX 560 MAX TECH (2020, 2021)

- Yamaha T-MAX 560 SX (2020, 2021)



Image: The Puig 9841N Windshield mounted on a blue Yamaha T-MAX scooter, showcasing its design and fit.



Image: The Puig 9841N Windshield mounted on a grey Yamaha T-MAX scooter, highlighting its integration with the vehicle's aesthetics.

SAFETY INFORMATION

Always prioritize safety when installing and using motorcycle accessories. Failure to follow these guidelines may result in injury or damage to your vehicle.

- **Professional Installation Recommended:** If you are unsure about any step, seek assistance from a qualified motorcycle mechanic.
- **Read Instructions:** Fully understand all installation steps before beginning.
- **Use Correct Tools:** Ensure you have the appropriate tools for installation to prevent damage to fasteners or the windshield.
- **Secure Fasteners:** All bolts and screws must be tightened to the manufacturer's specifications. Periodically check for tightness.
- **Visibility:** Ensure the installed windshield does not obstruct your field of vision or interfere with the operation of controls.
- **Cleaning:** Use only recommended cleaning agents and methods to avoid damaging the windshield material.
- **Inspect Regularly:** Before each ride, inspect the windshield for cracks, loose fittings, or any damage that could compromise safety.

SETUP AND INSTALLATION

The Puig 9841N Windshield is designed for direct replacement or specific mounting on compatible Yamaha T-MAX models. While specific instructions may vary slightly by model year, the general procedure involves removing the original windshield (if applicable) and securing the new Puig windshield using the provided hardware or existing mounting points.

Tools Required (Typical):

- Hex key set (Allen wrenches)
- Screwdriver set (Phillips and/or flathead, depending on existing fasteners)
- Torque wrench (recommended for precise tightening)
- Soft cloth to protect painted surfaces

Installation Steps (General Guide):

1. **Prepare the Motorcycle:** Park the motorcycle on a stable, level surface. Turn off the engine and remove the key.
2. **Remove Existing Windshield (if applicable):** Carefully locate and remove all fasteners securing the original windshield. Store these fasteners safely if they are to be reused, or discard if new hardware is provided.
3. **Clean Mounting Area:** Ensure the mounting surfaces on the motorcycle are clean and free of debris.
4. **Position the New Windshield:** Carefully align the Puig 9841N Windshield with the mounting points on your Yamaha T-MAX.
5. **Install Fasteners:** Begin by loosely installing all fasteners (bolts, screws, washers, nuts) that secure the windshield. Do not fully tighten any fastener until all are in place.
6. **Align and Adjust:** Once all fasteners are loosely installed, gently adjust the windshield to ensure proper alignment and fit.
7. **Tighten Fasteners:** Systematically tighten all fasteners. It is recommended to tighten them in a cross-pattern if multiple fasteners are present, ensuring even pressure. Refer to your motorcycle's service manual for specific torque specifications if available, or tighten securely without overtightening.
8. **Final Inspection:** Double-check all fasteners for tightness. Ensure the windshield is securely mounted and does not wobble. Verify that the windshield does not interfere with steering, controls, or any other motorcycle

components.

Note: For detailed, model-specific installation instructions, please refer to the documentation provided directly by Puig or consult a professional mechanic.

OPERATING CONSIDERATIONS

Once installed, the Puig 9841N Windshield operates passively by deflecting airflow. Consider the following for optimal performance and safety:

- **Aerodynamic Benefits:** The V-Tech design is intended to reduce wind turbulence and improve rider comfort, especially at higher speeds.
- **Visibility:** Always ensure your line of sight is clear through or over the windshield. Keep the windshield clean to maintain optimal visibility.
- **Wind Conditions:** Be aware that strong crosswinds can affect motorcycle stability, and a larger windshield may slightly alter the motorcycle's handling characteristics in such conditions.
- **Impact Resistance:** While designed to be durable, the windshield is not indestructible. Avoid impacts with hard objects.

MAINTENANCE AND CARE

Proper care will extend the life and maintain the clarity of your Puig windshield.

Cleaning:

- **Gentle Cleaning:** Use only mild soap (e.g., dish soap) and lukewarm water with a soft, clean microfiber cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, ammonia-based products (like window cleaner), or solvents (e.g., gasoline, paint thinner) as these can damage the windshield material.
- **Rinse Thoroughly:** Rinse the windshield thoroughly with water to remove loose dirt before wiping to prevent scratching.
- **Dry Gently:** Pat dry with a clean, soft cloth or allow to air dry to prevent water spots.

Inspection:

- Regularly check all mounting bolts and screws for tightness.
- Inspect the windshield surface for any cracks, chips, or deep scratches that could impair visibility or structural integrity.
- Ensure no parts are loose or vibrating during operation.

TROUBLESHOOTING

This section addresses common issues you might encounter with your windshield.

Problem	Possible Cause	Solution
Windshield is loose or vibrates	Loose mounting bolts; incorrect installation.	Check and tighten all mounting bolts securely. Re-read installation instructions to ensure all steps were followed correctly.
Reduced visibility through windshield	Dirty surface; scratches; incorrect cleaning agents used.	Clean the windshield using only mild soap and water with a soft cloth. Avoid abrasive materials. If scratched, consider professional polishing or replacement.

Problem	Possible Cause	Solution
Increased wind noise or turbulence	Improper installation; rider height/helmet combination; specific riding conditions.	Verify windshield is installed correctly and securely. Experiment with riding posture. Note that some turbulence is normal depending on rider and helmet.

SPECIFICATIONS

Detailed specifications for the Puig 9841N Windshield:

Attribute	Detail
Model Number	9841N
Brand	Puig
Color	Black
Exterior Finish	Stainless Steel (referring to mounting hardware, not windshield material)
Style	Modern, V-Tech Line Supersport
Auto Part Position	Center
Item Weight	1.28 pounds
Package Dimensions	16.93 x 12.8 x 3.15 inches
ASIN	B07P769KXN
Date First Available	August 14, 2019

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please contact Puig directly or the authorized retailer from whom you purchased the product. Keep your proof of purchase for warranty claims.

Manufacturer: PUIG

Website: www.puig.tv (Note: This is a general link to Puig's website, actual support contact details may vary)