Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

allen + roth 26961MB

User Manual for Allen + Roth Matte Black Steel Single Curtain Rod Bracket

Model: 26961MB | Brand: allen + roth

Product Overview

The allen + roth Matte Black Steel Single Curtain Rod Bracket is designed to provide robust and elegant support for your curtain rods. Crafted from durable steel with a sleek matte black finish, these brackets enhance the aesthetic of any room while ensuring long-lasting stability for your window treatments. Each package contains two brackets and all necessary mounting hardware for a straightforward installation.



Image: A single matte black steel curtain rod bracket, showing its wall-mount plate with two screw holes and the curved arm designed to hold a curtain rod.

Important Safety Information

- Always wear appropriate safety gear, such as eye protection, during installation.
- Ensure the mounting surface is suitable and can support the weight of the brackets, curtain rod, and curtains.
- Use a stud finder to locate wall studs for secure mounting, or use appropriate wall anchors for drywall.
- Keep small parts and hardware away from children and pets to prevent choking hazards.
- Do not overtighten screws, as this may damage the bracket or mounting surface.

Package Contents

Verify that all components are present before beginning installation:

- 2 x Matte Black Steel Single Curtain Rod Brackets
- Mounting Hardware (screws and wall anchors)

Installation Guide

Tools Required:

- Pencil
- Tape Measure
- Level
- Drill with appropriate drill bit (for pilot holes and anchors)
- Screwdriver (Phillips head recommended)
- Stud Finder (optional, but recommended for secure mounting)

Step-by-Step Installation:

1. **Determine Placement:** Decide on the desired height and width for your curtain rod. Mark the approximate location for the first bracket on the wall using a pencil. Ensure the brackets will extend beyond the window frame to allow curtains to fully open.
2. **Mark Screw Holes:** Hold one bracket against the wall at your marked location. Use a level to ensure it is straight. Mark the positions of the two screw holes on the wall with your pencil.
3. **Drill Pilot Holes:** Using a drill bit appropriate for your wall type and the provided screws/anchors, drill pilot holes at the marked locations. If drilling into a wall stud, a smaller pilot hole may suffice. For drywall without a stud, insert the provided wall anchors into the pilot holes until flush with the wall surface.
4. **Mount First Bracket:** Align the bracket with the drilled holes (or anchors). Insert the provided screws through the bracket's holes and tighten them securely with a screwdriver. Do not overtighten.
5. **Position Second Bracket:** Measure the desired distance for your curtain rod. Mark the location for the second bracket, ensuring it is level with the first bracket. Use a tape measure and level to confirm alignment.
6. **Mount Second Bracket:** Repeat steps 2-4 for the second bracket. Double-check that both brackets are level and at the correct distance apart.
7. **Install Curtain Rod:** Once both brackets are securely mounted, place your curtain rod into the curved supports of the brackets.

Usage

These single curtain rod brackets are designed to hold one curtain rod securely. Once installed, simply place your curtain rod into the U-shaped cradle of each bracket. Ensure the rod is properly seated and balanced. The robust steel construction provides reliable support for various curtain weights, though it is always recommended to consider the total weight of your curtains and rod to ensure the mounting surface can adequately support it.

Care and Maintenance

- To clean the brackets, simply wipe them with a soft, dry cloth.

- Avoid using abrasive cleaners or harsh chemicals, as these may damage the matte black finish.
- Periodically check the mounting screws to ensure they remain tight and secure. Retighten if necessary.

Troubleshooting

Problem	Possible Cause	Solution
Brackets are not level.	Incorrect marking or drilling.	Remove brackets, re-mark using a level, and re-drill if necessary. Ensure accurate measurements between brackets.
Brackets feel loose on the wall.	Screws not fully tightened or inadequate wall anchors.	Tighten screws. If still loose, consider using stronger wall anchors or mounting into a wall stud.
Curtain rod does not fit.	Rod diameter is too large for the bracket's opening.	Ensure your curtain rod's diameter is compatible with the bracket's design. These brackets are typically designed for standard single curtain rods.

Product Specifications

Feature	Detail
Brand	allen + roth
Model Number	26961MB
Material	Steel
Color	Matte Black
Unit Count	2.0 Count (2 Brackets per pack)
Mounting Type	Wall Mount
Product Dimensions (L x W x H)	3.5 x 4.13 x 1.5 inches
Item Weight	6.4 ounces
UPC	680656165331

Warranty and Support

For information regarding product warranty or technical support, please contact allen + roth customer service. Refer to the product packaging or the official allen + roth website for the most current contact details and warranty terms.

© 2024 allen + roth. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07YR6WBQ1

More documents and user manuals: **https://manuals.plus/**