

[Manuals.plus](#) /

> [AMBEE21](#) /

> AMBEE21 Vintage Style Metal Bed Frame Instruction Manual - Queen Size, Silver (Model: A-1451-QN-SLR)

AMBEE21 A-1451-QN-SLR

AMBEE21 Vintage Style Metal Bed Frame Instruction Manual

Model: A-1451-QN-SLR (Queen Size, Silver)

1. PRODUCT OVERVIEW

The AMBEE21 Vintage Style Metal Bed Frame offers a classic design with modern functionality. This Queen size bed frame in silver features a wrought iron headboard and footboard, providing a sturdy platform for your mattress without the need for a box spring. Its design incorporates gothic accents and wire spindle rods, ideal for enhancing various bedroom decors.

Brand: AMBEE21

Model: A-1451-QN-SLR

Color: Silver

Size: Queen

2. SAFETY INFORMATION

- Exercise caution around sharp edges during assembly and use.
- Do not exceed the maximum weight recommendation of 550 pounds (249 kg).
- Assemble the bed frame carefully to prevent instability.
- Keep children away from the bed frame during assembly and ensure proper supervision during use.

3. KEY FEATURES

- **Vintage Style Design:** Features a wrought iron-art bedframe in a sleek silver finish with gothic accents and wire spindle rods, suitable for classic decor.
- **Sturdy Metal Platform:** Constructed from durable metal, this platform bed provides consistent, noise-free performance for your mattress, eliminating the need for a box spring.
- **Decorative Headboard & Footboard:** Includes vintage-inspired headboard and footboard with gothic curves and twisted wire detailing.
- **Under-Bed Storage:** Offers approximately 11 inches of clearance under the bed for convenient storage of boxes or linens.

- **Easy Assembly:** Ships in one compact box with labeled parts and clear instructions for straightforward setup without extra tools or hardware.

4. SETUP AND ASSEMBLY

The AMBEE21 Vintage Style Metal Bed Frame is designed for easy assembly. All necessary parts are labeled, and clear instructions are included. No additional tools are required for assembly.

Assembly Steps:

1. Unpack all components and verify against the parts list provided in the manual.
2. Assemble the headboard and footboard sections according to the diagrams.
3. Attach the side rails to the headboard and footboard.
4. Install the metal slats onto the frame. Ensure they are securely fastened for mattress support.
5. Tighten all bolts and connections once the frame is fully assembled.



Figure 4.1: Exploded view of bed frame components for assembly.



Figure 4.2: Detail of the easy push assembly mechanism for connecting frame parts.

Assembly Video:

Your browser does not support the video tag.

Video 4.1: Detailed assembly guide for the AMBEE21 Vintage Metal Bed Frame.

5. OPERATING INSTRUCTIONS

This bed frame is designed to support your mattress directly, eliminating the need for a box spring. Simply place your mattress on the assembled metal slats.

Under-Bed Storage:

Utilize the 11 inches of clearance beneath the frame for convenient storage. This space is ideal for storing seasonal clothing, extra bedding, or other items in storage containers.



Figure 5.1: Illustration of the 11-inch under-bed storage space.

6. MAINTENANCE

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Regular Inspection:** Periodically check all bolts and connections to ensure they remain tight. Retighten if necessary to maintain stability and prevent squeaking.
- **Weight Distribution:** Ensure weight is evenly distributed across the bed frame to prevent stress on individual components.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Bed frame is squeaking.	Loose bolts or connections.	Tighten all bolts and connections on the frame.
Mattress slides on the frame.	Lack of mattress skid protection.	Ensure mattress skid protection features are correctly installed or add non-slip pads between the mattress and slats.
Frame feels unstable.	Improper assembly or loose parts.	Re-check all assembly steps and tighten all fasteners. Ensure the frame is on a level surface.

8. SPECIFICATIONS

Size: Queen

Material: Alloy Steel (Iron Headboard)

Product Dimensions (L x W x H): 80"L x 60"W x 46.5"H

Item Weight: 61 Pounds

Maximum Weight Recommendation: 550 Pounds

Under-Bed Clearance: 11 Inches

Style: Vintage

Color: Silver

Assembly Required: Yes (Instructions included)



Figure 8.1: Detailed dimensions of the AMBEE21 Queen Size Vintage Metal Bed Frame.

9. WARRANTY & SUPPORT

Return Policy: This product is eligible for a 30-day return for refund or replacement.

For customer support or inquiries, please refer to the contact information provided by your retailer or visit the [AMBEE21 Store on Amazon](#).

