

Husky Liners 16009

Husky Liners Heavy-Duty Bed Mat Instruction Manual

Model 16009 for 2015-2024 Ford F-150 (78.9-inch Bed)

1. INTRODUCTION

This manual provides essential information for the proper installation, usage, and maintenance of your Husky Liners Heavy-Duty Bed Mat. Designed for specific Ford F-150 models, this bed mat offers robust protection for your truck bed and cargo, while enhancing comfort and stability.

The Husky Liners Heavy-Duty Bed Mat is engineered with DuraGrip HD construction, providing impact absorption and chemical resistance. Its unique Air Dry Nibs promote air circulation, preventing moisture buildup between the mat and the truck bed. This product is proudly made in the USA and is guaranteed for life.

2. SAFETY INFORMATION

- Always ensure the truck bed is clean and free of debris before installation to prevent shifting or damage.
- When handling the bed mat, be aware of its weight (approximately 18.48 pounds) and size to avoid personal injury.
- Do not install this bed mat over existing drop-in bed liners, as this may compromise fitment and performance.
- Secure all cargo properly, even with the anti-skid surface, to prevent movement during transit.

3. PACKAGE CONTENTS

- One (1) Husky Liners Heavy-Duty Bed Mat (Model 16009)

4. INSTALLATION

The Husky Liners Heavy-Duty Bed Mat is designed for quick and tool-free installation.

1. Ensure your truck bed is clean and dry before proceeding. Remove any existing drop-in liners.
2. Unroll the Husky Liners Heavy-Duty Bed Mat into the truck bed.
3. Position the mat to align with the contours of your truck bed. The custom fit ensures proper coverage.

Note: The mat may arrive rolled. Allow it to lay flat for a short period to regain its intended shape, especially in warmer temperatures.



Figure 1: The Husky Liners Heavy-Duty Bed Mat fully installed in a truck bed, showcasing its custom fit and textured surface.

HEAVY-DUTY BED MAT

Installs with no tools.

Easy to install in a matter of seconds with no tools.

Simply pull out to remove.



Figure 2: A person positioning the Husky Liners Bed Mat into the truck bed, demonstrating the ease of installation without tools.

5. OPERATION AND USAGE

Your Husky Liners Heavy-Duty Bed Mat provides multiple benefits during daily use:

- **Bed Protection:** The DuraGrip HD construction absorbs impact from cargo, protecting your truck bed from dents, scratches, and other damage.
- **Anti-Skid Surface:** The textured surface helps prevent cargo from sliding around in the bed during transit, providing stability for your items.
- **Knee Comfort:** The mat's material offers a cushioned surface, providing comfort for your knees when working in the truck bed.

HEAVY-DUTY BED MAT

Two-way protection for bed & cargo.

Super-tough, rubberized DuraGrip HD™ construction.

Absorbs impact of objects to protect the bed.

Resistant to most chemicals.



Figure 3: A sleigh resting on the Husky Liners Bed Mat in a truck bed with snow, illustrating the mat's anti-skid properties and durability in various conditions.



Figure 4: A person kneeling on the Husky Liners Bed Mat while operating a power saw, demonstrating the mat's comfort and robust surface for working in the truck bed.

6. MAINTENANCE

Maintaining your Husky Liners Heavy-Duty Bed Mat is simple and helps prolong its lifespan and effectiveness:

- **Cleaning:** The mat can be easily cleaned by hosing it down with water. For stubborn dirt, a mild soap solution and a brush can be used. Allow it to air dry.
- **Moisture Management:** The integrated Air Dry Nibs on the underside of the mat keep it slightly elevated, allowing air to circulate and preventing moisture from being trapped between the mat and the truck bed. This helps prevent mildew and corrosion.
- **Chemical Resistance:** The mat is resistant to most chemicals, making it suitable for various hauling needs.

HEAVY-DUTY BED MAT

Moisture's out, protection's in.

Backed with a grid of AirDry Nibs.

Mat stays slightly elevated so air can pass through.

Moisture stays out, mat and bed stay dry.



Figure 5: A hand lifting a corner of the Husky Liners Bed Mat, revealing the Air Dry Nibs on the underside designed to promote air circulation and prevent moisture buildup.



Figure 6: A person cleaning a Husky Liners Bed Mat outdoors with water, demonstrating the ease of maintenance for the product.

7. TROUBLESHOOTING

Most issues with the Husky Liners Heavy-Duty Bed Mat relate to fitment or cleaning. If you encounter any problems:

- **Improper Fit:** Ensure the mat is correctly positioned and that no other bed liners are present underneath. Verify your vehicle's make, model, and bed size match the product specifications. This mat is specifically for 2015-2024 Ford F-150 with a 78.9-inch bed.
- **Mat Not Lying Flat:** If the mat does not lay perfectly flat immediately after unrolling, allow it some time, especially in warmer conditions, to relax and conform to the truck bed.
- **Persistent Odor:** A new rubber product may have a slight odor initially. This will dissipate over time with exposure to air.

8. SPECIFICATIONS

Feature	Detail
Brand	Husky Liners
Model Number	16009
Color	Black
Material	Rubberized DuraGrip HD
Fitment	2015-2024 Ford F-150 (78.9-inch / 6'7" Bed)
Item Weight	18.48 pounds
Special Features	Heavy-duty, Anti-skid, Air Dry Nibs, Chemical Resistant

9. WARRANTY AND SUPPORT

Husky Liners products, including this Heavy-Duty Bed Mat, are backed by a lifetime guarantee. For warranty claims, product support, or further assistance, please contact Husky Liners customer service directly. Refer to the official Husky Liners website or product packaging for the most current contact information.

© 2024 Husky Liners. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question