



Manuals+



[Manuals.plus](#) /

› [ScratchesHappen](#) /

› ScratchesHappen Exact-Match Spray Paint - Woodland Green (R39/WR39) for Rolls-Royce - Essential (Paint + Clear Coat) User Manual

ScratchesHappen SH-PAINT-KIT-AEROSOL-ESSENTIAL-5135

ScratchesHappen Exact-Match Spray Paint User Manual

Model: SH-PAINT-KIT-AEROSOL-ESSENTIAL-5135

Brand: ScratchesHappen

PRODUCT OVERVIEW

This touch up paint kit is engineered to address and repair scratches and scuff marks on vehicle surfaces. It provides a color-matched solution for restoring the appearance of your vehicle.

Key features include:

- **Easy Restoration:** Fix scratches and scuff marks with color-matched spray paint. Step-by-step instructions simplify the process, requiring no prior experience.
- **Cost-Effective Repairs:** Enables DIY paint damage repair, avoiding expensive body shop visits while delivering quality results.
- **Enhanced Durability:** Includes a clear coat for application over the paint, sealing it and achieving the proper finish. The clear coat enhances color match and acts as a protective shield.
- **Note on Primer:** Primer is not included in this kit. For bare metal or plastic surfaces, applying primer first is recommended to improve paint adhesion. Primer is available in the Preferred kit for deeper scratches.



Image: The ScratchesHappen Exact-Match Spray Paint kit, showing both the paint and clear coat aerosol cans.

SETUP AND PREPARATION

Proper preparation is crucial for achieving optimal results. Ensure the area is clean and free from contaminants.

1. **Clean the Surface:** Thoroughly clean the area to be painted with soap and water, then dry completely. Remove any wax, grease, or silicone.
2. **Sand (if necessary):** For deeper scratches or rough surfaces, lightly sand the area with fine-grit sandpaper (e.g., 600-800 grit wet/dry sandpaper) to smooth it out. Clean off any sanding dust.
3. **Mask Surrounding Areas:** Use automotive masking tape and paper or plastic sheeting to protect areas not intended for painting.
4. **Apply Primer (if needed):** If painting over bare metal or plastic, or if the scratch is deep, apply an appropriate automotive primer. Allow the primer to dry completely according to its instructions before proceeding.
5. **Shake Cans:** Before use, vigorously shake both the paint and clear coat cans for at least one minute after the mixing ball begins to rattle. Continue shaking periodically during application.

OPERATING INSTRUCTIONS (APPLICATION)

Follow these steps carefully for best results in applying the paint and clear coat.

1. **Test Spray:** Always perform a test spray on a hidden area or a test card to check color match and spray pattern.
2. **Apply Paint:** Hold the paint can approximately 8-12 inches (20-30 cm) from the surface. Apply thin, even coats using a steady, sweeping motion. Avoid applying too much paint at once to prevent runs.
3. **Layering:** Allow 5-10 minutes between coats for the paint to flash off (become tacky). Apply 2-3 coats or until the scratch is adequately covered and the color matches the surrounding area.
4. **Drying Time for Paint:** Allow the final paint coat to dry for at least 30-60 minutes before applying the clear coat. For best results, wait 24 hours if possible, especially in humid conditions.
5. **Apply Clear Coat:** Once the paint is dry to the touch, apply the clear coat using the same technique as the paint: thin, even coats from 8-12 inches away.
6. **Clear Coat Layers:** Apply 2-3 coats of clear coat, allowing 5-10 minutes between coats. The clear coat provides gloss and protection.
7. **Final Drying:** Allow the clear coat to dry for at least 24 hours before handling the painted area. Full cure time may vary depending on temperature and humidity, typically 2-7 days.



Image: A visual demonstration of the product's effectiveness, showing a scratched gas cap area before and after repair.

DON'T WORRY, WE'VE GOT YOU COVERED

STEP-BY-STEP INSTRUCTIONS
FOR GREAT RESULTS EVERY TIME

Scratches
happen

REFINISHING
SIMPLIFIED

Image: A person examining a car's paint, illustrating the focus on achieving a perfect finish with the step-by-step instructions.

MAINTENANCE

Once the paint and clear coat have fully cured, the repaired area can be maintained like the rest of your vehicle's finish.

- **Washing:** After the full cure time (typically 7 days), the repaired area can be washed with mild automotive soap and water. Avoid harsh chemicals or abrasive cleaners.
- **Waxing/Polishing:** For optimal protection and shine, you may wax or polish the repaired area after the clear coat has fully cured. This will help blend the repair with the surrounding paint.
- **Protection:** The clear coat provides a protective layer against UV rays and environmental elements, helping to maintain the color and finish over time.

TROUBLESHOOTING

If you encounter issues during or after application, consider the following common problems and solutions:

- **Runs or Sags:** This usually occurs from applying too much paint or clear coat in one pass, or holding the can too close. If wet, wipe off and reapply. If dry, light sanding and reapplication may be necessary.
- **Uneven Finish/Orange Peel:** Can be caused by holding the can too far away, insufficient shaking, or improper temperature/humidity. Ensure proper distance and consistent motion.
- **Poor Adhesion:** Often due to inadequate surface preparation (e.g., not cleaning thoroughly, not sanding, or not using primer on bare surfaces). Ensure the surface is clean, dry, and properly prepped.
- **Color Mismatch:** While this product is exact-match, slight variations can occur due to vehicle age, sun exposure, or application technique. Always test on an inconspicuous area first.
- **Slow Drying:** High humidity or low temperatures can significantly extend drying and cure times. Ensure application in a well-ventilated area with moderate temperature and humidity.

SPECIFICATIONS

Attribute	Detail
Brand	ScratchesHappen
Color	Woodland Green (R39/WR39)
Finish Type	Metallic
Size	23.46 Ounce (Pack of 1)
Item Volume	177 Milliliters
Special Feature	UV Resistant
Unit Count	23.46 Ounce
Paint Type	Spray
Specific Uses For Product	Exterior
Surface Recommendation	Metal, Plastic, Fiberglass
Item Form	Aerosol
UPC	057345270391
Manufacturer	ScratchesHappen
Part Number	SH-PAINT-KIT-AEROSOL-ESSENTIAL-5135
Item Weight	1.47 pounds
Product Dimensions	5.51 x 2.76 x 8.27 inches

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available documentation. For any product-related

inquiries, technical support, or warranty claims, please contact ScratchesHappen directly.

You can find more information and contact details on the official ScratchesHappen website or through your purchase platform.

Manufacturer: [ScratchesHappen](#)

© 2023 ScratchesHappen. All rights reserved.

This manual provides general guidelines. Always refer to specific product labels for detailed safety and application instructions.