

Spigen AFL01445

Spigen NeoFlex Screen Protector Instruction Manual

For Samsung Galaxy Note 20 Ultra (Model AFL01445)

INTRODUCTION

This manual provides detailed instructions for the proper installation, use, and maintenance of your Spigen NeoFlex Screen Protector for the Samsung Galaxy Note 20 Ultra. Following these guidelines will help ensure optimal performance and longevity of your screen protector.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- 2 x Spigen NeoFlex Screen Protectors
- 1 x Installation Spray Solution
- 1 x Squeegee
- 1 x Microfiber Cleaning Cloth
- 1 x Dust Removal Sticker

SETUP: INSTALLATION GUIDE

For best results, perform the installation in a dust-free environment. It is recommended to watch the official Spigen installation video, typically available on the product page or manufacturer's website, before beginning.

Preparation

1. Wash your hands thoroughly to remove any oils or dirt.
2. Power off your Samsung Galaxy Note 20 Ultra.
3. Use the microfiber cleaning cloth to wipe the screen clean. Ensure there are no smudges or fingerprints.
4. Use the dust removal sticker to lift any remaining dust particles from the screen. Inspect the screen carefully under good lighting.

Application Steps

1. **Spray Application:** Lightly spray the installation solution onto your fingertips and both sides of the screen protector. This allows for repositioning during installation.

2. **Positioning:** Carefully peel off the protective film from the screen protector. Align the screen protector with your phone's screen, ensuring the cutouts for the camera and sensors match perfectly. The wet application allows you to slide and adjust the protector until it is perfectly centered.
3. **Squeegee Out Bubbles:** Once aligned, use the provided squeegee to gently push out any excess solution and air bubbles from the center towards the edges. Apply firm, even pressure. For curved edges, apply pressure and hold for a few seconds to help the protector adhere.
4. **Drying Time:** Allow the screen protector to dry for several hours, ideally 12-24 hours, without touching or using the device. Small bubbles or haziness may be present immediately after installation; these will typically disappear as the solution dries and evaporates.



Image: Initial placement of the Spigen NeoFlex Screen Protector on the Samsung Galaxy Note 20 Ultra screen.



Image: Using the squeegee to remove air bubbles and excess solution during installation.



Image: The Spigen NeoFlex Screen Protector fully applied to the Samsung Galaxy Note 20 Ultra.

OPERATING: USAGE TIPS

- **Fingerprint Scanner:** After the screen protector has fully dried and cured, re-register your fingerprints in your phone's settings. This ensures optimal performance of the in-display fingerprint sensor.
- **Touch Sensitivity:** If you experience reduced touch sensitivity, enable the 'Touch sensitivity' option in your phone's display settings.
- **S Pen Usage:** The NeoFlex protector is compatible with the S Pen. Note that the feel of the S Pen on the TPU material may differ slightly from direct screen contact.

MAINTENANCE

- **Cleaning:** To clean the screen protector, gently wipe it with a soft, damp cloth. Avoid harsh chemicals or abrasive materials.
- **Self-Healing:** The NeoFlex protector features self-healing properties for minor scratches. Deeper marks or punctures may not fully recover.

TROUBLESHOOTING

- **Small Bubbles/Haze:** If small bubbles or haziness remain after installation, allow more drying time (up to 48 hours). These are typically residual moisture from the installation solution and will dissipate naturally.
- **Edges Lifting:** If the edges begin to lift, gently press them down with your finger or the squeegee, applying consistent pressure for a few seconds. This may be more effective after the protector has partially dried.
- **Fingerprint Scanner Not Working:** Ensure you have re-registered your fingerprints after installation and enabled 'Touch sensitivity' in your phone's settings. Clean the fingerprint sensor area on the screen protector.
- **Dust Under Protector:** If dust particles are trapped under the protector, it may be necessary to carefully lift a corner, use a dust removal sticker to remove the particle, and then re-apply the section with a small amount of spray solution and squeegee. If unsuccessful, consider using the second protector provided.

SPECIFICATIONS

Model Number	AFL01445
Compatible Devices	Samsung Galaxy Note 20 Ultra
Material	Thermoplastic Polyurethane (TPU)
Item Hardness	9H
Product Dimensions (L x W)	15.9L x 7.4W Centimetres
Unit Count	2 Count
Water Resistance Level	Water Resistant
Finish Type	Matte
Screen Size Compatibility	6.9 Inches

WARRANTY AND SUPPORT

Spigen products are designed for quality and durability. For any questions, concerns, or warranty inquiries regarding your NeoFlex Screen Protector, please contact Spigen customer support directly through their official website or the retailer where the product was purchased. Please have your model number (AFL01445) and proof of purchase available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08CZ15HZR>

More documents and user manuals: **<https://manuals.plus/>**