



Manuals.plus /

- › TOP QUALITY /
- › TOP QUALITY Front Wiper Blades Instruction Manual (Model K90-100561)

## TOP QUALITY K90-100561

# TOP QUALITY Front Wiper Blades Instruction Manual (Model K90-100561)

This manual provides detailed instructions for the installation, operation, and maintenance of your TOP QUALITY K90-100561 Front Wiper Blades.

## 1. PRODUCT OVERVIEW

---

The TOP QUALITY K90-100561 Front Wiper Blades are designed to provide clear visibility for your vehicle's windshield. Featuring an exclusive improved flexible spine design, these blades ensure maximum contact with the screen for effective wiping. This product is covered by a limited lifetime warranty against manufacturer defects.

## 2. PACKAGE CONTENTS

---

- 2x Front Windshield Wiper Blades (Model K90-100561)

## 3. SAFETY INFORMATION

---

Always exercise caution when working on your vehicle. Ensure the vehicle is parked on a level surface with the engine off and parking brake engaged. Avoid touching the windshield wiper arm or blade while the ignition is on to prevent accidental activation. If unsure about any step, consult a professional mechanic.

## 4. VEHICLE FITMENT CHECK

---

Before installation, it is crucial to confirm that the K90-100561 wiper blades are compatible with your vehicle. Refer to the vehicle fitment guide to verify the correct year, make, model, and sub-model. Also, confirm the correct position (front) for the part you are purchasing. Pay close attention to any specific notes regarding fitment, such as disc rotor size, brake type, production date, or transmission type, to ensure proper installation and avoid returns.

# IMPORTANT!

## VEHICLE FITMENT CHECK

1.

Select your vehicle: Year ▼ Make ▼ Model ▼

Confirm your vehicle Year, Make, Model, Sub-Model and confirm the position of the part you are purchasing.

2.

✓ This fits your: 2015 Volkswagen Passat ▼  
See all products that fit this vehicle  
This product fits this position on your 2015 Volkswagen Passat:  
- Front and Rear  
| Notes: Vehicle Production Date To 6/30/14

### NOTE:

There may be notes to carefully check even after the vehicle fitment is confirmed.

These notes provide specific information supplementing the fitment such as disc rotors size, brakes type, the part position, the production date, transmission type (2wd/4wd), operating parking brake (power or manual) and more.

**We recommend to double check the fitment, verify the note carefully (if any), validate the position needed and make sure the product picture match the part you need to avoid having to return the product.**

Figure 1: Important Vehicle Fitment Check. This image illustrates the steps to confirm vehicle compatibility for the wiper blades, including selecting vehicle details and reviewing specific fitment notes.

## 5. INSTALLATION INSTRUCTIONS

Follow these steps to install your new TOP QUALITY K90-100561 Front Wiper Blades. It is recommended to place a towel on the windshield when lowering the wiper arm to prevent damage.

### 5.1. Removing Old Wiper Blades

1. Lift the wiper arm away from the windshield until it locks into the upright position.
2. Locate the release tab or button on the old wiper blade's connector.
3. Press the tab or button and slide the old wiper blade off the wiper arm. Some older models may require a specific adapter removal.
4. Carefully lower the wiper arm back onto the windshield, ensuring a towel is placed underneath to prevent the arm from hitting and cracking the glass.

## 5.2. Installing New Wiper Blades

The K90-100561 wiper blades are designed for easy installation on most common wiper arm types. The blade comes with a pre-installed adapter. If your vehicle requires a different adapter type (e.g., a specific hook or pin type), you may need to remove the pre-installed adapter and attach the correct one provided with the blade, following the instructions on the packaging.

1. Lift the wiper arm away from the windshield again.
2. Align the new wiper blade's connector with the wiper arm. For U/J-hook type arms, ensure the hook slides securely into the adapter. For other types, ensure the correct adapter is attached and properly aligned.
3. Slide the new wiper blade onto the wiper arm until it clicks into place. Gently pull on the blade to ensure it is securely fastened.
4. Remove the green protective cover from the wiper blade.
5. Carefully lower the wiper arm back onto the windshield.
6. Repeat the process for the other front wiper blade.

## 5.3. Visual Installation Guides

For visual assistance, please refer to the following instructional videos:

### U/J-Hook Wiper Blade Installation Video

Your browser does not support the video tag.

Video 1: This video demonstrates the installation process for U/J-Hook type wiper blades, showing how to remove the old blade and securely attach the new one.

### OEM Wiper Installation Video

Your browser does not support the video tag.

Video 2: This video provides a general guide for installing OEM quality wiper blades, covering the steps from removal to secure attachment.

### SIMPWIBLD All Season Premium Windshield Wiper Blades Installation

Your browser does not support the video tag.

Video 3: A quick demonstration of installing SIMPWIBLD all-season premium windshield wiper blades, highlighting key steps for a secure fit.

## 6. OPERATION

Once installed, operate your wiper blades by activating your vehicle's windshield wiper controls. Ensure they move smoothly across the windshield and clear water effectively without streaking or excessive noise. Test them in various settings (intermittent, low, high) to confirm proper function.



Figure 2: TOP QUALITY K90-100561 Front Wiper Blades. This image displays the pair of front windshield wiper blades, ready for installation and operation.

## 7. MAINTENANCE

---

- **Regular Cleaning:** Periodically clean the rubber edge of the wiper blades with a soft cloth and windshield washer fluid or mild soap and water. This removes dirt, grime, and road film that can cause streaking.
- **Inspect for Damage:** Regularly check the wiper blades for cracks, tears, or hardening of the rubber. Damaged blades should be replaced immediately to maintain clear visibility.
- **Avoid Dry Wiping:** Do not operate wiper blades on a dry windshield, as this can damage the rubber and scratch the glass. Always use windshield washer fluid.
- **Winter Care:** In freezing conditions, ensure wiper blades are not frozen to the windshield before operating them. Gently lift them away from the glass or use a defroster to thaw them.

## 8. TROUBLESHOOTING

---

- **Streaking:**
  - Clean the wiper blades and windshield thoroughly.
  - Check for damaged or worn rubber; replace blades if necessary.
  - Ensure the wiper arm has proper tension against the windshield.
- **Chattering/Skipping:**
  - Clean the windshield and blades.
  - Check if the wiper arm is bent or has insufficient tension.
  - Ensure the wiper blade is installed correctly and not twisted.
- **Ineffective Wiping:**
  - Verify correct blade size and fitment for your vehicle.
  - Inspect blades for wear or damage.

- Ensure the wiper arm is making full contact with the windshield.

## 9. SPECIFICATIONS

---

<b>Brand</b>	TOP QUALITY
<b>Model Number</b>	K90-100561
<b>Manufacturer</b>	Transit
<b>Position</b>	Front
<b>Material</b>	Metal, Rubber
<b>Item Weight</b>	370 g
<b>Fit Type</b>	Vehicle Specific Fit
<b>Date First Available</b>	Nov. 20 2020

## 10. WARRANTY

---

This TOP QUALITY K90-100561 Front Wiper Blade product is covered by a limited lifetime warranty against manufacturer defects. For warranty claims or further details, please refer to the manufacturer's official website or contact their customer support.

## 11. SUPPORT

---

For additional assistance, technical support, or inquiries regarding your TOP QUALITY K90-100561 Front Wiper Blades, please contact the manufacturer, Transit, directly. Contact information can typically be found on the product packaging or their official website.