

HOOMIC B097K43RFC

**HOOMIC Queen Size Upholstered Platform Bed Frame
Instruction Manual**

Model: B097K43RFC

		Overview	Features	Package		
Contents	Specifications	Assembly	Maintenance	Troubleshooting	Warranty & Support	

1. PRODUCT OVERVIEW

This manual provides instructions for the assembly, operation, and maintenance of your HOOMIC Queen Size Upholstered Platform Bed Frame. This bed frame features a durable design with a fabric upholstered headboard and strong wood slats, eliminating the need for a box spring.



Figure 1: HOOMIC Queen Size Upholstered Platform Bed Frame (Blue)

2. KEY FEATURES

- **Simple Durable Design:** Features an interior steel design with an upholstered fabric linen finish and clean lines, creating a contemporary feel.
- **Sturdy for Quiet Sleep:** Integrated design and extra strong support legs ensure stability and minimize noise for a restful night's sleep.
- **No Box Spring Needed:** Sturdy wooden slats provide direct support for latex, memory foam, or spring mattresses.
- **High Weight Capacity:** All sizes of bed frames support up to 800 lbs.
- **Easy Assembly:** Includes a step-by-step instruction manual and all necessary hardware tools for quick assembly within 30-60 minutes.
- **Single Box Packaging:** Conveniently packaged in one box for easy transport, assembly, and disassembly.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Bed Frame Components
- Headboard
- Wood Slats
- Hardware Pack (screws, bolts, tools)



Figure 2: Key structural components including Quick Setup Velcro, Strong Wood Slats, and Noise-Free EVA Foam.

4. PRODUCT SPECIFICATIONS

Brand	HOOMIC
Model Number	B097K43RFC
Size	Queen
Color	Blue
Dimensions (L x W x H)	82.2" x 60.6" x 43.3"
Weight Capacity	800 lbs
Material	Metal, Wood, Polyester Fabric

Assembly Required	Yes
Box Spring Needed	No



Figure 3: Queen Size Bed Frame Dimensions and Max Capacity.



Figure 4: Product highlights: 800 lbs weight capacity, no box spring required, and packaged in 1 box.

5. ASSEMBLY INSTRUCTIONS

Please follow these steps carefully to assemble your HOOMIC bed frame. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the single package. Lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Headboard:** Attach the headboard panels as per the included diagram. Ensure all bolts are securely tightened.
3. **Connect Side Rails:** Attach the side rails to the headboard and footboard using the provided hardware. The side rails feature a quick setup Velcro system for slat attachment.
4. **Install Center Support:** Place the center support bar(s) and legs into position. Ensure they are aligned and securely fastened to the frame.
5. **Place Wood Slats:** Lay the wooden slats across the frame. The slats are designed with EVA foam to prevent noise and are secured with Velcro to the side rails. Ensure even spacing and secure placement of all slats.
6. **Final Tightening:** Double-check all bolts and connections to ensure they are tight and secure.

Strong Foot Pads

Protect floor from scratches and provide powerful support



Figure 5: Strong foot pads for floor protection and stability.

Your browser does not support the video tag.

Video 1: Assembly overview for HOOMIC bed frame, demonstrating key features like strong structure and accessible cleaning.

6. OPERATING INSTRUCTIONS

Once assembled, your HOOMIC bed frame is ready for use. No box spring is required. Simply place your mattress directly onto the wooden slats.

- Ensure the mattress is centered and evenly distributed on the slats.
- The bed frame is designed to support a maximum weight of 800 lbs. Do not exceed this limit.
- The design allows for easy cleaning underneath the bed frame, accommodating robotic vacuums.

7. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your bed frame.

- **Cleaning:** For the upholstered fabric, gently vacuum with an upholstery attachment to remove dust. For spills, blot immediately with a clean, damp cloth. Avoid harsh chemicals.

- **Frame Inspection:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten if necessary to maintain stability and prevent squeaking.
- **Slats:** Ensure slats remain properly seated and undamaged. Replace any broken slats immediately to maintain mattress support.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable.	Loose bolts or uneven assembly.	Ensure all bolts are securely tightened. Check that all legs are making even contact with the floor.
Squeaking noises.	Loose connections, friction between parts, or improperly seated slats.	Re-tighten all hardware. Verify that the EVA foam on the slats is intact and positioned correctly. Ensure slats are fully seated.
Mattress sagging.	Damaged or improperly spaced slats.	Inspect all wooden slats for damage. Ensure they are evenly spaced and securely attached to the frame. Replace any broken slats.

9. WARRANTY AND SUPPORT

The HOOMIC Queen Size Upholstered Platform Bed Frame comes with a limited warranty. Please refer to your purchase documentation or the manufacturer's website for specific warranty terms and conditions.

For customer support, missing parts, or further assistance, please contact HOOMIC customer service through the retailer where the product was purchased or visit the official HOOMIC website.