

[Manuals.plus](#) /

› [VECELO](#) /

› VECELO 14-Inch Metal Platform Bed Frame Instruction Manual (Model Q09)

## VECELO Q09

# VECELO 14-Inch Metal Platform Bed Frame Instruction Manual

Model: Q09

### IMPORTANT SAFETY INFORMATION

- **Maximum Weight Capacity:** Do not load more than 3000 pounds on the bed frame.
- **Sharp Edges:** Exercise caution around all edges during assembly and use to prevent injury.
- **Assembly:** Always follow the assembly instructions precisely to ensure stability and prevent collapse.
- **Leg Contact:** Ensure all support legs remain in full contact with the ground at all times.
- **Regular Inspection:** Periodically check all screws and bolts to ensure they are tightened.
- **Mattress Not Included:** This product includes the bed frame only; a mattress must be purchased separately.

### PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged.

- 1 x VECELO 14-Inch Metal Platform Bed Frame (Queen Size)
- 1 x Instruction Manual
- 1 x Assembly Kit (includes all necessary hardware and tools)

### SETUP AND ASSEMBLY

Follow these steps carefully to assemble your VECELO Metal Platform Bed Frame. It is recommended to have two people for assembly.

#### 1. Unpack and Identify Parts:

Carefully unpack all components from the box. Lay them out on a clean, soft surface to prevent scratches. Each part is labeled with a letter for easy identification, matching the instructions.



Image: All bed frame components laid out for assembly.

## 2. Assemble the Main Frame:

Connect the side rails and end rails using the provided bolts and the included Allen wrench or your own drill with a suitable bit. Ensure all connections are secure but do not fully tighten the bolts until the entire frame is assembled. The frame features plastic caps on the ends of the slats to prevent squeaking and scratching.



Image: Detail of the plastic caps on the metal slats for noise reduction.

### 3. Install Center Support and Legs:

Attach the central support bar and its corresponding legs. These are crucial for the frame's stability and weight distribution. Ensure these legs are firmly attached and will make full contact with the floor.



Image: Dimensions of the assembled bed frame.

#### 4. Insert Slats:

Place the metal slats into the designated slots on the side rails. These slats provide direct support for your mattress, eliminating the need for a box spring. Ensure each slat is properly seated.

#### 5. Final Tightening:

Once all parts are assembled and correctly aligned, go back and securely tighten all bolts. This step is vital for the frame's long-term stability and to prevent any wobbling or noise.



Image: Fully assembled bed frame, ready for mattress placement.

## OPERATION

The VECELO 14-Inch Metal Platform Bed Frame is designed for direct mattress placement, eliminating the need for a box spring. Its robust metal slat system provides ample support for various mattress types.

- **Mattress Placement:** Carefully place your mattress directly onto the assembled metal slats.
- **Under-Bed Storage:** The 12.6-inch clearance beneath the frame offers significant space for storage, helping to keep your bedroom organized.
- **Noise-Free Design:** The reinforced steel frame and plastic caps on the slats are engineered to minimize noise, providing a quiet sleeping environment.



Image: Key features of the bed frame.

## MAINTENANCE

- **Cleaning:** Wipe the metal frame with a dry cloth to remove dust and debris. Avoid harsh chemicals that may damage the finish.
- **Regular Checks:** Periodically (e.g., every 3-6 months) inspect all bolts and connections to ensure they remain tight. Re-tighten if necessary to maintain stability and prevent squeaking.
- **Floor Protection:** The legs are designed with soft pads to protect your floors. Ensure these pads are intact and in place.

## TROUBLESHOOTING

| Problem                             | Possible Cause                                              | Solution                                                                                                                                                                                                                 |
|-------------------------------------|-------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Bed frame is squeaking or wobbling. | Loose bolts or uneven legs.                                 | Ensure all bolts are fully tightened. Check that all support legs are making firm contact with the floor. Adjust if necessary.                                                                                           |
| Mattress slides on the frame.       | Lack of friction between mattress and slats.                | The frame is designed with a slight subsidence to help prevent mattress sliding. If sliding persists, consider using a non-slip mattress pad between the mattress and the slats.                                         |
| Difficulty during assembly.         | Parts not aligned correctly or bolts tightened prematurely. | Refer to the labeled parts and ensure correct orientation. Do not fully tighten bolts until all components are loosely assembled. If a piece seems difficult to fit, double-check the instructions for proper placement. |

## SPECIFICATIONS

| Feature                                       | Detail              |
|-----------------------------------------------|---------------------|
| Brand                                         | VECELO              |
| Model Number                                  | Q09 (YT-Q09)        |
| Size                                          | Queen               |
| Material                                      | Alloy Steel, Metal  |
| Color                                         | Mattle Black        |
| Product Dimensions (L x W x H)                | 81.5" x 62" x 14.2" |
| Ground to Item Distance (Under-bed clearance) | 12.6 Inches         |
| Item Weight                                   | 17.65 Kilograms     |
| Maximum Weight Recommendation                 | 3000 Pounds         |
| Box Spring Required                           | No                  |
| Assembly Required                             | Yes                 |
| Product Care Instructions                     | Wipe with Dry Cloth |

## WARRANTY AND SUPPORT

VECELO is committed to providing quality products and excellent customer service. If you encounter any issues or have questions regarding your bed frame, please do not hesitate to contact us.

- **Customer Service:** We pack items carefully and include buffers to protect against shipping damage. For any concerns, please contact VECELO customer support.
- **Quality Standards:** VECELO products are designed to be space-saving, highly compatible, and economically

priced.

- **Assistance:** We are always available to address your questions and concerns.

© 2024 VECELO. All rights reserved.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B09LYNB123>

More documents and user manuals: <https://manuals.plus/>