



[Manuals.plus](#) /

> [ikalido](#) /

> ikalido Queen Size Metal Canopy Bed Frame with Wooden Headboard (Model CY-9931-4) Instruction Manual

ikalido CY-9931-4

ikalido Queen Size Metal Canopy Bed Frame with Wooden Headboard (Model CY-9931-4) Instruction Manual

Brand: ikalido | Model: CY-9931-4

1. SAFETY INFORMATION

Important: Do not exceed the maximum weight recommendation of 800 pounds. Be cautious around the canopy to prevent entanglement. Ensure all connections are securely fastened before use.

2. PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. Refer to the included parts list in your package. The package typically includes:

- Metal Bed Frame Components
- Wooden Headboard Panel
- Wooden Slats
- Assembly Hardware (screws, washers, Allen wrench)
- Instruction Manual (this document)

Note: Mattress is not included.

3. SPECIFICATIONS

Feature	Detail
Size	Queen
Product Dimensions	83"L x 60"W x 72"H
Weight Capacity	800 lbs

Feature	Detail
Material	Alloy Steel, Wood (Headboard)
Color	Rustic Brown
Assembly Required	Yes
Box Spring Needed	No
Under-bed Clearance	12.4 inches



Image: Detailed product dimensions and weight capacity for the ikalido Queen Size Metal Canopy Bed Frame.

4. SETUP AND ASSEMBLY

Assembly of the ikalido Queen Size Metal Canopy Bed Frame is designed to be straightforward. We recommend two people for assembly to ensure ease and safety. All necessary tools and hardware are included.

Preparation:

- Clear a spacious area for assembly.
- Unpack all components and lay them out, identifying each part using the included parts list.
- Ensure all hardware is present.

Assembly Steps:

1. **Assemble the Side Rails:** Connect the long side rails to the headboard and footboard sections using the provided screws and Allen wrench. Do not fully tighten screws until the entire frame is assembled.
2. **Attach the Headboard:** Secure the wooden headboard panel to the designated slots on the headboard frame.
3. **Install Center Support Legs:** Attach any central support legs to the middle beam of the frame.
4. **Place Slats:** Lay the wooden slats across the frame. The slats feature Velcro tape to prevent movement and ensure stability. Press firmly to secure the Velcro.
5. **Assemble Canopy Posts:** Attach the four vertical canopy posts to the corners of the bed frame.
6. **Connect Top Canopy Rails:** Connect the horizontal top rails to the canopy posts to complete the canopy structure.
7. **Final Tightening:** Once all components are in place and aligned, systematically tighten all screws. Ensure all connections are firm and secure.

Tip: Pay close attention to the orientation of the frame bars and ensure holes align as shown in the diagrams to avoid reassembly.



Image: The ikalido Queen Size Metal Canopy Bed Frame fully assembled, ready for a mattress.



01.



Stylish Design

Features the classic wood texture panel for variety of decoration.



Image: Close-up of thoughtful design elements: Velcro tape on slats for stability, EVA sponge for noise reduction, and durable metal and wood construction.

5. OPERATION (MATTRESS PLACEMENT)

This bed frame is designed to be used without a box spring. Simply place your mattress directly onto the wooden slats. The recommended mattress height is 10-14 inches for optimal comfort and aesthetic.



Mattress Recommendation

Height: 10–14”

1 Mattress



or

2 Mattress + Box Spring



Image: Illustration of mattress recommendation, indicating a 10-14 inch mattress is ideal, and that a box spring is not required.

The 12.4-inch under-bed clearance provides convenient storage space. You can utilize this area for storage bins, seasonal items, or other sundries.



Image: View of the 12.4-inch under-bed storage space, demonstrating its utility for baskets and other items.

6. MAINTENANCE

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. The wooden headboard can be cleaned with a wood-safe cleaner.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability and prevent noise.
- **Weight Distribution:** Distribute weight evenly across the bed frame to prevent stress on individual slats or frame components.
- **Canopy Care:** If using canopy curtains (not included), ensure they are installed securely and do not interfere with the frame's structure.

The durable P2 MDF board headboard is crafted to be stain and scratch resistant, simplifying maintenance.

7. TROUBLESHOOTING

Issue: Bed frame is squeaking.

Solution: Ensure all screws are fully tightened. The frame is designed with an EVA sponge to prevent noise, but loose connections can still cause squeaking. Check that the wooden slats are properly seated and the Velcro is securely attached.

Issue: Bed frame feels unstable or wobbly.

Solution: Verify that all frame components are correctly assembled and all screws are tightened. Ensure the bed is placed on a flat, level surface. Uneven flooring can affect stability.

Issue: Missing parts or damaged components.

Solution: Refer to the package contents list. If any parts are missing or damaged upon arrival, contact ikalido customer support immediately for assistance.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official ikalido website. Our customer service team is available to assist with any questions or concerns regarding your bed frame.

Contact Information: Please refer to the contact details provided in your product packaging or on the ikalido brand store page.

