



[Manuals.plus](#) /
› [iPormis](#) /
› iPormis Full Size Platform Bed Frame with Button Tufted Headboard - Instruction Manual

iPormis 620A1

iPormis Full Size Platform Bed Frame with Button Tufted Headboard

Model: 620A1 - Instruction Manual

[Introduction](#)[Safety Information](#)[Package](#)

[Contents](#)[Assembly](#)[Operating](#)[Maintenance](#)[Troubleshooting](#)[Specifications](#)[Support](#)

1. INTRODUCTION

Thank you for choosing the iPormis Full Size Platform Bed Frame. This manual provides essential instructions for the safe assembly, operation, and maintenance of your new bed frame. Please read this manual thoroughly before beginning assembly and retain it for future reference.



Image 1.1: The iPormis Full Size Platform Bed Frame with its button-tufted headboard, shown in a bedroom environment.

2. SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the product:

- Do not exceed the recommended weight limit of 1000 lbs.
- Avoid contact with liquids to prevent damage to fabric components.
- Ensure all wooden slats are securely fastened to prevent safety hazards and maintain structural integrity.
- Keep small parts away from children during assembly.
- Assemble on a soft, clean surface to prevent scratching the product or flooring.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 1 x Instruction Manual

- 1 x Metal Bed Frame (various sections)
- 1 x Wingback Headboard
- 12 x Wooden Slats
- Installation Tools & Accessories (screws, bolts, Allen wrench, etc.)

4. ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward and typically takes approximately 30 minutes with two people. All necessary tools are included.



Image 4.1: Overview of bed frame dimensions, weight capacity, and estimated assembly time.

Step-by-Step Assembly:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface. Refer to the included parts list to ensure all pieces are present.
2. **Assemble the Frame:** Connect the metal frame sections according to the diagrams in your separate instruction sheet. Ensure all bolts are finger-tightened initially.
3. **Attach the Headboard:** Secure the wingback headboard to the assembled frame. Ensure the button-tufted side faces outward.
4. **Install Wooden Slats:** Place the wooden slats across the frame. The slats feature Velcro attachments for stability and noise reduction. Press firmly to secure them.

5. **Tighten All Connections:** Once all components are in place, fully tighten all bolts and screws using the provided Allen wrench. Do not overtighten.



Image 4.2: Details of the sturdy metal frame, thick solid wood slats, and reinforced bed legs, highlighting structural components.



Velcro Slats Attached

Offer extre stability between slats and foudation plus easy installing

EVA Foam Mute Bars

Avoid direct contact between steel frame and wood slats plus noises eliminating



Image 4.3: Illustration of the Velcro-secured slats and EVA foam mute bars, designed to prevent noise and enhance stability.

5. OPERATING INSTRUCTIONS

Mattress Placement:

This platform bed frame does not require a box spring. Place your mattress directly onto the wooden slats. A mattress height of 8-12 inches is recommended for optimal comfort and aesthetic integration with the headboard.



SPECIFICATIONS

Size:	Full
Color:	Dark Grey
Material:	Fabric & Wood & Iron
Product Dimensions:	77*56*48in
Box Spring Required:	No
Weight Capacity:	1000 lbs
Package Content:	Bed frame & Instruction

Image 5.1: Recommended mattress height for proper fit and comfort.

Weight Capacity:

The bed frame is designed to support a maximum weight of 1000 lbs, including the mattress and occupants. Do not exceed this limit to ensure safety and product longevity.

Under-Bed Storage:

The frame provides 8 inches of clearance underneath, offering convenient space for storage. Utilize storage bins or containers to keep items organized and easily accessible.



Image 5.2: Visual representation of the 8-inch under-bed storage clearance.

6. MAINTENANCE

Fabric Care:

The upholstered components of this bed frame are designed for dry cleaning only. For minor spills, gently blot with a clean, dry cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the fabric.

Frame Care:

Periodically check all bolts and connections to ensure they remain tight. Retighten if necessary. Wipe metal and wood surfaces with a soft, damp cloth to remove dust. Avoid excessive moisture.

7. TROUBLESHOOTING

Squeaking Noises:

If you experience squeaking, ensure all assembly bolts are securely tightened. The bed frame incorporates Velcro-secured wooden slats and noise-reducing strips to minimize friction. Verify that these components

are correctly installed and free from debris.

Instability:

If the bed frame feels unstable, re-check all connections and ensure they are fully tightened. Confirm that the bed is placed on a level surface. Uneven flooring can affect stability.

Missing Parts:

In the event of missing parts, please refer to the 'Package Contents' section and contact iPormis customer support with your product model number and a description of the missing item(s).

8. SPECIFICATIONS



Image 8.1: Summary of product specifications.

Feature	Detail
Size	Full
Color	Dark Grey
Material	Fabric, Wood, and Steel
Product Dimensions	77"L x 54"W x 48"H
Under-Bed Clearance	8 inches
Weight Limit	1000 Pounds
Item Weight	70 Pounds
Upholstery Fabric Type	Linen
Assembly Required	Yes
Box Spring Needed	No

Special Features	8" Storage Space, Cosy Fabric, Elegant Wingback, Squeak Resistant, Strong Metal & Wood Structure
------------------	--

9. WARRANTY AND SUPPORT

For warranty information, product support, or to report missing/damaged parts, please contact iPormis customer service through the retailer's platform or visit the official iPormis website. Please have your model number (620A1) and purchase date available when contacting support.