



Manuals.plus /

› iPormis /

› iPormis Queen Size Platform Bed Frame with Button Tufted Headboard User Manual

## iPormis 620B2

# iPormis Queen Size Platform Bed Frame User Manual

Model: 620B2

## 1. PRODUCT OVERVIEW

---

The iPormis Queen Size Platform Bed Frame is designed to provide a comfortable, sturdy, and stylish foundation for your mattress. Featuring a button-tufted headboard with elegant wingback sides, solid wooden slats, and a noise-free design, this bed frame offers both aesthetic appeal and practical functionality, including ample underbed storage.



Figure 1: Overall view of the iPormis Queen Size Platform Bed Frame.

## 2. PACKAGE CONTENTS

---

Before beginning assembly, please ensure all parts are present and undamaged. Refer to the included instruction manual for a detailed parts list. The package should contain:

- 1 x Metal Bed Frame components
- 1 x Wingback Headboard
- 12 x Wooden Slats
- Installation Tools & Accessories (screws, wrench, etc.)
- 1 x Instruction Manual



## Velcro Slats Attached

Offer extre stability between slats and foudation plus easy installing

## EVA Foam Mute Bars

Avoid direct contact between steel frame and wood slats plus noises eliminating



Figure 2: Key components including Velcro slats for stability and EVA foam mute bars for noise reduction.



Figure 3: Illustration of the sturdy metal frame, thick solid wood slats, and reinforced bed legs.

### 3. SETUP GUIDE

---

Assembly of the iPormis bed frame is designed to be straightforward. Please follow these steps carefully to ensure proper and safe construction.

#### 3.1 Preparation

1. Unpack all components and lay them out on a clean, soft surface (e.g., a rug or blanket) to prevent scratches.
2. Identify all parts and hardware using the provided instruction manual's parts list.
3. Ensure you have enough space for assembly.

#### 3.2 Assembly Steps

1. **Attach Side Rails to Headboard:** Connect the side rails to the upholstered wingback headboard using

the designated bolts and tools. Ensure a secure fit.

2. **Assemble Footboard:** Attach the footboard to the other end of the side rails, securing it firmly.
3. **Install Center Support Bar:** Place and secure the central support bar, which provides additional stability for the mattress.
4. **Lay Wooden Slats:** Unroll or place the wooden slats across the bed frame. The slats are designed with Velcro to attach securely to the frame, preventing movement and noise. Ensure the EVA foam mute bars are properly positioned between the slats and the metal frame.
5. **Tighten All Connections:** Once all components are in place, double-check and tighten all bolts and screws to ensure maximum stability and safety.

**Important Safety Note: Do not exceed the weight limit of 800 lbs. Always follow the assembly instructions carefully to ensure the stability and safety of the bed frame. Two adults are recommended for assembly.**

## 4. USAGE GUIDELINES

Your iPormis bed frame is designed for optimal comfort and durability. Here are some guidelines for its use:

### 4.1 Mattress Compatibility

This platform bed frame does not require a box spring. It is designed to support your mattress directly on its wooden slats. We recommend a mattress height of 8-12 inches for optimal aesthetic and comfort.



Size:	Queen
Color:	Light Grey
Material:	Fabric & Wood & Iron
Product Dimensions:	82*62*48in
Box Spring Required:	No
Weight Capacity:	1000 lbs
Package Content:	Bed frame & Instruction

Figure 4: Recommended mattress height for the bed frame.

### 4.2 Headboard Features

The button-tufted headboard is upholstered with a soft, skin-friendly, and breathable linen fabric. The winged sides provide a convenient shelf on top, perfect for placing small items like glasses or a phone, enhancing both practicality and comfort.



## SOFT UPHOLSTERED WINGBACK HEADBOARD



Soft Cushion



Skin-Friendly



Breathable

Figure 5: Detail of the soft upholstered wingback headboard.



Figure 6: The headboard stands 48 inches tall, providing a prominent and comfortable backrest.

### 4.3 Underbed Storage

The bed frame offers 8 inches of clearance underneath, providing valuable space for storing household items. This feature is ideal for maximizing space in bedrooms with limited storage options.



Figure 7: Visual representation of the 8-inch under-bed storage space.

## 5. CARE AND MAINTENANCE

---

To ensure the longevity and appearance of your iPormis bed frame, please follow these care instructions:

- **Cleaning:** The upholstered fabric should be dry cleaned only. For minor spills, gently blot with a clean, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Regular Inspection:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten if necessary to maintain stability and prevent squeaks.
- **Avoid Excessive Moisture:** Keep the bed frame in a dry environment to prevent damage to the wood and fabric.
- **Weight Distribution:** Distribute weight evenly across the bed frame to prevent undue stress on any single point.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your bed frame, please refer to the following common solutions:

Problem	Possible Cause	Solution
Squeaking noises	Loose connections; slats rubbing against frame	Tighten all bolts and screws. Ensure wooden slats are properly seated and the EVA foam mute bars are in place.
Bed frame feels unstable	Incomplete or incorrect assembly; loose hardware	Review the assembly steps in Section 3.2. Ensure all connections are fully tightened. Verify all components are correctly aligned.
Headboard appears uneven	Improper attachment to side rails	Check the connection points between the headboard and side rails. Adjust and re-tighten as needed.

## 7. PRODUCT SPECIFICATIONS

---

Feature	Detail
Brand	iPormis
Model Number	620B2
Size	Queen
Color	Light Grey
Product Dimensions	82"L x 60"W x 48"H
Material	Fabric (Linen), Wood, Steel
Weight Capacity	Up to 800 LBS
Underbed Clearance	8 Inches
Box Spring Required	No
Assembly Required	Yes
Product Weight	48.6 pounds

