

## KOMFOTT 10196-T-F-Q-HU

# KOMFOTT Full Size Wood Platform Bed Frame User Manual

Brand: KOMFOTT | Model: 10196-T-F-Q-HU

## 1. PRODUCT OVERVIEW

---

The KOMFOTT Full Size Wood Platform Bed Frame with Headboard is designed to provide a sturdy and comfortable foundation for your mattress. Featuring solid rubber wood and engineered wood construction, this bed frame eliminates the need for a box spring, offering ample under-bed storage space and a noise-free sleeping experience. Its modern design and sleek lines make it a versatile addition to any bedroom.



A complete view of the assembled KOMFOTT Full Size Wood Platform Bed Frame in black, featuring a headboard and ample under-bed space.

## 2. SAFETY INFORMATION

---

Do not exceed the recommended weight limit of 550 lbs (250 kg) for the Full size bed frame. Always follow the assembly instructions carefully to prevent instability or collapse. Ensure all connections are securely tightened before use. Keep small parts away from children during assembly.


## 3. ASSEMBLY INSTRUCTIONS

---

The KOMFOTT bed frame is designed for straightforward assembly. Detailed instructions and all necessary accessories are included in the package. For best results, follow these general steps:

- 1. Unpack and Identify Parts:** Carefully unpack all components and lay them out. Refer to the parts list in your included manual to identify each piece and ensure nothing is missing. Pay close attention to part labels and screw types to avoid confusion.
- 2. Assemble the Headboard and Footboard:** Connect the headboard and footboard components as per the diagrams in your manual. Ensure all bolts are finger-tightened initially.
- 3. Attach Side Rails:** Connect the side rails to the assembled headboard and footboard.

4. **Install Center Support:** Secure the center support beam(s) and legs to the frame.
5. **Place Slats:** Unroll or individually place the wooden slats across the frame. Ensure they are properly seated and secured to the side rails. The slatted design means no box spring is needed; your mattress can be placed directly on top.
6. **Final Tightening:** Once all components are in place, systematically tighten all bolts and screws using the provided tools. Do not overtighten.



Sturdy Wooden  
Construction



Noise-free Sleep



Simple  
Maintenance



A clear view of the KOMFOTT Full Size Wood Platform Bed Frame in black, showing the wooden slats and overall structure before mattress placement.



A composite image illustrating key features: secured wooden slats for noise-free sleep, the durable integrated headboard, and the slatted platform design that eliminates the need for a box spring.

#### **4. OPERATING THE BED FRAME**

Once assembled, simply place your full-size mattress directly onto the wooden slats. The raised side rails are designed to keep the mattress securely in place, preventing shifting during use. No box spring is required for this platform bed frame.



## **Secured Slats**

No Squeaking Noise

## **Integrated Headboard**

Durable & impressive



## **Slatted Platform Bed**

No Box-spring Needed

This image demonstrates how a mattress fits directly onto the platform bed frame, secured by raised side rails.

## **5. MAINTENANCE**

---

To maintain the appearance and longevity of your KOMFOTT bed frame, regularly wipe it down with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish. Periodically check all bolts and connections to ensure they remain tight and secure.

## Accommodates Mattresses of Standard Size

The bedframe with raised side rails can keep the mattress in place.



An image showcasing the benefits of the bed frame, including its sturdy wooden construction, design for noise-free sleep, and ease of maintenance.

## 6. TROUBLESHOOTING

- **Bed Frame Feels Unsturdy/Wobbly:** Ensure all bolts and screws are fully tightened. Re-check each connection point according to the assembly instructions. Verify that the center support legs are properly aligned and making firm contact with the floor.
- **Slats Are Not Staying in Place:** Confirm that each slat is correctly positioned within the designated slots or supports on the side rails. If the slats are roll-out, ensure they are fully extended and secured.
- **Screws/Bolts Do Not Fit or Go Through Wood:** Double-check that you are using the correct hardware for each step as indicated in the assembly manual. Some screws may be designed for specific depths. If parts appear defective or misaligned, contact customer support for assistance.
- **Squeaking Noises:** Tighten all connections. If squeaking persists, you may apply a small amount of wax or lubricant to the contact points between the slats and the frame, or where metal parts meet.

## 7. SPECIFICATIONS

Feature	Detail
---------	--------

Size	Full
Product Dimensions	78"L x 56.5"W x 41.5"H
Special Feature	No Box Spring Needed
Color	Black
Included Components	Bed Frame, Headboard
Compatible With Mattress Size	Full
Brand	KOMFOTT
Assembly Required	Yes
Ground To Item Distance	5.5 Inches
Item Weight	65 pounds
Item Model Number	10196-T-F-Q-HU
UPC	798470510630



An illustration detailing the dimensions of the full-size bed frame: 78 inches long, 56.5 inches wide, and 41.5 inches high at the headboard.



This image highlights the 5.5-inch under-bed clearance, suitable for storage or easy cleaning.

## 8. WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your KOMFOTT bed frame, please contact KOMFOTT Customer Support. Refer to your purchase documentation for specific warranty details and contact information. Most products come with a standard manufacturer's warranty covering defects in materials and workmanship.