

VECELO bed-frames

VECELO Twin Size Bed Frame with Headboard - Instruction Manual

INTRODUCTION

Thank you for choosing the VECELO Twin Size Bed Frame. This manual provides essential information for the safe assembly, use, and maintenance of your new bed frame. Please read these instructions carefully before beginning assembly and retain them for future reference.

This bed frame features a sturdy metal construction with a rustic wooden headboard and footboard, designed for durability and style. It offers ample under-bed storage and is engineered for quiet, stable support without the need for a box spring.

IMPORTANT SAFETY INFORMATION

- For safe use, ensure all parts are firmly attached before assembly and use.
- Follow the instruction manual carefully during assembly.
- Do not exceed the maximum weight capacity of 450 lbs (Twin size).
- Keep children away from the bed frame during assembly and use.
- Regularly inspect the bed frame for any loose parts or damage.
- Do not stand on the bed frame.
- Use only on a flat, level surface.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x Bed frame (all structural components)
- 1 x Accessory Kit (includes all necessary screws, bolts, and tools)
- 1 x Instructions Manual (this document)

PRODUCT SPECIFICATIONS

Feature	Detail
Material	Wood & Metal
Bed Frame Color	Black & Brown
Size	Twin
Product Dimensions (L x W x H)	74.8" x 38.9" x 40"
Headboard Height	40"
Footboard Height	16.7"
Under-bed Clearance	13.7"
Max Load Capacity	450 lbs
Recommended Mattress Thickness	6"-12"
Assembly Required	Yes

Twin Size

Material
Wood,Metal

Dimensions
74.8"L x 38.9"W x 40"H

Weight Capacity
450lbs

ASSEMBLY INSTRUCTIONS

Before You Begin

- Clear an open space for assembly.
- Lay out all parts and hardware on a soft, clean surface to prevent scratches.
- Identify each part using the provided labels and the parts list in your accessory kit.
- Ensure all tools are readily available.



Image: All parts and tools included for assembly.

Step-by-Step Assembly

Step 1: Assemble the Headboard and Footboard

Attach the wooden panels to the metal headboard and footboard frames using the designated screws. Ensure all connections are secure but do not fully tighten screws until all parts are aligned.

Rustic Wooden Headboard

Made of high-quality wood board combined with metal frame to provide stable support, add style and function to your bedroom.



Image: Detail of the headboard assembly, showing the rustic wooden panel integrated into the metal frame.

Step 2: Connect Side Rails

Attach the side rails to the assembled headboard and footboard using the provided bolts. Make sure the side rails are correctly oriented with the slat supports facing inwards.



Image: Illustration of connecting the bed frame's side rails to the headboard and footboard sections.

Step 3: Install Center Support Legs

Attach the center support legs to the central beam of the bed frame. These legs provide additional stability and weight distribution.

Step 4: Place Metal Slats

Unroll or place the metal slats onto the side rail supports. Secure them using the provided fasteners. Ensure the EVA foam padding on the center slat is correctly positioned to minimize noise.



Image: Step-by-step visual guide for installing the metal slats onto the bed frame.

Durable Metal Bed Frame



Heavy-duty Metal Slats



Easy Assemble & Save Time



Embedded Design Prevents Slipping



Image: Detail of the durable metal slats, highlighting the embedded design for mattress stability and noise reduction features.

Step 5: Final Tightening

Once all parts are assembled and aligned, go back and fully tighten all screws and bolts using the provided Allen wrench. Do not overtighten.



Image: The completed bed frame assembly, ready for mattress placement.

Step 6: Place Mattress

Carefully place your twin-size mattress onto the assembled slats. The small tailgate at the foot of the bed helps keep the mattress securely in place.



Image: Visual guide for mattress placement, showing compatibility with various mattress types and recommended heights.

CARE AND MAINTENANCE

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. For the wooden headboard/footboard, use a dry cloth or a slightly damp cloth with a mild wood cleaner. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all bolts and screws to ensure they remain tight. Retighten if necessary to maintain stability and prevent squeaking.
- **Placement:** Avoid placing the bed frame in direct sunlight or near heat sources to prevent warping or fading of the wooden components.
- **Moving:** When moving the bed frame, lift it rather than dragging it to prevent damage to the legs or frame structure.

TROUBLESHOOTING

Common Issues and Solutions

- **Squeaking Noise:**
 - Ensure all bolts and screws are fully tightened.
 - Verify that the EVA foam padding on the center slat is correctly positioned to reduce friction between metal parts.
 - Check if the mattress is causing the noise; try removing it temporarily to isolate the source.
- **Mattress Sliding:**
 - Confirm the mattress is properly seated against the small tailgate at the foot of the bed.
 - Consider using a non-slip mattress pad between the mattress and the slats.
- **Instability/Wobbling:**
 - Recheck all connections and ensure they are securely tightened.
 - Ensure the bed frame is on a flat, level surface. Adjust leg levelers if applicable (not specified for this model, but a general tip).

WARRANTY AND CUSTOMER SUPPORT

VECELO products are designed for quality and durability. For any issues, questions, or concerns regarding your bed frame, please contact our customer support team. Our team is available to assist you with assembly, missing parts, or any other product-related inquiries.

Please refer to your purchase documentation for specific warranty details. Keep your proof of purchase for warranty claims.