

[Manuals.plus](#) /

› [KOMFOTT](#) /

› KOMFOTT 14-Inch Wood Platform Bed Frame Full Size Instruction Manual

KOMFOTT 63258-63259-63260-63261

KOMFOTT 14-Inch Wood Platform Bed Frame Instruction Manual

Model: 63258-63259-63260-63261 (Full Size, Natural)

Brand: KOMFOTT

1. INTRODUCTION

This manual provides essential instructions for the assembly, operation, and maintenance of your KOMFOTT 14-Inch Wood Platform Bed Frame. Please read this manual thoroughly before beginning assembly and retain it for future reference. Proper assembly and care will ensure the longevity and safe use of your bed frame.



Image 1.1: KOMFOTT 14-Inch Wood Platform Bed Frame (Full Size, Natural).

This image displays the complete KOMFOTT 14-inch Wood Platform Bed Frame in its natural finish, highlighting its minimalist design and the integrated wooden slat system.

2. SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.

- Assemble the bed frame on a soft, clean surface (e.g., carpet) to prevent scratches.
- Tighten all bolts and screws securely. Periodically check and re-tighten fasteners to maintain stability.
- Do not exceed the maximum weight capacity of 500 lbs (Full Size).
- Keep small parts away from children during assembly to prevent choking hazards.
- Do not jump on the bed frame.
- Use only the recommended mattress size for this frame.

3. PACKAGE CONTENTS

Please verify that all components and hardware are included in your package. If any items are missing or damaged, please contact customer support.

- Side Rails (2)
- End Rails (2)
- Center Support Beam(s)
- Support Legs (including center legs)
- Wooden Slats (14 sturdy plywood slats)
- Hardware Pack (bolts, washers, Allen wrench)
- Assembly Instructions



Image 3.1: Detail of solid rubber wood construction and support feet.

This image highlights the solid rubber wood material used for the frame, the robust support feet designed for stability, and the secure, tight connections between components, ensuring a durable structure.

4. SETUP AND ASSEMBLY

Assembly typically requires two adults and takes approximately 30-60 minutes. All necessary tools are included.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent damage. Identify each component using the parts list.
2. **Assemble Frame Sides:** Attach the side rails to the end rails using the provided bolts and Allen wrench. Do not fully tighten bolts until the entire frame is assembled.
3. **Install Center Support:** Secure the center support beam(s) and any associated support legs to the frame. Ensure these are properly aligned to provide even weight distribution.
4. **Place Slats:** Lay the wooden slats across the frame. The slats are designed with hook and loop fasteners (Velcro) to secure them in place and prevent shifting. Ensure they are evenly spaced and firmly attached to the side rails.
5. **Final Tightening:** Once all components are in place and aligned, fully tighten all bolts and screws. Do not overtighten.

6. **Apply Mattress Retaining Stickers:** If included, apply the mattress retaining stickers to the slats or frame to prevent the mattress from sliding.



Image 4.1: Detail of the slat system and mattress retention features.

This image illustrates the design of the 14 sturdy plywood slats, which feature hook and loop fasteners for secure and easy installation. It also highlights that a box spring is not required and mentions the inclusion of mattress retaining stickers to prevent mattress movement.

5. OPERATING INSTRUCTIONS

Your KOMFOTT platform bed frame is designed for direct mattress placement, eliminating the need for a box spring.

- **Mattress Placement:** Carefully place your latex, spring, or memory foam mattress directly onto the assembled wooden slats. Ensure the mattress is centered on the frame.
- **Weight Capacity:** The Full size bed frame has a maximum weight capacity of 500 lbs. Do not exceed this limit to ensure structural integrity and safety.
- **Underbed Storage:** The frame provides approximately 10.5 inches of clearance underneath, offering ample space for storage containers or allowing for easy cleaning with a robot vacuum.

Ample Space Underneath the Bed



Add to storage capacity, contributing to easy floor cleaning



Image 5.1: Underbed storage space and clearance.

This image demonstrates the practical underbed storage capability, highlighting the 10.5-inch clearance. This space is suitable for storing various items in boxes or for convenient floor cleaning by a robot vacuum.

6. MAINTENANCE

- **Cleaning:** Wipe the wood frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Fastener Check:** Periodically (e.g., every 3-6 months) check all bolts and screws to ensure they remain tight. Re-tighten if necessary to maintain stability and prevent squeaking.
- **Avoid Excessive Moisture:** Protect the wood from prolonged exposure to moisture or extreme temperature changes.

7. TROUBLESHOOTING

- **Squeaking Noises:** If the frame squeaks, check all connections and tighten any loose bolts. Ensure slats are properly seated and not rubbing against the frame.
- **Instability/Wobbling:** Verify that all legs are making full contact with the floor and that all fasteners are

securely tightened. Ensure the frame is assembled on a level surface.

- **Mattress Sliding:** Ensure the mattress retaining stickers (if provided and applied) are functioning. If not, consider using a non-slip mattress pad.

8. SPECIFICATIONS

Feature	Detail
Brand	KOMFOTT
Model Number	63258-63259-63260-63261
Size	Full
Color	Natural
Product Dimensions (L x W x H)	74.5" x 53.5" x 14"
Recommended Mattress Size	75" x 54" (Not Included)
Weight Limit	500 lbs
Item Weight	43 lbs
Material	Solid Rubber Wood, Poplar Wood Slats
Underbed Clearance	10.5 Inches
Assembly Required	Yes
Special Feature	No Box Spring Needed



Image 8.1: Product specifications overview.

This graphic provides a comprehensive overview of the bed frame's specifications, including its dimensions, the recommended mattress size, and the maximum weight limit for various bed sizes (Twin, Full, Queen, King).

9. WARRANTY INFORMATION

This KOMFOTT bed frame comes with a limited warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or contact KOMFOTT customer support directly.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing or damaged parts, please contact KOMFOTT customer support. Refer to the contact information provided in your product packaging or visit the official KOMFOTT website for support options.

