

[Manuals.plus](#) /

› [KOMFOTT](#) /

› KOMFOTT 14-Inch Natural Wood Platform Bed Frame, Twin Size Instruction Manual

KOMFOTT 63258-63259-63260-63261

KOMFOTT 14-Inch Natural Wood Platform Bed Frame, Twin Size Instruction Manual

Model: 63258-63259-63260-63261

INTRODUCTION

Thank you for choosing the KOMFOTT 14-Inch Natural Wood Platform Bed Frame. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed frame. Please read these instructions carefully before assembly and retain them for future reference.

This platform bed frame is designed for a Twin size mattress and features a sturdy construction of solid rubber wood and poplar wood slats. It offers 14 inches of under-bed storage space and eliminates the need for a box spring.



Image: The KOMFOTT 14-Inch Natural Wood Platform Bed Frame, Twin Size, shown fully assembled in a bedroom with a mattress and bedding.

SAFETY INFORMATION

For safe use, assemble the bed frame strictly according to the instructions provided. Ensure all connections are secure before use. This bed frame is designed to support a maximum weight capacity of 250 lbs for the Twin size. Do not exceed this weight limit. Avoid standing or jumping on the bed frame, as this could lead to instability or collapse and potential injury. Regularly check all bolts and screws to ensure they remain tight. Keep small parts away from children during assembly.

PACKAGE CONTENTS

Before beginning assembly, verify that all components and hardware are present. If any parts are missing or damaged, please contact customer support.

- Headboard/Footboard (if applicable, though this model is a simple platform)
- Side Rails
- Center Support Legs
- Wood Slats (14 pieces)

- Hardware Pack (bolts, washers, nuts, Allen wrench)
- Assembly Instructions

Ample Space Underneath the Bed



Add to storage capacity, contributing to easy floor cleaning



Image: Components of the bed frame, highlighting the 14 sturdy plywood slats with hook and loop fasteners and mattress retaining stickers.

ASSEMBLY INSTRUCTIONS

Assembly is straightforward and typically takes minutes. It is recommended to assemble the bed frame with two people. Ensure you have enough space and a clean, soft surface to prevent scratching components.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface. Check against the package contents list.
2. **Attach Side Rails:** Connect the side rails to the headboard and footboard sections using the provided bolts and Allen wrench. Do not fully tighten bolts until all major components are connected.
3. **Install Center Support:** Attach any center support legs or beams as indicated in the diagram. These are crucial for stability.
4. **Place Slats:** Lay the wooden slats across the bed frame. Many slats feature hook and loop fasteners to secure them to the frame, preventing movement. Ensure slats are evenly spaced.

5. **Tighten All Connections:** Once all components are in place, go back and securely tighten all bolts and screws. Do not overtighten.
6. **Apply Mattress Retainers (Optional):** If included, apply the mattress retaining stickers or strips to the top of the slats or frame to prevent the mattress from slipping.



Image: Detailed view of the bed frame's construction, showing solid rubber wood, robust support feet, and secure connections, which are key for assembly.

OPERATING INSTRUCTIONS

This platform bed frame is designed to be used without a box spring. Place your Twin size mattress directly onto the wooden slats. The dense wood slats provide ample support for various mattress types, including latex, spring, or memory foam.

- **Mattress Placement:** Carefully place your Twin size mattress on top of the assembled slats. Ensure it is centered and aligned with the frame.
- **Weight Capacity:** The Twin size bed frame has a weight limit of 250 lbs. Do not exceed this limit to ensure structural integrity and safety.
- **Under-Bed Storage:** Utilize the 14 inches of clearance beneath the frame for storage. This space is also suitable for robot vacuum cleaners.

Specifications



	Bed Dimensions	Recommended Mattress (Not Included)	Weight Limit
Twin	74.5" x 38" x 14"	75" x 39"	250 lbs
Full	74.5" x 53.5" x 14"	75" x 54"	500 lbs
Queen	80" x 60" x 14"	80" x 60"	500 lbs
King	80" x 76" x 14"	80" x 76"	500 lbs

Image: The KOMFOTT bed frame in a room, illustrating the available under-bed storage space and how a mattress sits directly on the slats.

MAINTENANCE

Regular maintenance will help prolong the life of your bed frame and ensure continued safety.

- **Cleaning:** Wipe the wood surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Check Connections:** Periodically (e.g., every 3-6 months) inspect all bolts and screws. Tighten any that have become loose.
- **Slat Inspection:** Ensure all wooden slats are securely in place and show no signs of damage or cracking. Replace any damaged slats immediately.

TROUBLESHOOTING

If you encounter any issues with your bed frame, refer to the following common solutions:

- **Squeaking Noises:**
 - Ensure all bolts and screws are tightly secured.

- Check if slats are properly seated and not rubbing against the frame.
- Verify the mattress is not causing the noise by temporarily removing it.
- **Instability/Wobbling:**
 - Re-tighten all assembly hardware.
 - Ensure the bed frame is on a level surface.
 - Confirm all support legs are making firm contact with the floor.
- **Mattress Slipping:**
 - Ensure mattress retaining stickers (if provided) are properly applied.
 - Consider placing a non-slip mat between the mattress and the slats.

SPECIFICATIONS

Feature	Detail
Brand	KOMFOTT
Model Number	63258-63259-63260-63261
Size	Twin
Color	Natural
Product Dimensions (L x W x H)	74.5" x 38" x 14"
Frame Material	Rubberwood
Slat Material	Poplar Wood
Weight Limit	250 Pounds
Item Weight	43 Pounds
Under-Bed Clearance	14 Inches
Assembly Required	Yes
Special Feature	No Box Spring Needed



Solid Rubber Wood Material



6 Robust Support Feet



Tight Connection



Image: Detailed specifications table outlining bed dimensions, recommended mattress sizes, and weight limits for various bed frame sizes.

WARRANTY AND SUPPORT

This KOMFOTT bed frame comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your product or contact KOMFOTT customer service directly.

If you require assistance with assembly, have questions about product features, or need to report missing/damaged parts, please contact KOMFOTT customer support. Contact information can typically be found on the packaging, in the included documentation, or on the official KOMFOTT website.

For online purchases, you may also refer to your order details for seller contact information.