

Acme BD00660Q

Acme Katia Queen Bed Instruction Manual

Model: BD00660Q

Brand: Acme

1. INTRODUCTION

This manual provides detailed instructions for the assembly, use, and maintenance of the Acme Katia Queen Bed, Model BD00660Q. The Katia Queen Bed features a modern rustic design with a white frame and gray linen upholstered headboard and footboard. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

2. SAFETY INFORMATION

- Always use with a box spring for proper mattress support and bed stability.
- Exercise caution during assembly and use to avoid injury from sharp edges or heavy components.
- Due to the weight of the components, it is recommended that assembly be performed by two adults.
- Ensure all fasteners are securely tightened before using the bed. Periodically check and re-tighten as needed.
- Do not allow children to climb on or play with the bed frame during or after assembly.

3. PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, contact Acme customer support.

- One (1) Queen Bed Headboard
- One (1) Queen Bed Footboard
- Two (2) Queen Bed Side Rails
- One (1) Four-piece Slat Kit with eight (8) support legs



Image: Main components of the Acme Katia Queen Bed frame, including the headboard, footboard, and side rails, ready for assembly. The gray linen upholstered panels contrast with the white frame.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Acme Katia Queen Bed is required. Follow these general steps for proper construction. Specific hardware and detailed diagrams are typically included in a separate assembly guide within the product packaging.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Attach Side Rails to Headboard:** Connect the side rails to the headboard using the provided hardware. Ensure connections are secure but do not fully tighten bolts until all major components are assembled.
3. **Attach Side Rails to Footboard:** Connect the other end of the side rails to the footboard. Align all holes and insert hardware.
4. **Install Slat Kit:** Place the four-piece slat kit within the bed frame. Ensure the support legs are properly attached to the slats and positioned to provide even support across the frame.
5. **Final Tightening:** Once all components are in place and aligned, fully tighten all bolts and screws. Do not overtighten.
6. **Position Bed:** Carefully move the assembled bed frame to its desired location.



Image: A side view of the assembled Acme Katia Queen Bed, showing a mattress and bedding in place. This illustrates the bed's profile and how a mattress sits within the frame.

5. OPERATING INSTRUCTIONS

The Acme Katia Queen Bed is designed to accommodate a standard queen-sized mattress. A box spring is required for proper mattress support and to ensure the longevity and stability of the bed frame. Place your box spring directly onto the installed slat kit, followed by your queen-sized mattress.



Image: This image presents the Acme Katia Queen Bed as part of a complete bedroom set, showcasing its aesthetic within a decorated room. It highlights the bed's design and scale in a typical environment.

6. MAINTENANCE

- **Regular Inspection:** Periodically inspect all bolts, screws, and connections to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Cleaning Frame:** Dust the white frame with a soft, dry cloth. For more stubborn marks, use a slightly damp cloth with a mild, non-abrasive cleaner, then wipe dry immediately.
- **Cleaning Upholstery:** For the gray linen upholstered panels, gently vacuum to remove dust and debris. For spills, blot immediately with a clean, dry cloth. For deeper cleaning, use a fabric cleaner specifically designed for linen, following the product's instructions. Test on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals on any part of the bed, as these can damage the finish or fabric.

7. TROUBLESHOOTING

- **Squeaking Noises:** If the bed produces squeaking noises, ensure all assembly bolts and screws are securely tightened. Verify that the slat kit is correctly installed and evenly distributed. Confirm that a box spring is in use, as it is essential for preventing excessive movement and potential noise.
- **Instability/Wobbling:** Check that the bed is placed on a level surface. Re-examine all assembly connections to ensure they are firm. Confirm that the slat support legs are making proper contact with the floor.
- **Parts Missing/Damaged:** If you discover missing or damaged parts during unpacking or assembly, do not proceed with assembly. Contact Acme customer support immediately for assistance.

8. SPECIFICATIONS

Feature	Detail
Model Number	BD00660Q
Brand	Acme
Size	Queen
Product Dimensions (L x W x H)	88"L x 65"W x 62"H
Color	Light Gray and White
Finish Type	Painted (Soft White Finish)
Materials	Poplar, Linen, Foam
Item Weight	152 pounds
Assembly Required	Yes
Box Spring Required	Yes
UPC	840412309700
Manufacturer	Acme Furniture

9. WARRANTY AND SUPPORT

For information regarding product warranty, replacement parts, or technical support, please contact Acme Furniture directly. It is recommended to retain your purchase receipt as proof of purchase when contacting customer service.

Acme Furniture Contact Information: Please refer to the contact details provided with your product packaging or visit the official Acme Furniture website for the most current support information.