

SPEDWHEL ES2 ES3 ES4

SPEDWHEL Ninebot ES2 ES3 ES4 Electric Scooter Foot Pad Instruction Manual

Model: ES2, ES3, ES4

1. INTRODUCTION

This manual provides detailed instructions for the installation, maintenance, and care of your SPEDWHEL Original Foot Pad, designed for Ninebot ES2, ES3, and ES4 electric scooters. Please read this manual thoroughly before installation to ensure proper use and longevity of the product.

2. SAFETY INFORMATION

- Ensure the scooter is powered off and disconnected from any charging source before beginning installation.
- Wear appropriate safety gear, such as gloves, to protect your hands during installation.
- Keep small parts away from children.
- Dispose of old parts responsibly according to local regulations.
- If you are unsure about any step, seek professional assistance.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x SPEDWHEL Original Foot Pad (for Ninebot ES2/ES3/ES4)

4. INSTALLATION GUIDE

Follow these steps to replace the foot pad on your Ninebot ES2, ES3, or ES4 electric scooter.

4.1. Preparation

1. Park your scooter on a stable, flat surface.
2. Turn off the scooter and remove the key (if applicable).

3. Clean the surface of the existing foot pad and surrounding area to remove any dirt or debris.

4.2. Removing the Old Foot Pad

1. Carefully peel off the old foot pad from the scooter deck. You may need a plastic pry tool or a similar non-abrasive instrument to gently lift the edges.
2. Once the old foot pad is removed, thoroughly clean the scooter deck surface. Ensure it is free of any adhesive residue, dirt, or grease. A degreaser or rubbing alcohol can be used for this step. Allow the surface to dry completely.

4.3. Installing the New Foot Pad

1. Align the new SPEDWHEEL foot pad with the scooter deck to ensure proper fitment before removing the adhesive backing.



Figure 1: Top view of the SPEDWHEEL foot pad, illustrating its textured surface and specific cutouts designed for Ninebot ES2, ES3, and ES4 electric scooters.

2. Carefully peel off a small portion of the protective backing from one end of the new foot pad, exposing the adhesive.



Figure 2: Close-up view of the foot pad, showing the protective white backing being peeled back to reveal the adhesive layer underneath.

3. Align the exposed adhesive portion with the corresponding area on the scooter deck. Press down firmly to secure it.
4. Slowly continue to peel off the remaining protective backing while simultaneously pressing the foot pad onto the scooter deck. Work from one end to the other, ensuring no air bubbles are trapped underneath.
5. Once fully applied, press firmly over the entire surface of the foot pad, paying extra attention to the edges, to ensure maximum adhesion.
6. Allow the adhesive to cure for at least 24 hours before riding the scooter. Avoid exposing the scooter to moisture during this curing period.

5. OPERATING AND USAGE

The foot pad provides a non-slip surface for improved grip and comfort during scooter operation. Ensure your feet are placed securely on the pad while riding.

- Always maintain proper foot placement for balance and control.
- Avoid standing on the very edges of the foot pad, as this may reduce stability.

6. MAINTENANCE

- **Cleaning:** Regularly wipe the foot pad with a damp cloth to remove dirt and debris. For stubborn stains, a mild soap solution can be used. Avoid harsh chemicals or abrasive cleaners, as these may damage the surface.
- **Inspection:** Periodically inspect the foot pad for signs of wear, peeling edges, or damage. If the foot pad shows significant wear or begins to peel, consider replacing it to maintain optimal grip and safety.
- **Storage:** When not in use, store the scooter in a dry, cool place away from direct sunlight to prolong the life of the foot pad and other components.

7. TROUBLESHOOTING

- **Foot Pad Not Sticking Properly:**
 - Ensure the scooter deck surface was thoroughly cleaned and dry before installation. Any residue (dirt, grease, old adhesive) will prevent proper adhesion.
 - Apply firm, even pressure across the entire surface during installation.
 - Allow the recommended curing time (24 hours) before use.
- **Edges Peeling:**
 - Re-apply pressure to the peeling edges. If peeling persists, a small amount of strong adhesive designed for outdoor use may be applied carefully to the underside of the edge, then pressed firmly.
 - Consider replacing the foot pad if peeling is extensive or affects safety.

8. SPECIFICATIONS

Product Name	SPEDWHEL Original Foot Pad
Compatible Models	Ninebot ES2, ES3, ES4 Electric Scooters
Brand	SPEDWHEL
Material	Durable, textured material with adhesive backing
Number of Pieces	1
UPC	784154442366
Finish Type	Powder coated (referring to the scooter deck, not the pad itself)

9. WARRANTY INFORMATION

This product is covered by the standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact SPEDWHEL customer support directly. Keep your proof of purchase for warranty claims.

10. SUPPORT

For technical assistance, troubleshooting, or any questions regarding your SPEDWHEL Original Foot Pad, please contact our customer support team:

- **Manufacturer:** SPEDWHEL
- **Website:** Visit [SPEDWHEL on Amazon](#) (for general product inquiries)
- *Please refer to your purchase documentation for direct contact information, such as email or phone number.*

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question