

ModernLuxe WF299308AAP-MZJ

ModernLuxe Twin Size Loft Bed with Storage and Shelves - Espresso

Model: WF299308AAP-MZJ

1. INTRODUCTION

Thank you for choosing the ModernLuxe Twin Size Loft Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new loft bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

This loft bed features a sturdy pine wood frame, integrated storage boxes, shelves, and a unique climbing frame design. It is designed to provide a functional and space-saving sleeping solution.

2. SAFETY INFORMATION

- Always follow assembly instructions precisely. Incorrect assembly can lead to instability and injury.
- Ensure all bolts and connectors are securely tightened before use and check periodically.
- Do not allow children under 6 years of age on the upper bunk.
- Use only a mattress that meets the recommended thickness of 6 inches to ensure proper guardrail height.
- The maximum weight capacity for this loft bed is 175 LBS. Do not exceed this limit.
- Prohibit horseplay on or under the bed.
- Always use the climbing frame for access to the bed. Do not use other furniture or objects to climb onto the bed.
- Keep all small parts out of reach of children during assembly.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Loft Bed Frame Components (Plywood, MDF, Pine wood)
- Bed Slats (Plywood)

- 2 Storage Boxes with Casters
- Assembly Hardware (bolts, screws, etc.)
- Assembly Tools (Screwdriver)

4. SETUP AND ASSEMBLY INSTRUCTIONS

Partial assembly is required for this loft bed. It is recommended that two people assemble the bed to ensure safety and efficiency. Estimated assembly time is approximately 30 minutes. A screwdriver is included for assembly. **Do not use power tools** as they may overtighten screws and damage the wood.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all parts using the provided parts list (refer to the separate assembly guide for detailed diagrams).
3. Begin by assembling the main bed frame structure, ensuring all connections are finger-tight before final tightening.
4. Attach the climbing frame and guardrails securely to the bed frame.
5. Install the bed slats evenly across the bed frame.
6. Assemble the two storage boxes and attach their casters. Position them beneath the bed as desired.
7. Once fully assembled, ensure all bolts and screws are tightened. Do not overtighten.



Figure 4.1: Overall dimensions of the loft bed, including height, length, and width of the bed frame and integrated storage units.



Figure 4.2: The loft bed featuring the pull-out desk and open storage drawers, demonstrating functional space utilization.

5. OPERATING INSTRUCTIONS (USAGE)

- **Sleeping Area:** Place a twin-size mattress (recommended thickness 6 inches) on the bed slats. Ensure the mattress fits snugly within the frame.
- **Climbing Frame:** Use the integrated climbing frame to safely access the upper bunk. The climbing rope can be used for additional physical activity.
- **Chalkboards:** The three sides of the loft bed are equipped with double-sided chalkboards. Use standard chalk to draw or write. A chalk slot is provided for convenience.
- **Storage Boxes:** Utilize the two included storage boxes for organizing toys, books, or other items. The casters allow for easy movement, and they can be locked in place beneath the bed.
- **Slide:** The bed includes a slide for exiting the bed. Ensure the area around the slide is clear before use. The smooth MDF surface provides a safe sliding experience.



Figure 5.1: The ModernLuxe loft bed in a typical room setting, showcasing its design and integrated features.



Figure 5.2: Detailed view of the storage drawers and open shelving units, highlighting their accessibility and capacity.

6. MAINTENANCE

- **Cleaning:** Wipe the wood surfaces with a clean, damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the finish. For chalkboards, use a damp cloth or chalkboard eraser.
- **Hardware Check:** Periodically check all bolts, screws, and connectors to ensure they remain tight. Retighten as necessary to maintain stability.
- **Wood Care:** Protect the wood from direct sunlight and extreme temperature changes to prevent warping or fading.

7. TROUBLESHOOTING

- **Bed feels wobbly:** Ensure all assembly hardware is securely tightened. Check that the bed is placed on a level surface.
- **Drawers not sliding smoothly:** Check for any obstructions in the drawer glides. Ensure the casters on the storage boxes are clean and free of debris.
- **Squeaking noises:** Identify the source of the squeak. Often, retightening bolts or applying a small amount of lubricant to metal-on-metal contact points can resolve this.
- **Missing parts:** If you discover missing parts during assembly, do not proceed. Contact customer support immediately for assistance.

8. SPECIFICATIONS

Product Type	Loft Bed
Size	Twin
Color	Espresso
Overall Product Dimensions	78.5"L x 79.2"W x 34"H
Product Material	Plywood + MDF + Pine wood
Bed Slat Material	Plywood
Weight Capacity	175 LBS
Recommended Mattress Thickness	6 inches
Level of Assembly	Partial Assembly
Estimated Assembly Time	30 minutes
Suggested Number of People for Assembly	2
Additional Tools Required	Screwdriver (included)
Country of Origin	Vietnam
Model Number	WF299308AAP-MZJ
UPC	195358565049

9. WARRANTY INFORMATION

This ModernLuxe Loft Bed comes with a one-year warranty against manufacturing defects. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper assembly, misuse, abuse, accidents, or normal wear and tear.

To make a warranty claim, please retain your proof of purchase and contact customer support with details of the issue.

10. CUSTOMER SUPPORT

For any questions, missing parts, or assistance with assembly or operation, please contact ModernLuxe customer support. Have your model number (WF299308AAP-MZJ) and proof of purchase ready when contacting support.

Contact information can typically be found on the product packaging or the retailer's website where the product was purchased.