Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BOFENG 972F-RB

BOFENG Full Size Bed Frame with Storage Headboard and Charging Station

Model: 972F-RB

Product Overview

The BOFENG Full Size Bed Frame (Model 972F-RB) is designed for durability and convenience, featuring a rustic brown finish and a grey linen-like fabric upholstered headboard. It includes a built-in storage shelf and a charging station. This platform bed frame eliminates the need for a box spring, providing strong steel slat support for various mattress types.

- **Rustic Design:** Farmhouse-style headboard with grey linen-like fabric and vintage brown wooden shelf.
- **Integrated Storage & Charging:** 2-tier headboard shelf for essentials and a built-in charging station with 2 AC outlets and 2 USB ports.
- **Robust Construction:** Made from P2 grade MDF and heavy-duty steel slats, supporting up to 800 lbs.
- **Noise-Free Operation:** Reinforced triangular structure and non-slip tape on slats minimize squeaks and wobbling.
- **Under-Bed Clearance:** Provides ample space beneath the frame for additional storage.

Safety Information

Please read and follow all safety instructions carefully before assembly and use to prevent injury or damage to the product.

- Always follow the assembly instructions precisely to ensure stability and prevent collapse.
- Exercise caution around sharp edges during assembly to avoid injury.
- Do not exceed the maximum weight recommendation of 800 pounds.
- Ensure all bolts and screws are securely tightened before use and periodically check for looseness.
- Keep children away from the assembly area and small parts.

Setup and Assembly

The BOFENG Full Size Bed Frame is designed for straightforward assembly. All necessary parts and tools are included in the package. Please follow the provided installation manual for detailed step-by-step instructions.

Preparation

- Unpack all components and verify against the parts list in the manual.
- Ensure you have sufficient space for assembly.

- Keep all small parts, such as screws and bolts, organized.

Assembly Steps

1. Begin by assembling the headboard and footboard sections as per the manual.
2. Attach the side rails to the headboard and footboard.
3. Install the central support beams and legs.
4. Place the steel slats onto the frame, ensuring they are properly secured and the non-slip tape is engaged.
5. Connect the charging station components to the headboard.
6. Tighten all connections securely, but do not overtighten.



Figure 1: Assembled bed frame structure without mattress.

This image illustrates the complete bed frame structure before a mattress is placed, highlighting the metal frame and rustic brown wooden accents.



Figure 2: Detail of the double reinforced connection for enhanced stability.

This close-up shows the double reinforced connection points, which contribute to the bed frame's overall strength and stability, minimizing wobbling and noise.



Figure 3: Components of the bed frame, including the upholstered headboard, the robust metal slat system, and the rustic brown footboard.

This image provides a detailed look at the various components, including the upholstered headboard, the robust metal slat system, and the rustic brown footboard, essential for proper assembly.

Operating Instructions

Using the Charging Station

The integrated charging station in the headboard provides convenient power access for your electronic devices.

- Locate the power cord (9.8ft) extending from the headboard.
- Plug the power cord into a standard wall outlet.
- Use the 2 AC outlets to power devices like lamps or laptops.
- Use the 2 USB ports to charge smartphones, tablets, and other USB-powered devices.



Figure 4: Detail of the headboard's integrated charging station.

This image shows the charging station built into the headboard, featuring two AC outlets and two USB ports, ready for device connection.

Utilizing the Storage Headboard

The 2-tier storage headboard provides a convenient surface for bedside items.

- Place small items such as phones, glasses, books, or decorative items on the wooden shelf.
- Avoid placing heavy or oversized objects that could damage the shelf or pose a safety risk.

Under-Bed Storage

The bed frame offers approximately 10.63 inches of clearance, suitable for storing various items in bins or containers.



Figure 5: Illustration of available under-bed storage space.

This image demonstrates the generous clearance beneath the bed frame, ideal for placing storage boxes or other items to maximize bedroom space.

Maintenance

Proper maintenance ensures the longevity and appearance of your bed frame.

- **Cleaning:** Wipe the metal and wooden surfaces with a dry cloth. For upholstered parts, use a soft, damp cloth and mild soap if necessary, then blot dry. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically inspect all bolts and screws to ensure they remain tight. Re-tighten if any looseness is detected to maintain stability and prevent squeaking.
- **Weight Distribution:** Ensure weight is evenly distributed across the bed frame to prevent stress on individual slats or frame components.

Troubleshooting

Refer to this section for solutions to common issues.

Squeaking or Wobbling

- **Solution:** Check all bolts and screws. Tighten any loose connections. Ensure all slats are properly seated and the non-slip tape is making contact with the mattress. The reinforced triangular structure is designed to prevent noise, so ensure it is correctly assembled.

Charging Station Not Working

- **Solution:** Verify that the bed frame's power cord is securely plugged into a functional wall outlet. Check if the wall outlet itself is receiving power by testing it with another device. Ensure devices are properly connected to the AC outlets or USB ports.

Missing or Damaged Parts

- **Solution:** If you find any parts missing or damaged upon unboxing, please contact BOFENG customer support immediately for assistance. Refer to the parts list in your assembly manual.

Specifications

Feature	Detail
Model Number	972F-RB
Size	Full
Product Dimensions (L x W x H)	76.93" x 54.53" x 38.78"
Material	Engineered Wood (MDF), Metal (Alloy Steel)
Headboard Material	MDF with Fabric Upholstery
Color	Rustic Brown/Grey
Maximum Weight Recommendation	800 Pounds
Special Features	No Box Spring Needed, Pre-drilled Holes, Squeak Resistant, With Power Outlets (2 AC, 2 USB)
Ground to Item Distance	10.63 Inches
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth



Figure 6: Dimensional diagram of the bed frame.

This diagram provides key measurements of the bed frame, including length, width, height, and under-bed clearance, to assist with planning and placement.

Warranty and Support

For warranty information, product support, or to report missing/damaged parts, please contact BOFENG customer service. Refer to your purchase documentation for specific contact details or visit the official BOFENG website.

Manufacturer: BOFENG

© 2026 BOFENG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CCV5L4SV

More documents and user manuals: **https://manuals.plus/**