

JURMERRY 16

JURMERRY Metal Bed Frame 150 x 200 Instruction Manual

Model: 16

1. INTRODUCTION

Thank you for choosing the JURMERRY Metal Bed Frame. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed frame. Please read these instructions carefully before beginning assembly and retain them for future reference.

This bed frame is designed for stability and durability, featuring a metal frame with a wooden headboard and footboard accent. It is suitable for various bedroom environments and does not require a box spring.

2. SAFETY INFORMATION

- Always assemble the bed frame on a soft, clean surface to prevent damage to components.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight capacity of 200 kg (440 lbs).
- Keep small parts away from children during assembly to prevent choking hazards.
- Avoid standing or jumping on the bed frame.
- Use only the mattress size compatible with this frame (150 x 200 cm).

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Headboard
- Footboard
- Side Rails (Metal)
- Bed Slats (Metal)
- Support Legs
- Hardware Pack (bolts, screws, washers, Allen wrench)
- Assembly Instructions Manual

4. SETUP AND ASSEMBLY

Assembly of the JURMERRY Metal Bed Frame is designed to be straightforward. Tools required for assembly are included in the package. For detailed, step-by-step instructions, please refer to the specific assembly manual provided within your product packaging.

General Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface. Identify each component using the parts list in your included manual.
2. **Attach Side Rails:** Connect the side rails to the headboard and footboard using the provided hardware. Ensure all connections are firm but do not fully tighten bolts until the frame is fully assembled.
3. **Install Support Legs:** Attach any central support legs to the frame as indicated in your manual.
4. **Place Bed Slats:** Position the metal bed slats across the frame. Secure them according to the instructions, ensuring even spacing and firm attachment.
5. **Final Tightening:** Once all components are in place and aligned, fully tighten all bolts and screws. Do not overtighten.
6. **Position Bed Frame:** Carefully move the assembled bed frame to its desired location.

Note: Two people are recommended for assembly to ensure ease and safety.



Figure 4.1: Product dimensions for the JURMERRY Metal Bed Frame. This image illustrates the overall length, width, headboard height, footboard height, and under-bed storage clearance.



Figure 4.2: Front view of the bed frame, highlighting the design of the headboard and footboard with integrated wooden panels and the metal slat system.

5. OPERATING AND USAGE

Once assembled, the JURMERRY Metal Bed Frame is ready for use. Place your mattress directly onto the metal slats. A box spring is not required for this bed frame.

- **Mattress Placement:** Carefully place your 150 x 200 cm mattress onto the bed slats. Ensure it is centered and lies flat.
- **Under-Bed Storage:** The frame provides approximately 27 cm (10.6 inches) of clearance, offering valuable space for storage bins or other items.
- **Weight Distribution:** For optimal longevity, distribute weight evenly across the bed surface.



Figure 5.1: The JURMERRY bed frame in a bedroom, illustrating its appearance with a mattress and bedding.

6. MAINTENANCE

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. For the wooden panels, use a dry or slightly damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Regular Checks:** Periodically inspect all bolts and connections to ensure they remain tight. Retighten if necessary to maintain stability and prevent creaking.
- **Rust Prevention:** The frame features an environmentally friendly paint process for good rust prevention. Avoid prolonged exposure to moisture.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed frame creaks	Loose bolts or connections. Uneven floor surface.	Check and tighten all bolts. Ensure the bed is on a level surface; use shims if necessary.

Problem	Possible Cause	Solution
Frame feels unstable	Incomplete assembly or loose hardware.	Review assembly instructions and ensure all parts are correctly installed and tightened.
Parts do not fit	Incorrect orientation of parts.	Double-check the assembly manual for correct part orientation. Some parts may look similar but have specific directions.

8. SPECIFICATIONS

Feature	Detail
Brand	JURMERRY
Model Number	16
Color	Black
Material	Metal (frame), Wood (headboard/footboard accent)
Overall Dimensions (L x W x H)	208 x 157 x 101 cm (81.9 x 61.8 x 39.8 inches)
Compatible Mattress Size	150 x 200 cm (King size)
Under-Bed Clearance	27 cm (10.6 inches)
Maximum Weight Capacity	200 kg (440 lbs)
Product Weight	27 kg (59.5 lbs)
Special Features	No box spring needed, easy assembly, rust prevention finish

9. WARRANTY AND SUPPORT

The JURMERRY Metal Bed Frame comes with a **1-year worry-free warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use.

For warranty claims, missing parts, assembly assistance, or any other inquiries, please contact JURMERRY customer support. Have your purchase receipt and model number (16) ready when contacting support.

Contact information for customer support can typically be found on the product packaging or the retailer's website where the product was purchased.