



[Manuals.plus](#) /

> [Jocisland](#) /

> Jocisland Full Upholstered Platform Bed Frame BHB006 – Instruction Manual

Jocisland BHB006

Jocisland Full Upholstered Platform Bed Frame – Instruction Manual

MODEL: BHB006

Welcome

Thank you for choosing the Jocisland Full Upholstered Platform Bed Frame. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and proper use of your new bed frame.

Important Safety Information

- Do not exceed a total weight of 800 pounds on the bed frame.
- Follow all assembly instructions carefully to prevent instability or collapse.
- Ensure all bolts and fasteners are securely tightened before use.
- Keep small parts away from children during assembly.
- Assemble the bed frame on a level surface.

Package Contents

Please verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Headboard (1)
- Side Rails (2)
- Footboard (1)
- Center Support Beams (3)

- Wooden Slats (12)
- Support Legs (4 main, plus additional center support legs)
- Hardware Pack (Bolts, washers, Allen wrench, etc.)
- Installation Manual (This document)

Assembly Instructions

Estimated assembly time: Approximately 30 minutes for two people. No additional tools required beyond what is provided.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface (e.g., a rug or blanket) to prevent scratches. Compare all parts with the package contents list to ensure everything is present.
2. **Attach Side Rails:** Connect the side rails to the headboard and footboard using the provided bolts and an Allen wrench. Insert bolts loosely at first.
3. **Install Center Support Beams:** Secure the metal center support beams to the designated points on the headboard and footboard, and to the side rails.
4. **Place Wooden Slats:** Lay the wooden slats across the bed frame. Ensure they are evenly spaced and the anti-slip Velcro strips on the slats align with the corresponding strips on the frame.
5. **Attach Support Legs:** Screw the main support legs into the corners of the frame and attach any additional center support legs.
6. **Final Tightening:** Once all components are in place and aligned, fully tighten all bolts and fasteners securely. Do not overtighten.



Figure 1: Bed Frame Dimensions and Components Overview



Sturdy Structure

Total 12pcs hardwood slats & 3pcs metal center beams with a load capacity of up to 1000 LBS.No spring box is required

Figure 2: Detail of Slat and Metal Beam Support System



Figure 3: Anti-Slip Velcro on Slats

Usage Guidelines

This platform bed frame is designed for direct mattress placement. A box spring is not required.

- **Mattress Compatibility:** This frame accommodates full-size mattresses with heights between 8 and 16 inches.
- **Headboard Support:** The 51.2-inch tall wingback headboard provides comfortable support for sitting up

in bed, reading, or relaxing.

- **Even Placement:** Ensure your mattress is centered on the frame for optimal support and stability.



Figure 4: Mattress Height Compatibility



Figure 5: Wingback Headboard for Support

Care and Maintenance

- **Fabric Care:** For the upholstered linen fabric, spot clean with a damp cloth and a mild, pH-neutral detergent. Blot gently and avoid rubbing vigorously. Do not use harsh chemicals or abrasive cleaners.
- **Fastener Check:** Periodically check all bolts and screws and tighten them as needed to maintain the bed frame's stability and structural integrity.
- **Under-bed Cleaning:** The 5.9-inch clearance beneath the bed frame allows for easy cleaning, including access for most robotic vacuums.

Solid Wood Legs

Smart Underbed Cleaning



Figure 6: Under-bed Clearance for Easy Cleaning



Figure 7: Fine Linen Upholstery Detail

Troubleshooting

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable	Loose fasteners or incorrect assembly	Check and tighten all bolts and screws. Ensure all components are correctly aligned according to the assembly instructions.
Squeaking noises	Loose connections, friction between parts, or uneven floor	Tighten all hardware. Ensure slats are properly seated and secured with Velcro. If the floor is uneven, consider placing felt pads under the bed legs.
Slats shifting or falling out	Slats not properly secured or anti-slip Velcro not engaged	Ensure slats are correctly positioned and the anti-slip Velcro is fully engaged with the corresponding strips on the frame.
Mattress slides on the frame	Lack of friction between mattress and slats	The anti-slip Velcro on the slats is designed to minimize mattress movement. If sliding persists, a non-slip mattress pad can be placed between the mattress and slats.

Product Specifications

Brand	Jocisland
Model	BHB006
Size	Full
Product Dimensions (L x W x H)	79" x 58" x 51"
Headboard Height	51.2"
Under-bed Clearance	5.9 Inches
Color	Light Grey
Material	Upholstered Linen Fabric, Solid Wood Legs, Hardwood Slats, Metal Frame
Weight Capacity	Up to 800 lbs
Item Weight	84 pounds
Assembly Required	Yes
Box Spring Required	No

Warranty and Customer Support

For warranty information or assistance with your Jocisland bed frame, please refer to the purchase documentation or contact Jocisland customer support directly. Contact information for support can typically be found on the seller's page or through your purchase platform.

Note: No official product videos from the seller were available for embedding in this manual.

© 2024 Jocisland. All rights reserved.