

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Bellemave](#) /

> [Bellemave Twin Montessori Floor Bed Frame \(Model TH-00261-T-E2V\) - Instruction Manual](#)

## Bellemave TH-00261-T-E2V

# Bellemave Twin Montessori Floor Bed Frame (Model TH-00261-T-E2V) - Instruction Manual

Model: TH-00261-T-E2V | Brand: Bellemave

## SAFETY INFORMATION

Please read all instructions carefully before assembly and use of the Bellemave Twin Montessori Floor Bed Frame. Keep this manual for future reference.

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assembly should be performed by adults. Keep children away during the assembly process to prevent injury.
- Always place the bed on a flat, level surface.
- Regularly check all screws and fasteners to ensure they are tight. Loose fasteners can cause instability and injury.
- Do not allow children to jump on the bed frame as this may cause damage or injury.
- The bed is designed for a twin-size mattress. Ensure the mattress fits snugly to prevent gaps where a child could become entrapped.
- Keep the bed away from heat sources, open flames, and electrical outlets.
- Maximum weight capacity: Refer to product labeling for specific weight limits.

## PACKAGE CONTENTS

Verify that all components listed below are included in your package:

Part	Description	Quantity
Side Rails (Long)	Main frame sides with vertical slats.	2
End Rails (Short)	Headboard and footboard sections with vertical slats.	2
Guardrails	Integrated into the side rails.	Included
Slats	Wooden support planks for the mattress.	Quantity varies (typically 8-12)

Part	Description	Quantity
Hardware Pack	Screws, dowels, Allen wrench.	1 set
Instruction Manual	This document.	1

**Tools Required (Not Included):** Phillips head screwdriver.

## ASSEMBLY INSTRUCTIONS

---

Follow these steps to assemble your Bellemave Twin Montessori Floor Bed Frame. It is recommended to have two adults for assembly.

### Step 1: Prepare Components

Unpack all components and lay them out on a soft, clean surface to prevent scratches. Identify each part according to the Package Contents list. The hardware is typically organized in numbered bags.

Your browser does not support the video tag.

*Video: Overview of the Montessori Floor Bed. This video provides a general visual of the assembled bed and its low-profile design.*

### Step 2: Assemble the Short Sides

Attach the legs to the short end rails. Ensure the legs are oriented correctly, with any pre-drilled holes for the slats facing inwards. Use the provided dowels and screws from the hardware pack to secure them. Do not overtighten.

### Step 3: Connect the Long Sides

Connect the assembled short sides to the long side rails. Use the longer screws and barrel nuts to join the corners. It is advisable to loosely tighten these screws initially to allow for minor adjustments as you assemble the entire frame.

### Step 4: Install the Slats

Place the wooden slats across the bed frame. Ensure the side of the slat with the pre-drilled holes for screws faces upwards. Align the slats with the pre-drilled holes on the inner ledges of the side rails. Secure each slat using the provided screws. Distribute the slats evenly across the bed frame for optimal mattress support. Be careful when handling slats as some edges may be rough.

### Step 5: Final Tightening

Once all components are in place and the frame is square, fully tighten all screws and fasteners. Do not overtighten to avoid stripping the wood or hardware.

## USAGE GUIDELINES

---

- Place a twin-size mattress directly onto the installed slats. No box spring is needed.
- The low-profile design allows for easy access for children, promoting independence.
- Ensure the mattress fits snugly within the frame to prevent any gaps.

## MAINTENANCE

---

- Clean the bed frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- Periodically check all connections and tighten any loose screws to maintain stability.
- Inspect the wooden slats for any signs of wear or damage. Replace if necessary.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Bed frame is wobbly.	Loose fasteners.	Check and tighten all screws and bolts. Ensure the bed is on a level surface.
Parts do not align during assembly.	Incorrect orientation of parts; screws overtightened prematurely.	Review assembly steps, especially for leg and rail orientation. Loosen screws, adjust alignment, then retighten.
Mattress does not fit properly.	Incorrect mattress size.	Ensure you are using a standard twin-size mattress.

## SPECIFICATIONS

---

**Model:** TH-00261-T-E2V

**Brand:** Bellemave

**Size:** Twin Size

**Product Dimensions:** 78.2"L x 41.8"W x 17.5"H

**Material:** Wood

**Color:** Grey

**Special Feature:** No Box Spring Needed

**Included Components:** Guardrails, Slats

**Assembly Required:** Yes

**Item Weight:** 22 pounds

## WARRANTY AND SUPPORT

---

For warranty information or customer support, please refer to the documentation included with your purchase or contact Bellemave customer service directly. Contact details can typically be found on the manufacturer's website or on the product packaging.

**Manufacturer:** Bellemave

