

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SIXWIN](#) /

› [SIXWIN 2G+64G Android Car Stereo User Manual for Ford Explorer 2011-2019 \(Model A8262A3080\)](#)

### SIXWIN A8262A3080

## SIXWIN 2G+64G Android Car Stereo User Manual

For Ford Explorer 2011-2019 (Model A8262A3080)

### 1. PRODUCT OVERVIEW

The SIXWIN Android Car Stereo is a 9.7-inch full touch screen multimedia player designed for Ford Explorer models from 2011 to 2019. It operates on Android 13 with 2GB RAM and 64GB ROM, offering features like wireless Apple CarPlay, Android Auto, GPS navigation, Bluetooth, FM radio, Wi-Fi connectivity, and Hi-Fi audio. A backup camera and external microphone are included for enhanced functionality.



Figure 1: SIXWIN 9.7-inch Android Car Stereo Unit with included accessories.

## 2. PACKAGE CONTENTS

Verify that all components are present in the package:

- 1 x SIXWIN Android Car Stereo Unit (9.7-inch)
- 1 x Power Cable/Harness
- 1 x CANBUS Decoder
- 1 x RCA Cable Set
- 1 x AHD Rear Camera
- 1 x External Microphone
- 2 x USB Cables
- 1 x GPS Antenna
- 1 x Radio Antenna Cable

- 1 x Installation Tool Set (plastic pry tools)
- 8 x Screws



Figure 2: Detailed view of all components included in the SIXWIN car stereo package.

### 3. INSTALLATION GUIDE

This section provides general instructions for installing the SIXWIN Android Car Stereo. Professional installation is recommended.

#### 3.1 Disassembly of Original Car Stereo

1. Carefully use the provided plastic pry tools to remove the side trim panels around the original car stereo unit. Start from the bottom and work your way up.
2. Locate and remove the screws securing the original stereo unit. Typically, these are 7mm screws.
3. Gently pull out the original stereo unit. Disconnect all wiring harnesses by pressing the release clips and pulling them straight out.

4. Remove the air vents from the original stereo panel. These are usually held by plastic clips.

Video 1: Detailed steps for removing the original car radio and associated trim panels from a Ford Explorer 2011-2019. This video demonstrates the use of pry tools and screwdriver for safe removal.

Video 2: Visual guide on connecting the wiring harness for the Ford Explorer radio, specifically for models 2011-2019.

### **3.2 Wiring Connections**

1. Connect the main power cable to the corresponding port on the new Android stereo.
2. Connect the CANBUS decoder to the main harness.
3. Plug in the 6PIN and 4PIN USB cables to the stereo unit.
4. Connect the RCA cable set for audio/video inputs/outputs.
5. Attach the external microphone cable to the stereo.
6. Connect the GPS antenna to the designated port. Position the GPS antenna in a location with a clear view of the sky, typically on the dashboard.
7. Connect the radio antenna.
8. For the backup camera, connect the camera's video output to the