

## T4TREAM Queen (U.S. Standard)

# T4TREAM Farmhouse Queen Bed with Headboard and Storage Bench

Model: Queen (U.S. Standard) | Brand: T4TREAM

## INTRODUCTION

Thank you for choosing the T4TREAM Farmhouse Queen Bed. This manual provides detailed instructions for the assembly, operation, and maintenance of your new bed frame. Please read all instructions carefully before beginning assembly. Ensure all parts are present and undamaged. For safety, it is recommended to have a second person assist with assembly.

**Safety Warning: Includes safety warnings (specific details not provided in product data, please refer to packaging for full safety information).**

## PRODUCT FEATURES

- **Queen Size Bed Frame:** Features an Antique White finish with clean lines and a minimalist headboard design, providing both style and support.
- **Unique Storage Bench Design:** A versatile addition at the foot of the bed, offering seating and additional storage for pillows, blankets, clothes, and more.
- **Four Large Storage Drawers:** The 64-inch storage chest includes four spacious drawers, each measuring 28.7 inches wide and 5.7 inches deep, ideal for organizing bedroom essentials.
- **Sturdy and Durable Construction:** Built with a combination of metal and FSC-Certified engineered wood materials for excellent stability, support, and mattress longevity.

## SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have a second person assist with the process.

## Assembly Overview

Your browser does not support the video tag.

**Video Description:** This video provides a complete walkthrough of the bed assembly process, demonstrating each step from unpacking to final construction. It highlights the use of cam locks, wooden dowels, and drawer slides, offering visual guidance for users.

## Step-by-Step Guide

- 1. Prepare Side Rails (Pieces 25 & 26):** Insert 7 cam locks into each of these side rail pieces. Use a screwdriver, not a power drill, or use a power drill on a very slow setting to avoid damage.
- 2. Assemble Headboard Panels (Pieces 27 & 28):** Lay piece 27 flat. Insert the specified locking pieces (cams) and wooden dowels. Connect piece 28 to piece 27, ensuring all connections are secure.
- 3. Attach Headboard Panel (Piece 29):** Connect piece 29 (headboard panel) to the assembled pieces 27 and 28 using additional cam locks and wooden dowels.
- 4. Install Headboard Trim (Piece 19):** Secure piece 19 (headboard trim) to the top of the headboard assembly using cam locks and wooden dowels. Be conservative with glue application, or have extra glue available.
- 5. Install Bolts for Legs (Pieces 5 & 6):** Insert bolt M into the bottom of the legs (pieces 5 and 6).
- 6. Mount Drawer Slides (Pieces 5, 6, & 18):** Mount the drawer slides to pieces 5 and 6. Ensure the 'closed end' of the slide is oriented correctly (right-hand side for piece 5, left-hand side for piece 6). Mount another drawer slide to piece 18, paying attention to the closed end direction.
- 7. Connect Drawer Side Panels (Pieces 12 & 13):** Connect pieces 12 and 13 (drawer side panels) using cam locks and their corresponding locks.
- 8. Assemble Drawer Base (Pieces 3, 17, & 14):** Connect piece 17 (drawer front panel) to piece 3 (drawer back panel) using wooden dowels and the included hex key (from GG bag). Attach piece 14 (drawer bottom).
- 9. Seat Drawer Base (Piece 3 onto 17):** Carefully seat piece 3 onto piece 17, then lock the cams into place. Ensure the two additional cams on piece 17 are secured.
- 10. Connect Drawer Side (Piece 18):** Connect piece 18 (drawer side) to the assembled drawer base. Ensure the finished edge is correctly oriented.
- 11. Connect Drawer Sides (Pieces 5 & 6):** Connect pieces 5 and 6 (drawer sides) to the drawer assembly.
- 12. Connect Drawer Back (Piece 4 & 15):** Connect piece 4 (drawer back) using cam locks and piece 15 (foot base).
- 13. Connect Piece 4 to End Dresser:** Secure piece 4 to the bottom of the end dresser. This step may require careful alignment of multiple cam locks and dowels.
- 14. Attach Drawer Slide Brackets (Pieces 27, 10, & 7):** Attach pieces 27 (drawer slide brackets) to pieces 10 and 7 using bolt H.
- 15. Attach Drawer Front (Pieces 7, 8, & 9):** Attach pieces 7 and 8 to piece 9 (drawer front) using bolt H and the KK screw. Then, bolt this assembly to the bottom of the end dresser.
- 16. Attach Front Face (Piece 16):** Secure the front face (piece 16) to the chest of drawers.
- 17. Install Hinge Pieces (Pieces 1 & 2):** Install hinge pieces 1 and 2 for the storage bench lid. This step is easier with a second person.
- 18. Install Long Metal Support (Piece 22):** Grab piece 22 (long metal support) and bolt it down using

the H bolts. Use the J screw to attach it.

19. **Attach Side Rails (Pieces 25 & 26) to Headboard (29) & Footboard (5):** Attach the side rails (pieces 25 and 26) to the headboard (piece 29) and footboard (piece 5). Ensure the wooden dowels are glued into place on both sides. Insert the bolt into the hole and secure it with the washer and nut. Use the provided wrench to tighten. It is advisable to keep these bolts slightly loose initially for easier alignment, then tighten them fully.
20. **Attach Center Support Piece (Piece 22):** Attach the center support piece (piece 22) to the bed frame using the black bolts.
21. **Install Cover Pucks:** Place the cover pucks over the exposed bolts. Ensure the missing half of the puck aligns with the bolt head for a flush fit.
22. **Connect Slats (V pieces) to Center Beam (W):** Connect the V pieces (slats) to the center beam (W). It is recommended to insert one side first, then the other, and finally connect them in the middle before pushing them down to click into place.

## OPERATING INSTRUCTIONS

### Storage Bench

The storage bench at the foot of the bed features a hinged top that lifts to reveal a spacious compartment. Gently lift the lid to access the storage area. The hinges are designed for smooth operation. Close the lid carefully to avoid pinching.

### Drawers

The four large drawers in the storage bench operate on smooth ball-bearing slides. Pull the drawer handles gently to open. To close, push the drawers firmly until they are fully recessed. Avoid forcing the drawers if they encounter resistance.

## MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Tightening Hardware:** Periodically check and tighten all screws and bolts to ensure the bed frame remains stable and secure.
- **Wood Care:** Protect the wood surfaces from direct sunlight, extreme temperatures, and excessive moisture to prevent warping or discoloration.

## TROUBLESHOOTING

- **Wobbly Frame:** Ensure all cam locks, bolts, and screws are fully tightened. Recheck assembly steps to confirm correct part orientation.
- **Drawers Sticking:** Verify that drawer slides are correctly installed and free of obstructions. Ensure the closed ends of the slides are properly aligned as per instructions.

- **Lid Not Closing Properly:** Check hinges for proper installation and alignment. Ensure no items in the storage compartment are obstructing the lid's path.

## SPECIFICATIONS

Feature	Detail
Style	Antique
Size	Queen (U.S. Standard)
Special Feature	Storage Bench with 4 Large Drawers
Color	Light Rustic Oak
Frame Material	Engineered Wood
Brand Name	T4TREAM
Included Components	Headboard, Storage Chest
Item Dimensions L x W x H	95.7"L x 64"W x 42"H
Item Weight	220 Pounds
Required Assembly	Yes

## WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your purchase or visit the official T4TREAM website. Keep your purchase receipt for any warranty claims.