

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [DoCred](#) /
- › [DoCred Murphy Bed Cabinet \(Model 79x25 Modern\) Instruction Manual](#)

## DoCred 79x25 Modern

# DoCred Murphy Bed Cabinet Instruction Manual

Model: 79"x25" Modern

## 1. INTRODUCTION

Thank you for choosing the DoCred Murphy Bed Cabinet. This innovative and versatile furniture piece is designed to provide a comfortable sleeping solution while maximizing space in your home or office. It seamlessly transforms from a compact cabinet into a functional bed, complete with an included foam mattress. This manual provides essential information for safe assembly, operation, and maintenance of your new Murphy bed cabinet.



Image: DoCred 2-in-1 Cabinet Bed with Mattress highlighting space-saving, multipurpose, sturdy structure, foldable, premium material, and mattress features.

## 2. SAFETY INFORMATION

Please read and understand all safety warnings before assembling or using this product. Failure to follow these instructions may result in injury or product damage.

- **Weight Limit:** Do not exceed the maximum weight limit of **650 lbs (295 kg)**.
- **Wall Anchoring:** For stability and to prevent tip-over, the cabinet **must be securely anchored to a wall** when in use.
- **Assembly Caution:** Exercise caution during assembly to avoid injury from sharp edges or moving parts.
- **Children and Pets:** Keep children and pets away from the unit during assembly and conversion.

- **Level Surface:** Always place the cabinet on a flat, level surface.
- **Clearance:** Ensure adequate clearance around the cabinet when converting it from bed to cabinet and vice-versa.

### 3. PACKAGE CONTENTS

Your DoCred Murphy Bed Cabinet will arrive in two distinct packages. Please ensure all parts are present and undamaged before beginning assembly. Refer to the assembly video for a visual guide to components.

#### Package 1: Cabinet Components

- Cabinet panels (numbered 1-7 in assembly instructions)
- Hardware for cabinet assembly (screws, cam locks, dowels, brackets, handles)

#### Package 2: Folding Bed Frame with Mattress

- Pre-assembled folding steel bed frame
- 1.5-inch thick foam mattress
- Headboard component

## Converting a Cabinet To a Bed In Just 3 Steps



Image: Illustration showing the Murphy bed cabinet and the folding bed frame arriving in two separate packages.

### 4. SETUP AND ASSEMBLY INSTRUCTIONS

The folding bed frame comes pre-assembled. The cabinet requires assembly. Follow these steps carefully. It is recommended to have two people for assembly.

#### 4.1 Assembly Video Guide

Watch the official installation video for a comprehensive visual guide:

Your browser does not support the video tag.

Video: Official DoCred guide on how to install the Murphy Bed Cabinet, demonstrating each assembly step.

#### 4.2 Step-by-Step Cabinet Assembly

1. **Prepare Base Panel (Part 1):** Attach the plastic feet (E) and secure with screws (G) to the bottom of panel 1. Insert

- cam lock bolts (A) and wooden dowels (F) into the designated holes on panel 1.
- 2. Attach Side Panels (Parts 2 & 3):** Connect side panel 2 to panel 1 using the cam lock bolts (A) and wooden dowels (F). Secure with cam locks (B). Repeat for side panel 3.
  - 3. Install Back Panel (Part 7):** Slide back panel 7 into the grooves of the assembled U-shape structure. Secure it with screws (H).
  - 4. Integrate Bed Frame:** Carefully slide the pre-assembled folding bed frame into the cabinet structure. Align the mounting points. Secure the bed frame to the cabinet using screws (D).
  - 5. Attach Top Panel (Part 6):** Place top panel 6 onto the cabinet structure, aligning holes with cam lock bolts and dowels. Secure with screws (H).
  - 6. Install Front Panels (Parts 4 & 5):** Attach the hinges (J) to the inner edges of front panels 4 and 5 using screws (I). Mount the front panels to the cabinet structure, ensuring they align correctly. Secure with screws (C).
  - 7. Attach Handles (M):** Install the two handles (M) to the front panels 4 and 5 using screws (L).

# PRODUCT DIMENSIONS

## MULTIFUNCTIONAL FOLDING BED WITH MATTRESS



Image: Detailed diagram showing the dimensions of the Murphy bed cabinet in both folded and unfolded states, including the mattress thickness and load capacity of 650 lbs.

## 5. OPERATING INSTRUCTIONS

The DoCred Murphy Bed Cabinet is designed for easy conversion between its cabinet and bed forms.

### 5.1 Converting from Cabinet to Bed

1. **Unlock:** Ensure the cabinet is not locked or secured in any way.
2. **Open Front Panels:** Gently pull the handles on the front panels outwards to open them.
3. **Pull Out Bed:** Grasp the bed frame and pull it outwards from the cabinet. The four-fold mechanism will unfold as you pull.
4. **Extend Legs:** Ensure all support legs are fully extended and locked into place for stability.

### 5.2 Converting from Bed to Cabinet

1. **Clear Bed:** Remove all bedding, pillows, and personal items from the mattress.
2. **Fold Bed Frame:** Lift the bed frame from the foot end and push it inwards towards the cabinet. The four-fold mechanism will collapse.
3. **Close Front Panels:** Once the bed frame is fully retracted into the cabinet, close the front panels securely.



Image: Visual guide demonstrating the three simple steps to convert the cabinet into a bed.

## 6. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your Murphy bed cabinet.

- **Cleaning:** Wipe down the cabinet surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Mattress Care:** The included foam mattress can be spot cleaned with a mild detergent. Allow to air dry completely. Do not machine wash or tumble dry.
- **Hardware Check:** Periodically check all screws, bolts, and connections to ensure they are tight. Retighten if necessary.
- **Mechanism Lubrication:** If the folding mechanism becomes stiff, apply a small amount of silicone-based lubricant to the moving parts.
- **Storage:** When not in use, keep the bed in its cabinet form to protect the mattress and mechanism from dust and

damage.



Image: Close-up view of the bed's construction, highlighting high-quality solid MDP and MDF board, soft foam mattress, and movable design with smooth wheels.

## 7. TROUBLESHOOTING

If you encounter any issues with your DoCred Murphy Bed Cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed does not fold/unfold smoothly.	Mechanism is stiff or obstructed.	Check for any obstructions. Apply silicone lubricant to moving parts of the folding mechanism.

Problem	Possible Cause	Solution
Cabinet feels unstable.	Not properly anchored to the wall. Loose connections.	Ensure the cabinet is securely anchored to a wall. Tighten all assembly screws and bolts.
Missing parts during assembly.	Packaging error or lost during transit.	Refer to the package contents list. Contact DoCred customer support with your purchase details and the specific missing parts.
Mattress feels uncomfortable.	Personal preference or additional cushioning needed.	The included mattress is 1.5 inches thick. For extra cushioning, consider adding a thin mattress topper, ensuring it does not impede folding.

## 8. SPECIFICATIONS

- **Brand:** DoCred
- **Model:** 79"x25" Modern
- **Material:** Steel, Foam
- **Item Dimensions (Cabinet Folded):** 31.5 x 31.5 x 15.7 inches (approximate, based on feature bullets)
- **Item Dimensions (Bed Unfolded):** 74.8 x 29.1 x 9.4 inches (L x W x H, based on specifications)
- **Mattress Thickness:** 1.5 inches
- **Weight Capacity:** 650 lbs
- **Special Feature:** Foldable
- **Assembly Required:** Yes (Cabinet)

## 9. WARRANTY AND SUPPORT

For any questions, concerns, or to report missing/damaged parts, please contact DoCred customer support. Please have your purchase information and model number ready when contacting support.

**DoCred Customer Support:** Refer to your purchase documentation or the retailer's website for contact information.