

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [KOMFOTT](#) /

› KOMFOTT Twin Bed Frame with House Headboard Instruction Manual

## KOMFOTT 11001-HU-KT

# KOMFOTT Twin Bed Frame with House Headboard Instruction Manual

Model: 11001-HU-KT

## 1. INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your KOMFOTT Twin Bed Frame with House Shaped Headboard. Please read all instructions carefully before assembly and use to ensure safe and proper operation of the product.



Image 1.1: KOMFOTT Twin Bed Frame with House Shaped Headboard (Natural finish shown).

## 2. SAFETY INFORMATION

---

To prevent instability, injury, or damage to the product, observe the following safety guidelines:

- Always follow the assembly instructions carefully.
- Be cautious of sharp edges during assembly and use.
- Do not exceed the maximum weight capacity of 440 lbs (200 kg).
- Ensure all guardrails are properly installed and secured for safety.
- Regularly check all bolts and screws to ensure they remain tight.
- Do not allow children to jump on the bed.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- 1 x Twin Bed Frame (includes headboard, footboard, side rails, slats, and support legs)
- Assembly Hardware (screws, bolts, Allen wrench)

- 1 x Instruction Manual



Image 3.1: Overview of the KOMFOTT Twin Bed Frame components.

## 4. ASSEMBLY INSTRUCTIONS

---

Assembly is required. It is recommended to have two adults for assembly. Clear a spacious area for assembly and keep all hardware within reach.

1. **Step 1: Assemble the Headboard.** Attach the roof-shaped headboard panels and the built-in storage cube components using the provided screws. Ensure all connections are secure.



## Roof-shaped Headboard

Lovely styling is popular with kids



Built-in Storage Cube

Image 4.1: Detail of the house-shaped headboard with integrated storage.

- Step 2: Attach Side Rails and Footboard.** Connect the side rails to the assembled headboard and the footboard using the appropriate bolts. Do not fully tighten bolts until the entire frame is assembled.
- Step 3: Install Support Legs and Slats.** Secure the solid wood support legs to the bed frame. Place the 10 plywood slats across the side rails and fasten them according to the instructions. Ensure slats are evenly spaced and securely attached.



Image 4.2: Illustration of the solid wood support legs and plywood slats for mattress support.

- Step 4: Secure Guardrails.** Attach the safety guardrails to the sides of the bed frame, ensuring they are firmly in place. Confirm the side entrance is clear for access.

## Safety Guardrails



Image 4.3: View of the safety guardrails and convenient side entrance.

- Step 5: Final Tightening.** Once all components are in place, fully tighten all bolts and screws. Do not overtighten.

## 5. OPERATING INSTRUCTIONS

The KOMFOTT Twin Bed Frame is designed for use with a twin-sized mattress. No box spring is required due to the integrated plywood slats.

- **Mattress Placement:** Place a twin-sized mattress directly onto the plywood slats. The recommended mattress thickness is  $\leq 6$  inches (not included).
- **Weight Capacity:** The bed frame has a maximum weight capacity of 440 lbs. Do not exceed this limit.
- **Under-Bed Storage:** Utilize the 8.5-inch under-bed space for storage bins or other items to keep the room organized.



Image 5.1: Illustration of the ample under-bed storage space.

## 6. MAINTENANCE AND CARE

Proper care will extend the life of your bed frame.

- **Cleaning:** Wipe the bed frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.
- **Inspection:** Periodically check all connections (bolts, screws) to ensure they are tight. Retighten if necessary.
- **Ventilation:** If a new product has a slight odor, ensure adequate ventilation in the room.

## 7. TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Bed frame feels unstable or wobbly.	Loose connections; uneven assembly.	Ensure all bolts and screws are fully tightened. Disassemble and reassemble if necessary, ensuring parts are correctly aligned.

Problem	Possible Cause	Solution
Missing parts or hardware.	Packaging error; lost during unboxing.	Carefully check all packaging materials. Contact KOMFOTT customer support for replacement parts.
Strong odor from the wood.	New product off-gassing (VOCs from paint/finish).	Ensure the room is well-ventilated for several days or weeks. The odor should dissipate over time.

## 8. SPECIFICATIONS

Detailed product specifications for the KOMFOTT Twin Bed Frame.

Feature	Detail
Model Number	11001-HU-KT
Overall Dimensions (L x W x H)	82" x 44.5" x 36.5"
Material	Pine Wood, Plywood
Color	Natural
Weight Capacity	440 lbs (200 kg)
Net Weight	53.5 lbs (24.2 kg)
Under-bed Space Height	8.5"
Guardrail Height	13"
Recommended Mattress Thickness	≤6" (not included)
Assembly Required	Yes

# Specifications

440  
LBS

Weight Capacity

Recommended Mattress  
Thickness:

< 6" (not included)



Image 8.1: Visual representation of key dimensions and specifications.

## 9. WARRANTY AND SUPPORT

For warranty information or product support, please contact KOMFOTT customer service through the retailer where the product was purchased. Keep your purchase receipt and model number (11001-HU-KT) handy for faster service.