TIEZFUL TZ8061

TIEZFUL Running Boards Side Steps Instruction Manual

Model: TZ8061

Compatible with Chevy Colorado & GMC Canyon Crew Cab (2015-2026)

1. Introduction

Thank you for choosing TIEZFUL Running Boards Side Steps. These heavy-duty carbon steel running boards are designed to provide easy and safe access to your vehicle while enhancing its aesthetic appeal. Featuring a dual-stage textured finish and anti-slip steps, they offer superior traction and durability in all weather conditions. This manual provides detailed instructions for installation, operation, and maintenance to ensure optimal performance and longevity of your product.



Image: TIEZFUL Running Boards installed on a tan Chevy Colorado truck, highlighting features like anti-slip surface and no-drill installation.

2. Safety Information

- Always wear appropriate personal protective equipment (PPE) during installation, including safety glasses and gloves.
- Ensure the vehicle is parked on a level surface and the parking brake is engaged before beginning installation.
- Do not exceed the maximum weight limit of 500 lbs (226 kg) per side for the running boards.
- Regularly inspect all mounting hardware for tightness and signs of wear or damage. Tighten as necessary.
- Keep children and pets away from the work area during installation.

3. Package Contents

Verify that all components are present before beginning installation:

- 1 Pair of Running Boards
- Accessory Kits (including 6 heavy-duty brackets, bolts, nuts, and washers)
- Installation Instruction (this manual)

4. Setup & Installation

These running boards are designed for a no-drill installation, utilizing existing factory mounts on your Chevy Colorado or GMC Canyon Crew Cab (2015-2026). The process typically takes less than 30 minutes.

4.1 Vehicle Compatibility

Ensure your vehicle is a Chevy Colorado or GMC Canyon Crew Cab (4 full-size doors) model year 2015-2026 for proper fitment.



Image: Visual guide confirming compatibility with Crew Cab models and incompatibility with Regular Cab and Extended Cab models.

4.2 Installation Steps

1. **Identify Mounting Points:** Locate the pre-drilled factory mounting points along the rocker panel of your vehicle. There are typically three mounting points per side.
2. **Attach Brackets:** Secure the heavy-duty brackets to the factory mounting points using the provided bolts, nuts, and washers. Do not fully tighten the hardware at this stage to allow for adjustment.
3. **Position Running Board:** Carefully lift the running board and align it with the attached brackets.
4. **Secure Running Board:** Attach the running board to the brackets using the remaining hardware. Again, keep the bolts slightly loose for final adjustments.
5. **Adjust and Tighten:** Adjust the running board to your desired position, ensuring it is level and properly aligned with the vehicle. Once satisfied, fully tighten all bolts on both the brackets and the running board.



Image: Illustration demonstrating the no-drill installation process using existing factory mounts.

4.3 Installation Video Guide

For a visual guide on the installation process, please refer to the official seller video below:

Video: Tyger Access Running Boards Installation Demo. This video provides a step-by-step demonstration of how to install running boards on a Chevrolet Colorado, showcasing the ease of the no-drill process.

5. Operating Instructions

The TIEZFUL Running Boards are designed for convenient and safe vehicle entry and exit. The 4.9-inch wide steps feature a textured, non-slip surface to ensure maximum traction, even in wet or muddy conditions.



Image: Close-up of the 4.9-inch wide step area, designed for easy and secure entry/exit.

5.1 Weight Capacity

Each running board is capable of supporting up to 500 lbs (226 kg). Ensure this limit is not exceeded to maintain safety and product integrity.

6. Maintenance

To ensure the longevity and appearance of your TIEZFUL Running Boards, follow these maintenance guidelines:

- **Regular Cleaning:** Clean the running boards regularly with mild soap and water to remove dirt, mud, and road grime. The satin-black finish and seamless construction are designed to resist dirt buildup.
- **Inspection:** Periodically inspect the running boards and all mounting hardware for any signs of rust, corrosion, or loosening. The heavy-duty stainless steel construction with anti-corrosion powder coating is built to withstand harsh weather, but regular checks are recommended.
- **Tighten Hardware:** If any bolts or fasteners appear loose, tighten them immediately to the manufacturer's specifications.



Image: Diagram detailing the multi-layer rust-resistant coating process, including pre-treatment, E-coat, and dual-stage textured black powder.

7. Troubleshooting

- **Loose Running Board:** If the running board feels loose or wobbly, re-check and tighten all mounting bolts and nuts.
- **Unusual Noises:** If you hear any rattling or unusual noises, inspect the entire assembly for loose components or contact points that may be rubbing.
- **Difficulty with Installation:** Refer to the detailed instructions and diagrams provided in this manual. Ensure correct bracket placement and alignment with factory mounts. If issues persist, contact customer support.

8. Specifications

Brand	TIEZFUL
Model Number	TZ8061
Material	Carbon Steel
Color	Black
Exterior Finish	Polished
Item Dimensions (L x W x H)	79.52 x 5 x 5.1 inches
Weight Limit	226 Kilograms (500 lbs)
Vehicle Service Type	Chevy Colorado 2015-2026, GMC Canyon Crew Cab 2015-2026
Special Features	Accessibility, Heavy-Duty Durability, Matte Black Finish, Anti-slip, Rust-resistant

9. Warranty & Support

For any questions or assistance with your TIEZFUL Running Boards, please refer to the product's original purchase platform or contact TIEZFUL customer support directly. Our US-based team is available to provide prompt assistance and ensure your satisfaction.

© 2025 TIEZFUL. All rights reserved.