

[manuals.plus](#) /

- › [Nilight](#) /
- › [Nilight Floor Mats User Manual for Ford Flex 2009-2019](#)

Nilight Mat-1105

Nilight Floor Mats User Manual

FOR FORD FLEX 2009-2019

1. Introduction

Thank you for choosing Nilight Floor Mats. These custom-fit, heavy-duty floor liners are specifically designed to provide superior protection for your Ford Flex (models 2009-2019). Made from high-quality TPE material, they offer all-weather defense against various elements, ensuring your vehicle's interior remains clean and well-preserved.



Image: The Nilight Floor Mats, showing the front and rear mats, alongside their product packaging.

2. Setup and Installation

Nilight Floor Mats are engineered for a direct and precise fit, utilizing your vehicle's original fixed mounts for secure placement. Follow these steps for proper installation:

- Preparation:** Ensure the vehicle's floor is clean and free of debris before installing the new mats. Remove any existing floor mats.
- Front Mats:** Align the driver's side mat with the vehicle's floor contours and secure it using the existing floor retention hooks or posts. Repeat for the passenger side front mat.
- Rear Mat:** Place the one-piece rear mat across the rear floorboard, ensuring it sits flat and covers the entire area.
- Check Fitment:** Verify that all mats are securely in place and do not interfere with pedal operation (accelerator, brake, clutch). The custom design ensures no pedal interference.

CUSTOM DIRECT FIT



Image: A close-up view of the custom-fit floor mat installed in a vehicle, highlighting the heel friction pad and 3D full protection.

EASY INSTALL AND PERFECT FITMENT



Original fixed mount



Non-slip design



Full surround



Watertight seals

Image: A collage showing the ease of installation, including securing the mat to the original fixed mount, the non-slip design, full surround coverage, and watertight seals.

3. Operating and Usage

Nilight Floor Mats are designed for continuous use, providing robust protection in all weather conditions. Their heavy-duty construction and non-slip design ensure they stay in place, offering a stable and secure surface for your feet.

- **All-Weather Protection:** These mats are built to withstand rain, dust, and snow, protecting your vehicle's carpet from moisture, dirt, and debris.
- **Seamless Coverage:** The custom fit ensures maximum coverage, protecting your upholstery from spills and particles.
- **Safety:** The non-slip surface and secure fastening points prevent the mats from shifting during driving, enhancing safety.

FAST CLEANING



Image: A graphic illustrating the all-weather protection capabilities of the floor mats against rain, dust, and snow, with various vehicle scenarios.



Image: A four-panel image showing detailed views of the front row (driver and passenger side) and back row floor mats installed in a vehicle, highlighting their texture and fit.

4. Maintenance

Maintaining your Nilight Floor Mats is simple due to their durable and easy-to-clean TPE material. Regular cleaning will ensure their longevity and continued performance.

- **Fast Cleaning:** For most messes, a simple spray with a hose will suffice. For tougher dirt or spills, use mild soap and water.
- **Drying:** Allow the mats to air dry completely before placing them back in your vehicle to prevent moisture buildup underneath.
- **Material Benefits:** The TPE material is odorless, waterproof, and wear-resistant, ensuring the mats maintain their integrity and appearance over time.

ALL WEATHER SEAMLESS PROTECTION



Image: A person cleaning the floor mats with a high-pressure hose, demonstrating how easily dirt, mud, and liquid spills are removed.

TPE ECO-FRIENDLY MATERIALS



Image: An infographic detailing the benefits of TPE eco-friendly materials, including waterproof, wear-resistant, soft & soundproof, anti-slip, non-smell, OEM quality, non-slippery, and full protection.

5. Troubleshooting

If your floor mats appear folded or creased upon receipt, this is normal due to packaging for shipping. The TPE material is flexible and will recover its shape. Here are methods to restore their original form:

- **Lay Flat:** Simply lay the mats flat for some time (e.g., overnight) to allow them to recover naturally.
- **Reverse Fold:** Gently reverse fold the mat against the direction of the crease.
- **Sun Exposure:** Expose the mats to sunlight for a period. The warmth will help the material regain its shape.
- **Heat Application:** Use a hot hair dryer or warm water to gently heat the creased areas, then reshape by hand.

OUR TPE MATS



Non-Smell



Original Car Feeling



Non-Slippery



Full Protection



Image: A visual guide demonstrating four methods to recover the shape of folded floor mats: laying flat, reverse folding, sun exposure, and using a hot air dryer or hot water.

6. Specifications

Feature	Detail
Brand	Nilight
Model Number	Mat-1105
Compatible Vehicle	Ford Flex (2009-2019)
Material	High-Quality TPE
Item Weight	11.82 pounds
Product Dimensions	25 x 5 x 15 inches
Country of Origin	China
UPC	840323949439

7. Warranty and Support

Nilight stands behind the quality of its products. These floor mats come with a commitment to **Lifetime Service**. If you encounter any issues or have questions regarding your Nilight Floor Mats, please refer to the contact information provided with your purchase or visit the official Nilight store for support.

For further assistance, you may visit the [Nilight Store on Amazon](#).