

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [ModernLuxe](#) /
- › [ModernLuxe Double Bed Frame 140x200cm Instruction Manual](#)

ModernLuxe 140x200cm

ModernLuxe Double Bed Frame 140x200cm Instruction Manual

Model: 140x200cm | Brand: ModernLuxe

INTRODUCTION

Thank you for choosing the ModernLuxe Double Bed Frame. This manual provides essential information for the safe assembly, proper usage, and effective maintenance of your new bed frame. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

- Always assemble the bed frame on a soft, clean surface to prevent damage.
- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Tighten all screws and bolts securely, but do not overtighten. Periodically check and re-tighten fasteners.
- Keep small parts away from children during assembly.
- Assembly is recommended for two adults.
- Do not stand on the bed frame or use it as a trampoline.
- The maximum weight capacity for this bed frame is 200 kg.

PACKAGE CONTENTS

Please verify that all parts listed below are included in your package. If any parts are missing or damaged, please contact ModernLuxe customer support.

- Headboard (1)
- Side Rails (2)
- Footboard (1)
- Center Support Beam (1)
- Slats (Quantity varies by model, typically 12-14 pairs)
- Support Legs (4 main, 2-3 central)

- Hardware Pack (Screws, bolts, washers, Allen key)
- Assembly Instructions (This manual)

SETUP AND ASSEMBLY

Estimated assembly time: 30 minutes for two adults.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface. Identify each component using the parts list.
2. **Attach Support Legs to Headboard and Footboard:** Secure the main support legs to the headboard and footboard using the provided hardware. Ensure they are firmly attached.
3. **Connect Side Rails:** Attach the side rails to the headboard and footboard. Make sure the connections are secure and the frame is stable.
4. **Install Center Support Beam:** Place the center support beam along the length of the bed frame and secure it to the headboard and footboard, or to the designated brackets on the side rails. Attach any central support legs to this beam.
5. **Insert Slats:** Evenly space the wooden slats across the bed frame. Secure them in place using the provided fasteners or by inserting them into the designated slots on the side rails and center beam. Ensure all slats are properly seated and stable.
6. **Final Check:** Once assembled, gently shake the bed frame to ensure all connections are tight and the structure is stable. Re-tighten any loose fasteners.

Unit:CM



Figure 1: Bed Frame Dimensions. This diagram illustrates the overall dimensions of the bed frame, including the length (209 cm), width (141 cm), and height (101 cm for the headboard).



Weiches graues Leinen

Robuste Holzlatten

Luxuriöse und stabile Füße

Figure 2: Material Details. This image highlights the key material components: the soft linen fabric of the headboard, the robust wooden slats for mattress support, and the design of the stable wooden feet.

OPERATING (USAGE)

Your ModernLuxe bed frame is designed for comfortable and stable sleep. Place your mattress directly onto the slatted base. No box spring is required.

- Ensure the mattress is centered on the frame.
- Avoid placing excessive weight on any single point of the bed frame.
- The 17 cm under-bed clearance provides convenient storage space for items such as pillows, blankets, or seasonal clothing.



Figure 3: Assembled Bed Frame in Use. This image shows the complete bed frame with a mattress and bedding, demonstrating its appearance in a typical bedroom environment.

MAINTENANCE

- **Cleaning the Fabric:** For general cleaning, gently vacuum the upholstered headboard and frame with a soft brush attachment to remove dust. For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner specifically designed for linen, testing on an inconspicuous area first.
- **Frame Care:** Wipe the wooden legs and any exposed metal parts with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Fastener Check:** Periodically (every 3-6 months) check all screws, bolts, and connections to ensure they remain tight. Re-tighten as necessary to maintain stability and prevent squeaking.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause the fabric color to fade.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable.	Loose fasteners. Uneven floor.	Check and tighten all screws and bolts. Ensure the bed is on a level surface; use shims if necessary.
Squeaking noises.	Loose connections. Slats rubbing.	Tighten all hardware. Ensure slats are properly seated and not rubbing against each other or the frame. Apply felt pads if needed.
Mattress sags in the middle.	Damaged or improperly installed slats/center support.	Verify the center support beam is correctly installed and its legs are touching the floor. Check all slats for damage and ensure they are evenly spaced and secured.

SPECIFICATIONS

Brand:	ModernLuxe
Model:	140x200cm (Double Bed Frame)
Color:	Black
Overall Dimensions (L x W x H):	209 cm x 141 cm x 101 cm
Headboard Height:	101 cm
Under-bed Clearance:	17 cm
Weight Capacity:	Up to 200 kg
Materials:	Linen fabric, Steel frame, Wooden slats, Wooden legs
Assembly Required:	Yes (Approx. 30 minutes for two adults)
ASIN:	B0F997XPQJ
UPC:	198573956647

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact ModernLuxe customer service directly. Please have your model number (140x200cm) and ASIN (B0F997XPQJ) ready when contacting support.

Related Documents - 140x200cm

ASSEMBLY INSTRUCTIONS



WF294739/WF294740

1

[ModernLuxe Furniture Assembly Instructions: Bed Frame, Nightstand, and Storage Bench](#)

Comprehensive assembly instructions for ModernLuxe furniture products, including the WF294739/WF294740 bed frame, WF294735 nightstand, and WF294737 storage bench. Detailed steps, part lists, and hardware information for easy setup.