

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [GAOMON](#) /

> [GAOMON Queen Bed Frame with Rattan Headboard \(Model XQ2e1f\) Instruction Manual](#)

GAOMON XQ2e1f

GAOMON Queen Bed Frame with Rattan Headboard (Model XQ2e1f) Instruction Manual

Model: XQ2e1f | Brand: GAOMON

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your GAOMON Queen Bed Frame with Natural Rattan Headboard. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The GAOMON Queen Bed Frame (Model XQ2e1f) features a natural rattan headboard, a sturdy metal platform, and strong wooden slats designed to support a queen-size mattress without the need for a box spring. This design ensures a stable and quiet sleeping experience.

IMPORTANT SAFETY INFORMATION

- **Caution:** Be cautious of sharp edges on components during assembly and use. Handle all parts with care to prevent injury.
- **Stability:** Ensure proper support and stability during assembly due to the significant weight of the bed frame. It is recommended that two adults assemble this product.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 800 lbs for this bed frame.
- **Mattress Compatibility:** This bed frame is designed for a Queen size mattress. Recommended mattress thickness is 8-12 inches.
- **Regular Checks:** Periodically check all bolts and connections to ensure they remain tight and secure.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact GAOMON customer support.

- Headboard (Natural Rattan)
- Side Rails (Metal)
- Center Support Beam (Metal)

- Support Legs
- Wooden Slats
- Hardware Pack (Bolts, Washers, Allen Wrench)
- Assembly Instructions (this manual)



Figure 1: Exploded view of GAOMON Queen Bed Frame components and dimensions. The frame measures approximately 80.9 inches long, 60.2 inches wide, with a headboard height of 43.9 inches and a bed base height of 12.6 inches. The headboard itself is 62.2 inches wide and 19.6 inches high.

SETUP AND ASSEMBLY

Assembly typically requires two adults and takes approximately 30-60 minutes. An Allen wrench is included; no additional tools are required.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface (like a carpet) to prevent scratches.
2. **Attach Headboard to Side Rails:** Connect the side rails to the headboard using the provided bolts and washers. Do not fully tighten bolts until all connections are made.
3. **Attach Footboard to Side Rails:** Connect the footboard to the other end of the side rails. Ensure all connections are aligned before tightening.
4. **Install Center Support Beam:** Place the metal center support beam along the middle of the frame. Attach it to the headboard and footboard connections. Ensure any adjustable support legs on the center beam are properly extended and secured.

5. **Insert Wooden Slats:** Place the wooden slats across the bed frame. The slats are designed for simple installation, often fitting into pre-drilled holes or plastic caps on the side rails. Ensure they are evenly spaced and securely seated. Some slats may have sponge strips to reduce noise.
6. **Final Tightening:** Once all components are in place and aligned, systematically tighten all bolts using the Allen wrench. Do not overtighten.
7. **Check Stability:** Gently shake the assembled bed frame to ensure it is stable and all connections are secure.

PRODUCT DETAIL



SPONGE STRIPS FOR ELIMINATING NOISE



WOODEN SLATS FOR SIMPLE INSTALLATION



RATTAN WOVEN HEADBOARD



Figure 2: Close-up of key assembly features. This image highlights the sponge strips integrated into the metal frame to prevent noise, the simple installation method for the wooden slats, and the natural rattan woven headboard design.

BUILT TO LAST



Figure 3: Structural components of the bed frame. This image illustrates the robust metal center support and the arrangement of 12 sturdy plywood slats, designed for durability and mattress support.

OPERATING AND USE

Your GAOMON Queen Bed Frame is designed for comfortable and stable sleep. Follow these guidelines for optimal use:

- **Mattress Placement:** Carefully place your Queen size mattress directly onto the wooden slats. No box spring is required.
- **Recommended Mattress Thickness:** For best support and aesthetic, use a mattress between 8 and 12 inches thick.
- **Under-Bed Storage:** The frame provides ample under-bed clearance for storage. Utilize storage bins or containers to keep your bedroom organized.



Recommended Mattress Thickness



8-12INCH

Figure 4: Recommended mattress thickness. This diagram shows that a mattress between 8 and 12 inches is ideal for this bed frame.

Ample under-bed storage space

A large under-bed storage space available for flexible organization and placement.



Figure 5: Under-bed storage. This image demonstrates the generous space beneath the bed frame, suitable for various storage solutions like boxes and baskets.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your bed frame:

- **Cleaning the Frame:** Wipe metal and wooden parts with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Rattan Headboard Care:** The natural rattan headboard can be gently dusted with a soft brush or cloth. For deeper cleaning, a slightly damp cloth can be used, followed by immediate drying to prevent moisture damage. Avoid direct sunlight exposure for prolonged periods to prevent fading or drying out of the rattan.
- **Tighten Connections:** Periodically (e.g., every 3-6 months) check and retighten all bolts and screws to maintain stability and prevent squeaking.
- **Avoid Excessive Moisture:** Keep the bed frame in a dry environment to prevent warping of wooden components or rust on metal parts.

NATURAL RATTAN



Natural Rattan
Hand-woven From Indonesia

 Natural  Clean  Long lasting



Figure 6: Natural rattan detail. This image shows the handwoven natural rattan material used in the headboard, emphasizing its texture and quality.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed frame is squeaking or noisy.	Loose bolts or connections. Slats rubbing against the frame.	<ul style="list-style-type: none">◦ Check and tighten all bolts and screws.◦ Ensure wooden slats are properly seated and not shifting.◦ Verify sponge strips are in place to reduce metal-on-metal contact.

Problem	Possible Cause	Solution
Bed frame feels unstable.	Loose connections. Uneven floor.	<ul style="list-style-type: none"> Retighten all assembly hardware. Ensure all support legs are making firm contact with the floor. If the floor is uneven, consider using furniture pads or shims under the legs.
Mattress sags in the middle.	Improperly installed center support or slats. Overweight.	<ul style="list-style-type: none"> Verify the center support beam is correctly installed and its legs are firm. Ensure all wooden slats are evenly spaced and securely in place. Check if the combined weight on the bed exceeds the 800 lbs capacity.

SPECIFICATIONS

Feature	Detail
Model Number	XQ2e1f
Brand	GAOMON
Size	Queen
Product Dimensions (L x W x H)	80.9" x 60.2" x 43.9" (approximate assembled dimensions)
Headboard Material	Natural Rattan
Frame Material	Metal, Wood (slats)
Color	Natural
Weight Capacity	800 lbs
Recommended Mattress Thickness	8-12 inches
Assembly Required	Yes
Item Weight	83.6 pounds
UPC	199414149143

WARRANTY AND CUSTOMER SUPPORT

For any questions, missing parts, or concerns regarding your GAOMON Queen Bed Frame, please contact GAOMON customer support. While specific warranty details are not provided in this manual, Amazon offers a 90-day easy return policy for this product.

Please refer to your purchase documentation or the retailer's website for the most current warranty information and contact details.

