Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AVKENOEDY 56-60W72H-8MM

AVKENOEDY 56-60" W x 72" H Frameless Shower Door Instruction Manual

Model: 56-60W72H-8MM

1. Introduction

Thank you for choosing the AVKENOEDY Frameless Shower Door. This manual provides essential information for the safe installation, operation, and maintenance of your new shower door. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Figure 1.1: AVKENOEDY Frameless Shower Door in a bathroom setting. This image illustrates the sleek, modern design and clear glass panels of the installed shower door.

2. Safety Information

WARNING: Improper installation or use can result in serious injury or property damage. Always follow these safety guidelines:

- Always wear safety glasses, gloves, and appropriate protective gear during installation.
- Handle glass panels with extreme care. Tempered glass, while strong, can shatter into small pieces if its edges are struck or damaged.
- Ensure the installation surface (walls, floor) is structurally sound and capable of supporting the weight of the shower door.
- Do not attempt to install the shower door alone. Two or more people are required for safe handling and installation.
- Verify all measurements and clearances before drilling or making permanent modifications.

- Keep children and pets away from the installation area.



Figure 2.1: Illustration of shatterproof tempered safety glass. This image highlights the 5/16" (8mm) glass thickness and the explosion-proof film designed to hold fragments in place if the glass breaks, ensuring user safety.

3. Specifications

Feature	Specification
Brand	AVKENOEDY
Model	56-60W72H-8MM
Adjustable Width	56 - 60 inches (142.2 - 152.4 cm)
Height	72 inches (182.9 cm)

Feature	Specification
Glass Thickness	5/16 inch (8mm)
Glass Type	Clear SGCC Tempered Glass, ANSI Certified
Hardware Material	Stainless Steel
Hardware Finish	Brushed Nickel
Item Weight	Approximately 110 Pounds (50 kg)
Special Features	Nano Coating, Waterproof Seal Strip, Reversible Installation



Figure 3.1: Key dimensions of the AVKENOEDY Frameless Shower Door. This diagram illustrates the adjustable width, height, and glass thickness.

4. Package Contents

Please verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, contact customer support immediately.

- Tempered Glass Panels (Fixed and Sliding)
- Top Sliding Rail
- Wall Brackets and Mounting Hardware
- Sliding Rollers/Pulleys
- Door Handle (Stainless Steel)
- Waterproof Seal Strips and Anti-Splash Threshold
- Installation Screws and Anchors
- Installation Manual (this document)



Figure 4.1: Detail of the stainless steel handle. This image showcases the design and finish of the pull handle included with the shower

door.

5. Setup and Installation

Professional installation is recommended for optimal safety and performance. If you choose to install it yourself, ensure you have the necessary tools and assistance.

5.1 Pre-Installation Steps

1. **Inspect Components:** Unpack all items and check against the package contents list. Report any damage or missing parts immediately.
2. **Prepare Area:** Clear the installation area. Ensure the shower base/curb is level and the walls are plumb and structurally sound.
3. **Gather Tools:** You will need a drill, level, tape measure, pencil, screwdriver set, caulk gun, silicone sealant, and safety gear.

5.2 Installation Overview

The AVKENOEDY shower door features a reversible design, allowing for either a left-side or right-side opening configuration to suit your bathroom layout.



Figure 5.1: Reversible installation options. This image demonstrates how the shower door can be configured for either a left-side or right-side opening.

1. **Measure and Mark:** Carefully measure the opening width. The door is adjustable from 56 to 60 inches. Mark the positions for the wall brackets and top rail.
2. **Install Wall Brackets:** Secure the wall brackets to the wall using appropriate anchors and screws. Ensure they are level and aligned.
3. **Mount Top Rail:** Attach the top sliding rail to the wall brackets. This rail provides smooth and noiseless sliding for the door.



Figure 5.2: Detail of the super sturdy top rail. This image highlights the robust construction of the top rail and the smooth-gliding rollers, ensuring quiet and effortless operation.

4. **Install Fixed Glass Panel:** Carefully position and secure the fixed glass panel according to the instructions provided in the detailed installation guide (usually included in the box).
5. **Attach Rollers to Sliding Glass Panel:** Secure the sliding rollers to the top edge of the movable glass panel.
6. **Hang Sliding Glass Panel:** Carefully lift and hang the sliding glass panel onto the top rail.
7. **Install Handle and Seals:** Attach the pull handle to the sliding door. Install the waterproof seal strips along the edges of the glass panels and the anti-splash threshold at the bottom to prevent water leakage.
8. **Seal with Silicone:** Apply a bead of silicone sealant along all exterior joints where the shower door meets the wall and shower base to ensure a watertight seal. Allow adequate drying time before use.

6. Operating Instructions

The AVKENOEDY Frameless Shower Door is designed for smooth and effortless operation.

- To open the door, gently grasp the stainless steel pull handle and slide the door along the top rail.
- To close the door, slide it back until it meets the fixed panel and the magnetic seals engage.
- Avoid forcing the door or slamming it shut, as this can damage the rollers or glass.

7. Maintenance

Regular cleaning and maintenance will ensure the longevity and pristine appearance of your shower door.

7.1 Glass Cleaning

The glass panels feature a nano-coating for water repellency and to resist staining and hard water build-up.



Figure 7.1: Water repellent technology on glass. This image demonstrates how the nano-coating causes water to bead and run off, preventing water spots and build-up.

- After each use, wipe down the glass with a soft cloth or squeegee to remove water droplets.
- For general cleaning, use a mild, non-abrasive glass cleaner and a soft cloth.

- Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the nano-coating and hardware finish.
- For stubborn water spots, a solution of white vinegar and water can be used, followed by a thorough rinse.

7.2 Hardware and Seals

- Clean stainless steel hardware with a soft, damp cloth. Avoid abrasive cleaners.
- Periodically check the waterproof seal strips for wear or damage. Replace if necessary to maintain a watertight enclosure.
- Ensure the sliding rollers are free of debris and operate smoothly. Lubricate with a silicone-based lubricant if needed.

8. Troubleshooting

This section addresses common issues you might encounter with your shower door.

Problem	Possible Cause	Solution
Door does not slide smoothly	Debris in track, worn rollers, misaligned rail	Clean top rail and rollers. Inspect rollers for damage. Check rail alignment with a level. Lubricate rollers with silicone spray.
Water leakage from door edges	Damaged or improperly installed seal strips, insufficient silicone sealant	Inspect and adjust or replace seal strips. Reapply silicone sealant to exterior joints if necessary. Ensure door closes completely.
Door does not close completely	Obstruction, misaligned magnetic strips, bent rail	Check for obstructions. Adjust magnetic strips for proper contact. Inspect top rail for any deformation.
Glass appears cloudy or stained	Hard water build-up, improper cleaning agents	Clean with a vinegar-water solution or specialized glass cleaner for hard water. Avoid abrasive cleaners. Refer to Maintenance section.

9. Warranty and Support

The AVKENOEDY Frameless Shower Door is manufactured with high-quality materials and undergoes strict quality control. For specific warranty details, please refer to the warranty card included with your product or contact the seller directly.

If you have any questions about the product, installation, or require technical assistance, please do not hesitate to contact AVKENOEDY customer support. We are committed to assisting you.

Contact information can typically be found on the product packaging or through your purchase platform (e.g., AVKENOEDY Store on Amazon).

© 2025 AVKENOEDY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

The base of my shower is raised and is only 2 inches wide. Is this wide enough for the track roller piece on the AVKENOEDY 56-60W72H-8MM Frameless Shower Door?

Based on the specifications for the AVKENOEDY 56-60W72H-8MM Frameless Shower Door, a 2-inch wide threshold is generally considered the absolute minimum for most frameless sliding shower doors, but it may be very tight for...

Read full answer

Open the live page

https://manuals.plus/asin/B0FHPXRQZ5

More documents and user manuals: **https://manuals.plus/**