Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SlickBlue D-CO-HU10482BN-F

SlickBlue Modern Bed Frame User Manual

Model: D-CO-HU10482BN-F

Introduction

Thank you for choosing the SlickBlue Modern Bed Frame. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed frame. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The SlickBlue Modern Bed Frame, showcasing its wooden headboard and natural wood finish.

Safety Information

- Always assemble the bed frame on a soft, clean surface to prevent damage.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight capacity of 660 lbs (Full size).
- Keep small parts away from children during assembly to prevent choking hazards.
- Do not use power tools for assembly as this may overtighten and damage components.
- This product is intended for indoor use only.

Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Headboard (1)
- Footboard (1)
- Side Rails (2)
- Center Support Beam (1)
- Support Legs (3)
- Plywood Slats (Set)
- Hardware Pack (Bolts, Washers, Allen Wrench)

Setup and Assembly

Follow these steps carefully to assemble your bed frame. It is recommended to have two people for assembly.

Step 1: Attach Side Rails to Headboard and Footboard

Connect the side rails to the headboard and footboard using the provided bolts and washers. Ensure the bolt holes align correctly. Hand-tighten all bolts initially.



Image: Illustration of the bed frame structure, showing how side rails connect to the headboard and footboard.

Step 2: Install Center Support Beam and Legs

Attach the center support beam to the designated brackets on the headboard and footboard. Then, screw the support legs into the center beam. Ensure the legs are firmly attached and provide stable support.

Step 3: Place Plywood Slats

Unroll or place the plywood slats across the side rails. The slats are pre-connected and designed to fit securely. Fasten the slats to the side rails using the provided screws to prevent movement.



Image: Close-up view of the durable plywood slats and solid wood legs, highlighting the sturdy construction.

Step 4: Final Tightening

Once all components are in place, use the Allen wrench to fully tighten all bolts. Do not overtighten.

Usage and Mattress Placement

This bed frame is designed for use without a box spring. Place your mattress directly onto the secured plywood slats.

- **Recommended Mattress Thickness:** Up to 6 inches for optimal fit and airflow.
- The embedded slatted platform design helps keep the mattress in place and promotes air circulation.
- The bed frame has a maximum weight capacity of 660 lbs (Full size), including the mattress and occupants.



Image: Visual guide indicating the recommended mattress thickness (up to 6 inches) and illustrating the anti-slip embedded design of the bed frame.

The 12-inch under-bed clearance provides convenient storage space for various items and allows for easy cleaning underneath the bed.



Image: A view showing the 12-inch clearance under the bed frame, suitable for storage bins or robotic vacuums.

Maintenance

- **Cleaning:** Wipe the wooden surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten if necessary.
- **Placement:** Avoid placing the bed frame in direct sunlight or near heat sources to prevent wood warping or fading.

Troubleshooting

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable.	Loose bolts or uneven floor.	Ensure all bolts are fully tightened. Check if the floor is level; use furniture pads if needed.

Problem	Possible Cause	Solution
Squeaking noises.	Loose connections or friction between parts.	Re-tighten all bolts. Apply a small amount of lubricant (e.g., paraffin wax) to contact points if necessary.
Mattress slides on slats.	Mattress not properly seated or anti-slip features not effective.	Ensure the mattress is centered. Consider using a non-slip mattress pad between the mattress and slats.

Specifications

Model: D-CO-HU10482BN-F

Size: Full

Material: Engineered Wood, Wood

Overall Dimensions (L x W): 79.5" x 36"

Headboard Height: 20.5 inches

Under-bed Clearance: 12 inches

Maximum Weight Capacity: 660 lbs

Recommended Mattress Thickness: Up to 6 inches

Color: Walnut

UPC: 610803441452



Image: Diagram illustrating the key dimensions of the SlickBlue Full Bed Frame, including length, width, and height, and weight capacity.

Warranty and Support

For warranty information or customer support, please refer to the purchase documentation or contact SlickBlue customer service directly.

Manufacturer: SlickBlue

© 2026 SlickBlue. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FJMMY1LY

More documents and user manuals: **https://manuals.plus/**