

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HOMCOM](#) /

› [HOMCOM Full Size Bed Frame Instruction Manual \(Model 83D-056V81WT\)](#)

HOMCOM 83D-056V81WT

HOMCOM Full Size Bed Frame Instruction Manual

Model: 83D-056V81WT

Brand: HOMCOM

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Maximum Weight Limit:** Do not exceed the maximum weight limit of **660 lbs (300 kg)**. Exceeding this limit can cause structural failure and injury.
- **Pinch Points:** Be cautious of pinch points when assembling the solid wood slats and legs. Keep hands clear during assembly.
- **Assembly:** Follow the assembly instructions carefully to ensure stability and prevent collapse. Ensure all fasteners are securely tightened.
- **Children:** Keep children away from the assembly area. Small parts can be a choking hazard.
- **Maintenance:** Regularly check all bolts and connections to ensure they remain tight. Retighten as necessary.

2. PRODUCT OVERVIEW

The HOMCOM Full Size Bed Frame (Model 83D-056V81WT) is designed for modern bedrooms, offering a minimalist aesthetic with practical features. This platform bed frame includes a headboard and footboard, wooden slats, and provides under-bed storage space.

Key Features:

- **Modern Minimalist Style:** Clean white frame with wood-grain accents.
- **Stable Support:** Constructed with particleboard and MDF, featuring 14 solid wood slats and 10 supportive legs. Supports up to 660 lbs.
- **No Box Spring Needed:** The robust slat system eliminates the need for a box spring.
- **Under-Bed Clearance:** Provides 6.1 inches of space for storage or easy cleaning.
- **Low Noise Design:** Tight construction minimizes creaking.

- **Protective Foot Pads:** Included to prevent floor scratches.

Product Dimensions:



Figure 2.1: Overall dimensions of the bed frame.

Overall Dimensions: 80.1" L x 56.3" W x 36.8" H

Under-Bed Clearance: 6.1"

Suitable Mattress Size: Full (54" x 75")

3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. Refer to the included installation manual for a detailed list of components and hardware. Typically, the package includes:

- Headboard components
- Footboard components
- Side rails
- Wooden slats

- Support legs
- Assembly hardware (bolts, screws, washers, Allen wrench)
- Installation Manual

If any parts are missing or damaged, do not proceed with assembly. Contact HOMCOM customer support for assistance.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this bed frame. It is recommended that two adults assemble the product. Clear instructions and labeled parts are provided in the included installation manual.

Recommended Tools:

- Included Allen wrench
- Phillips head screwdriver (not always included, may be needed for some screws)

Assembly Steps (General Overview):

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface (e.g., carpet) to prevent scratches. Verify all parts against the parts list in your manual.
2. **Assemble Headboard and Footboard:** Attach the headboard and footboard panels as per the detailed diagrams in your manual.
3. **Attach Side Rails:** Connect the side rails to the assembled headboard and footboard using the provided hardware. Ensure all connections are secure.
4. **Install Center Support Legs:** Attach any central support legs to the frame as indicated.
5. **Place Wooden Slats:** Distribute and secure the wooden slats across the frame. Ensure they are evenly spaced and firmly attached to provide proper mattress support.
6. **Final Tightening:** Once fully assembled, carefully go over all bolts and screws to ensure they are tightened securely. Do not overtighten.



Figure 4.1: The HOMCOM Full Size Bed Frame fully assembled.

STABLE & LOW NOISE



Figure 4.2: Detail of the stable support system with wooden slats and legs.



Figure 4.3: Detailed view of the slat attachment mechanism.

5. OPERATING INSTRUCTIONS

This bed frame is designed for supporting a full-size mattress without the need for a box spring.

- **Mattress Placement:** Place your full-size mattress directly onto the wooden slats. Ensure the mattress is centered and fits within the frame.
- **Weight Distribution:** Distribute weight evenly across the bed frame. Avoid concentrating heavy loads on a single point.
- **Under-Bed Storage:** Utilize the 6.1 inches of under-bed clearance for storage bins or other items. Ensure items do not obstruct the bed's stability or airflow.



Figure 5.1: Under-bed storage space.

6. MAINTENANCE

Proper maintenance will extend the life of your HOMCOM bed frame.

- **Cleaning:** Wipe the frame with a dry cloth to remove dust and dirt. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Fastener Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections. Tighten any loose fasteners to maintain stability and prevent creaking.
- **Slats Inspection:** Check wooden slats for any signs of damage or cracking. Replace damaged slats immediately to ensure proper mattress support.
- **Relocation:** If moving the bed frame, disassemble it carefully following the reverse of the assembly instructions. Do not drag the assembled frame, as this can cause structural damage.

7. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

- **Bed Frame is Wobbly/Creaking:**

- Ensure all bolts and screws are securely tightened. Loose fasteners are a common cause of wobbling and noise.
- Verify that all support legs are making firm contact with the floor. Adjust if necessary.
- Check if the floor surface is even. Uneven surfaces can cause instability.

- **Missing or Damaged Parts:**

- Carefully re-check all packaging materials. Small parts can sometimes be overlooked.
- If parts are genuinely missing or damaged upon arrival, contact HOMCOM customer support immediately with your model number and a description of the issue. Do not attempt to assemble with missing or damaged parts.

- **Difficulty Assembling:**

- Review the assembly manual step-by-step. Ensure each component is oriented correctly.
- Do not force parts together. If parts do not fit, re-check the instructions and part identification.
- Consider having a second person assist with assembly, especially for larger components.

8. SPECIFICATIONS

Model Number	83D-056V81WT
Brand	HOMCOM
Size	Full
Product Dimensions	80.1" L x 56.3" W x 36.8" H
Under-Bed Clearance	6.1 Inches
Maximum Weight Capacity	660 lbs
Material	Engineered Wood (Particleboard and MDF)
Color	White
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth
Item Weight	97 pounds

9. WARRANTY AND SUPPORT

For warranty information, returns, or customer support, please refer to the specific terms and conditions provided at the point of purchase or contact HOMCOM directly.

Manufacturer: Aosom LLC

Customer Support: Please visit the [HOMCOM Store on Amazon](#) or contact Aosom Direct for assistance with product issues, missing parts, or assembly questions.

Return Policy: Typically, a 90-day easy return policy is offered. Please check your purchase details for exact return terms.

© 2025 HOMCOM. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.