

[Manuals.plus](#) /

› [DUMOS](#) /

› DUMOS Metal Platform Bed Frame (Model DUTW01) - Twin Size Instruction Manual

DUMOS DUTW01

DUMOS Metal Platform Bed Frame (Model DUTW01) - Twin Size Instruction Manual

PRODUCT OVERVIEW

Welcome to your new DUMOS Metal Platform Bed Frame. This frame is designed for durability and ease of use, providing a sturdy foundation for your twin-size mattress without the need for a box spring.

Key features of your DUMOS bed frame include:

- Solid Wood Construction for lasting durability.
- Integrated Wood Slat System for excellent mattress support and air circulation.
- Includes both a Headboard and Footboard.
- Provides 9.8 inches of Under-Bed Storage Clearance.
- Designed for Quick and Hassle-Free Assembly.

SAFETY GUIDELINES

Please read and follow these safety instructions carefully to ensure safe use of your bed frame.

- **Maximum Weight Capacity:** Do not load more than 350 pounds on this bed frame. Exceeding this limit may cause damage or injury.
- Ensure all bolts and fasteners are securely tightened before initial use and periodically check for tightness. Loose connections can lead to instability.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- Assemble the bed frame on a soft, clean surface (e.g., a carpet or blanket) to prevent scratching the product or your flooring.
- Do not allow children to play on or under the bed frame without supervision.

PACKAGE CONTENTS

Before beginning assembly, carefully unpack all components and verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Headboard
- Footboard
- Side Rails (2)
- Wooden Slats
- Support Legs (if separate from main frame)

- Hardware Pack (includes bolts, washers, and Allen wrench)
- Installation Manual (this document)



Image Description: This diagram illustrates the overall dimensions of the DUMOS Twin Size Bed Frame. It shows a length of 78.66 inches, a width of 42.4 inches, a headboard height of 42.12 inches, a footboard height of 26.3 inches, and an under-bed clearance of 9.8 inches. All major components are visible.

ASSEMBLY INSTRUCTIONS

Assembly of your DUMOS bed frame is designed to be straightforward and typically takes approximately 30 minutes. Follow these steps carefully:

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface. Refer to the 'Package Contents' section to identify each piece and ensure nothing is missing.
2. **Attach Side Rails to Headboard:** Connect the two side rails to the headboard using the provided bolts and the Allen wrench. Insert the bolts but do not fully tighten them at this stage.
3. **Attach Side Rails to Footboard:** Connect the other end of the side rails to the footboard. Ensure that all connections

are properly aligned before proceeding.

4. **Install Center Support (if applicable):** If your specific model includes a center support beam or additional support legs, install them now according to the diagrams in the included paper manual (if provided).
5. **Insert Wooden Slats:** Carefully place the wooden slats evenly across the side rails. Ensure they are properly seated and secured in place. The integrated wood slat system provides direct mattress support.
6. **Tighten All Bolts:** Once all components are in place and aligned, securely tighten all bolts using the Allen wrench. Do not overtighten, as this can strip the threads or damage the wood.



Solid Wood
Frame



Robust Bolt
Structure

Image Description: This image provides a close-up view of the DUMOS bed frame, emphasizing its solid wood construction and the robust bolt connections that contribute to its stability and durability.

Modern Minimalist Headboard



Contemporary
Appeal



Easy
Maintenance



Image Description: A detailed view of the DUMOS bed frame's modern minimalist headboard, showcasing its design which offers both comfort and a clean aesthetic.

USAGE GUIDELINES

Once assembled, your DUMOS Metal Platform Bed Frame is ready for use.

- **Mattress Placement:** Place your twin-size mattress directly onto the wooden slats. A box spring is not required due to the integrated slat system.
- **Under-Bed Storage:** Take advantage of the 9.8-inch clearance beneath the bed. This space is ideal for storing items such as extra bedding, shoes, or storage bins, helping to keep your room organized.

No Boxspring Need



Image Description: This image displays the DUMOS bed frame in a bedroom setting, illustrating how two woven storage baskets fit neatly underneath, highlighting the ample under-bed storage space and confirming that no box spring is needed.



Image Description: A close-up image demonstrating the 9.8-inch under-bed clearance of the DUMOS bed frame, with a robot vacuum positioned underneath, indicating ease of cleaning and storage potential.

CARE AND MAINTENANCE

Proper care and maintenance will extend the life and appearance of your DUMOS bed frame.

- **Cleaning:** Wipe the bed frame with a soft, slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the wood finish.
- **Regular Checks:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections to ensure they remain tight. Retighten any loose fasteners to maintain stability and prevent noise.
- **Avoid Overloading:** Adhere strictly to the maximum weight capacity of 350 pounds to prevent structural damage.
- **Protect from Moisture:** Keep the bed frame in a dry environment. Avoid prolonged exposure to direct sunlight or extreme temperature changes, which can affect wood integrity.

TROUBLESHOOTING

If you encounter any issues with your bed frame, refer to the following common solutions:

- **Squeaking Noises:**
 - Check all bolts and connections; tighten any loose ones.
 - Ensure all wooden slats are properly seated and not rubbing against the frame or each other.
 - Verify that your mattress is correctly positioned and not causing friction.
- **Instability or Wobbling:**
 - Confirm that all assembly steps were followed correctly and no parts were omitted or incorrectly installed.
 - Ensure all bolts are fully tightened.
 - Check that the bed frame is placed on a level surface. Adjust if necessary.
- **Missing Parts:**
 - Carefully re-check all packaging materials, including inside boxes and plastic bags, as small parts can sometimes be overlooked.
 - If parts are genuinely missing, contact DUMOS customer support for assistance.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	DUTW01
Size	Twin
Material	Wood
Product Dimensions (L x W x H)	78.54" x 42.4" x 42.12"
Under-Bed Clearance	9.8 inches
Maximum Weight Capacity	350 Pounds
Assembly Required	Yes
Color	Classic White
UPC	786302973340

CUSTOMER SUPPORT

For further assistance, inquiries about missing parts, or any questions regarding your DUMOS Metal Platform Bed Frame, please contact DUMOS customer support. Refer to your purchase documentation or the retailer's website for specific contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GFJLWK14>

More documents and user manuals: **<https://manuals.plus/>**