

F01 F02

Automatic Gear Shift Paddle Extension Instruction Manual

For BMW 7 Series F01 F02 (2013-2015)

1. INTRODUCTION

Thank you for choosing the Automatic Gear Shift Paddle Extension. This product is designed to enhance your driving experience by providing a more accessible and comfortable gear shifting interface for your vehicle's steering wheel. It also adds an elegant visual upgrade to your car's interior.

This manual provides essential information for the correct installation, operation, and maintenance of your new paddle extensions. Please read it thoroughly before proceeding with installation or use.

2. COMPATIBILITY

This gear shift paddle extension is compatible with the following vehicle models:

- BMW 7 Series F01 F02 (Years: 2013, 2014, 2015)

Important: Please confirm the compatibility with your vehicle's specific model and year before installation. Refer to the images provided in this manual and compare them with your existing steering wheel paddles to ensure a perfect fit. If you have any doubts, please contact customer support with your car's model and year.

3. PACKAGE CONTENTS

Upon opening the package, please verify that all the following items are present and undamaged:

- 1x Left Gear Shift Paddle Extension
- 1x Right Gear Shift Paddle Extension
- Installation Tools (e.g., adhesive tape, cleaning wipes)

If any items are missing or damaged, please contact customer support immediately.

4. SETUP & INSTALLATION

The installation process is designed to be straightforward and damage-free. However, professional installation is always recommended for optimal results.

1. **Preparation:** Ensure the installation area on your steering wheel's original shift paddles is clean and free from dust, grease, or debris. Use the provided cleaning wipes if necessary.
2. **Adhesive Activation:** Carefully peel off the protective backing from the adhesive tape on the back of

the paddle extensions. For stronger adhesion, gently heat the adhesive using a hairdryer or heat gun for a few seconds.

3. **Positioning:** Align the paddle extension precisely over your vehicle's existing shift paddle. Ensure it fits snugly and covers the original paddle correctly.
4. **Attachment:** Once aligned, press the paddle extension firmly onto the original paddle for at least 30 seconds to ensure the adhesive bonds securely. Repeat for the other paddle.
5. **Curing Time:** Allow the adhesive to cure for at least 24 hours before extensive use, especially in varying temperatures. Avoid washing the car or exposing the paddles to excessive moisture during this period.



This image displays the silver variant of the automatic gear shift paddle extensions. Each paddle features a sleek, elongated design with a mounting base for attachment to the steering wheel.



This image shows the black variant of the automatic gear shift paddle extensions. The paddles are designed to extend the reach of the original shifters, providing a more ergonomic and visually appealing interface.

5. OPERATING INSTRUCTIONS

Once installed, the paddle extensions function identically to your vehicle's original gear shift paddles, but with an enhanced feel and extended reach.

- **Upshift:** Pull the paddle marked with a "+" symbol (typically on the right side of the steering wheel) towards you to shift up a gear.
- **Downshift:** Pull the paddle marked with a "-" symbol (typically on the left side of the steering wheel) towards you to shift down a gear.

The extended design allows for more comfortable and intuitive shifting, especially during spirited driving or when your hands are not in the traditional 9 and 3 o'clock positions.

6. MAINTENANCE

To maintain the appearance and functionality of your paddle extensions:

- Clean the paddles regularly with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Periodically check the adhesion to ensure the paddles remain securely attached.

7. TROUBLESHOOTING

Issue: Paddles do not adhere properly.

Solution: Ensure the surface was thoroughly cleaned and dry before application. Re-apply adhesive if necessary, ensuring sufficient pressure and curing time. Heating the adhesive slightly before application can improve bonding.

Issue: Paddles do not fit correctly.

Solution: Double-check the compatibility with your specific BMW 7 Series F01 F02 model and year. Compare your original paddles with the product images. If there is a significant mismatch, the product may not be compatible with your vehicle.

8. SPECIFICATIONS

Brand	generic
Compatible Models	BMW 7 Series F01 F02
Compatible Years	2013, 2014, 2015
Material	CNC Machined Aluminum Alloy (sandblasted and anodized surface)
Color (as per specifications)	Red (Note: Product may be available in other colors like Black or Silver)
ASIN	B0GKFS72GP

9. WARRANTY AND SUPPORT

For any questions regarding installation, compatibility, or product issues, please contact the seller or manufacturer directly through the platform where the product was purchased. Please provide your order number and a detailed description of the issue for prompt assistance.