

CAFE CSB913P2VS1 Built In Convection Microwave Oven **Instruction Manual**

Home » Cafe » CAFE CSB913P2VS1 Built In Convection Microwave Oven Instruction Manual

CAFE CSB913P2VS1 Built In Convection Microwave Oven Instruction Manual

INSTALLATION INSTRUCTIONS

Advantium[®] Built-In Microwave Oven **CSB913** PSB9120

Built-In Convection Microwave Oven CWB713 PWB7030



P/No.: MFL59060950_00

31-2000354 Rev. 3 07-24

Contents

- 1 Installation Instructions
- **2 Installation Preparation**
- **3 Standard Installation Preparation**
- **4 Flush Mount Installation**

Preparation

- **5 Installation Preparation**
- **6 Installation Instructions**
- 7 Notes
- 8 Documents / Resources
 - 8.1 References

Installation Instructions

BEFORE YOU BEGIN

Read these instructions completely and carefully.

IMPORTANT — Save these instructions for local inspector's use.

IMPORTANT — Observe all governing codes and ordinances.

- Note to Installer Be sure to leave these instructions with the Consumer.
- Note to Consumer Keep these instructions with your Owner's Manual for future reference.
- Skill Level Installation of this appliance requires basic mechanical and electrical skills.
- Completion Time 1 Hour.
- Proper installation is the responsibility of the installer. Product failure due to improper installation is not covered under the warranty. See Owner's Manual for warranty information.

IMPORTANT — Use this oven only for its intended purpose. Never use the oven for warming or heating a room. Prolonged use of the oven without proper ventilation can be hazardous.

ACAUTION

For personal safety, remove house fuse or oven circuit

breaker before beginning installation to avoid severe or fatal shock injury.

ACAUTION

For personal safety, the mounting surface must be

capable of supporting the cabinet load, in addition to the added weight of the oven and drawer, plus additional oven loads.

CONTENTS

Design Information Models Available Product Dimensions and Clearances Tools and Parts Required Advance Planning	.3
Installation Preparation Electrical Requirements Preparing the Opening (Standard) Preparing the Opening (Flush Mount)	. 5
Storage Drawer Preparation Standard Flush	
Installation Instructions Step 1, Remove Packaging and Parts Step 2, Slide the Oven into the Cutout Step 3, Install Bottom Trim Step 4, Install Bottom Trim with Accessory Drawer Step 5, Install Mounting Screws Step 6, Finalize Installation	13 13 13

MODELS AVAILABLE

Café Pro Models:

CSB913P2NS1 - Stainless Steel

CSB913P3ND1 - Matte Black

CSB913P4NW2 - Matte White

CSB913P2VS1 - Stainless Steel

CSB913P3VD1 - Matte Black

CSB913P4VW2 – Matte White

CWB713P2VS1 - Stainless Steel

Café Min Models:

CSB913M2NS5 - Stainless Steel

CSB913M2VS5 - Stainless Steel

Profile Models:

PSB9120SVSS - Stainless Steel

PWB7030SVSS - Stainless Steel

*Accessory storage drawer is only available for stainless steel models

Installation Preparation


ELECTRICAL REQUIREMENTS

Single Built-In Advantium/Convection Oven Installation:

This product requires a 120-volt, 60 Hz, 15-amp circuit and draws 1.8 kilowatts. This product must be connected to a supply circuit of the proper voltage and frequency.

- Wire size must conform to the requirements of the National Electrical Code or the prevailing local code for this kilowatt rating.
- The power supply cord and plug should be brought to a separate 15 or 20 ampere branch circuit single grounded receptacle. The outlet box should be located within reach of the 48" power cord.

ELECTRICAL LOCATION



Locate outlet box in the shaded area

Install a recessed electrical outlet in the back wall of the opening within 6" of either side and at least 9" above the cutout floor.



GROUNDING INSTRUCTIONS

▲WARNING

Improper use of the grounding plug can result in a risk of electric shock.



This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current.

This appliance is equipped with a

power cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

Consult a qualified electrician or service technician if the GROUNDING INSTRUCTIONS are not completely understood, or if doubt exists as to whether the appliance is properly grounded.

If the outlet is a standard 2-prong wall outlet, it is your personal responsibility and obligation to have it replaced with a properly grounded 3-prong wall outlet.

Do not under any circumstacnes cut or remove the third (ground) prong from the power cord.

A short power-supply cord is provided to reduce risks resulting from becoming entangled or tripping over a longer cord.

Do not use an extension cord. If the power cord is too short, have a qualified electrician or service technician install an outlet near the appliance.

For best operation, plug this appliance into its own electrical outlet to prevent flickering of lights, blowing of fuse or tripping of circuit breaker.


Standard Installation Preparation

PREPARE THE OPENING

Built-In Advantium/Convection Oven can be installed in combination with other Built-In appliances. Always follow each product's Installation Instructions to complete the installation.

Built-In Advantium/Convection Oven Installation:


Order a 30" wide single oven cabinet or cut the opening in a wall to the dimensions shown.



- Allow the following clearances around the cutout on the front surface of the cabinet: 1–7/8 " from the top, 2–3/8" from the side edges, and 1–1/8" from the bottom. (Note: these refer to minimum clearances required for installation and do not reflect actual product dimensions.)
- Oven overlaps will conceal cut edges on all sides of the opening.
 When installed over a single oven or a warming drawer, allow at least 2" between the two openings.
 This separation will provide clearance for bottom overlap of the Built-In Advantium/Convection Oven and the other appliance overlaps.
- The support must be level and rigidly mounted, flush with the bottom edge of the cutout.

PREPARE THE OPENING (CONT.)


Installation over a Warming Drawer:



NOTE: Additional clearances between the cutouts may be required. Check to be sure the oven supports above the Warming Drawer location does not obstruct the required interior depth and height. See Warming Drawer installation instructions for details.

PREPARE THE OPENING (CONT.)


Installation over a Wall Oven:



 If you are replacing an electric double oven with the combined installation of an Built-In Advantium/ Convection Oven and a single oven, use the dimensions shown. The middle rail separating the two openings may need to be larger than the 2" minimum shown.

PREPARE THE OPENING (CONT.)

Installation over a Wall Oven and Warming Drawer:




NOTE: Additional clearances between the cutouts may be required. Check to be sure the oven supports above the Warming Drawer location does not obstruct the required interior depth and height. See Warming Drawer installation instructions for details.

ACAUTION

For personal safety, the mounting surface must be capable of supporting the cabinet load, in addition to the added weight of the oven and drawer, plus additional oven loads.

PREPARE THE OPENING (CONT.)


Installation over another Advantium Built-In Oven:



 If you are mounting a Built-In Advantium/Convection Oven over another, use the dimensions shown. The middle rail separating the two openings may need to be larger than the 3-1/8" minimum shown.

PREPARE THE OPENING (CONT.)

Installation under a Microwave Oven and over a Warming Drawer:




NOTE: Additional clearances between the cutouts may be required. Check to be sure the oven supports above the Warming Drawer location do not obstruct the required interior depth and height. See Warming Drawer installation instructions for details.

ACAUTION

For personal safety, the mounting surface must be capable of supporting the cabinet load, in addition to the added weight of the oven and drawer, plus additional oven loads.

PREPARE THE OPENING (CONT.) Installation beside another Advantium Built-In Oven: If you are mounting an Advantium Built-In Oven beside another, use the dimensions shown. The middle rail separating the two openings may need to be larger than the 4-1/2" minimum shown. 23-1/2" 25-1/4" 17-1/2" 17-1/2" 4-1/2" Min. (5-1/2" Recommended)



Flush Mount Installation Preparation


PREPARE THE INTERIOR

Cut and install side cleats:


 Cut side wood cleats to height of cabinet opening and approx. 2-1/2" in depth. Install, on each side, Dim. E from the front face of the cabinet.

Cut and install bottom cleat:

Cut bottom wood cleat to a height of 1-1/8", a depth of the cabinet minus Dim. E and a width of 25-1/4" to fit between side cleats. Install onto the cabinet floor between the side cleats, push it all the way back against cabinet wall and make sure its front face aligns with the front faces of the side cleats (Dim. E gap from the front cabinet face).



Α	Side and top cleats depth	2-1/2" min.
В	Bottom cleat height	1-1/8"
С	Bottom cleat depth	Cabinet depth minus Dim. E
D	Bottom cleat width	25-1/4"
Е	All four cleats inset depth	1 1/4"




PREPARE THE OPENING

The Built-In Advantium/Convection Oven can be installed in combination with other Built-In ovens. Always follow each product's Installation Instructions to complete the installation.

Single Built-In Advantium/Convection Oven Installation:

Cut the opening in a cabinet to the dimensions shown.



• The support must be level and rigidly mounted, flush with the bottom edge of the cutout.

Approved Flush Installation	Dimension F	
Approved Flush Installation	1/8" Reveal	1/4" Reveal
Single Advantium	30"	30-1/4"
Over Warming Drawer	30"	30-1/4"
Over Oven	30"	30-1/4"
Over Oven and Warming Drawer	30"	30-1/4"
Over Advantium Built-In Oven	30"	30-1/4"
Double Advantium (side by side)	See page 10	
Under Cooktop or Countertop	See page 10	

** Top and bottom reveals are set to 1/8".


PREPARE THE OPENING The Advantium Built-In Oven can be installed beside another Advantium Built-In Oven in a side-by-side combination. Pouble Advantium Built In Oven

Double Advantium Built-In Oven Installation:

Cut the opening in a cabinet to the dimensions shown.

- Center divider acts as cleat for side of each respective unit. Only one additional side cleat needed per oven cutout.
- The support must be level and rigidly mounted, flush with the bottom edge of the cutout.


Dimension	1/8" Reveal	1/4" Reveal
G	59-7/8"	60-1/4"
Н	5-1/8"	5-1/4"
I	27-3/8"	27-1/2"



PREPARE THE OPENING

Installation under a 30" or 36" Cooktop or Countertop:

Gas or electric cooktops may be installed over this oven. See cooktop installation instructions for the cutout size. See the label on top of the oven for approved cooktop models. This oven requires a separate from the cooktop, properly grounded 15-Amp, 120-Volt, 60Hz power supply. Use a 30" or wider base cabinet.



Installation Preparation

Preparation with an Accessory Storage Drawer

As needed, see the Standard Mount Installation Preparation OR Flush Mount Installation Preparation for configuration details. Note the modified cutout height below.


PREPARE THE OPENING (cont.)

The Built-In Advantium/Convection Oven can be installed in combination with other Built-In appliances. Always follow each product's Installation Instructions to complete the installation.


Single Built-In Advantium/Convection Oven Installation:

Order a 30" wide single oven cabinet or cut the opening in a wall to the dimensions shown.

STANDARD MOUNT:



FLUSH MOUNT:




Dimension	1/8" Reveal	1/4" Reveal
K	30"	30-1/4"

- For flush installation, make the bottom cleat height 3/4" when installed over a storage drawer.
- Allow the following clearances around the cutout on the front surface of the cabinet: 1–7/8 " from the top, 2–3/8" from the side edges, and 3/4" from the bottom. (Note: these refer to minimum clearances required for installation and do not reflect actual product dimensions.)
- · Oven overlaps will conceal cut edges on all sides of the opening.
- When installed over a single oven or a warming drawer, allow at least 2" between the two openings. This
 separation will provide clearance for bottom overlap of the Built-In Advantium/Convection and the other appliance
 overlaps.
- The support must be level and rigidly mounted, flush with the bottom edge of the cutout.

Installation Instructions

1 REMOVE THE PACKAGING AND PARTS

- · Remove all packing material and tape.
- Locate parts package containing mounting screws.
- Remove the oven from the carton. Do not lift unit by handle or conduit. Two people are required to lift this oven.
- Open the door and remove any packaging in oven.



Rack




5 Color-Matched Screws (4 required, 1 extra)



8 Brass Screws for the Bottom Trim (3 required, 5 extra)



Flat-Head Screws (4 extra)



IMPORTANT: If installing the Built-In Advantium/ Convection Oven with an accessory storage drawer, read the storage drawer assembly instructions to assemble the products together before proceeding to Step 2.

> * Not included with Models PWB7030 and CWB713

2 SLIDE THE OVEN INTO THE CUTOUT

Two people are required to lift the oven into the opening. Grasp the bottom at front and rear. DO NOT USE THE HANDLE TO LIFT THE OVEN. DAMAGE WILL OCCUR.




- Lift and hold the oven at the front of the opening.
 Hold the oven at an angle and plug in the power cord.
- Carefully, slide the oven into the cabinet part way. Leave the oven a few inches forward of the cabinet frame.
- Check to be sure the power cord is not trapped under the oven or along the sides of the oven.


3 INSTALL BOTTOM TRIM

NOTE: If installing the Built-In Advantium/Convection Oven with an accessory storage drawer, the bottom trim is not required. Proceed to Step 5.


- Installation Below or Above 36", align trim tabs on the trim to slots in the bottom of the oven.
- Align bottom trim tabs to slots in the bottom of the oven.



 Secure the bottom trim to the bottom of the oven using 3 screws provided.



4 INSTALL MOUNTING SCREWS



- Slide the oven the remaining way into the opening so that the side flanges and control panel are against the cabinet frame. Make sure that the oven is centered in the opening.
- Open the door, place a turntable tray in the oven and make sure that the tray in the unit is level.
- · Drill pilot holes through the side flanges.
- Drive the color-matched screws into the side flanges. It is recommended that the screws be hand tightened.

If installing oven with an accessory storage drawer:

- · Open the drawer.
- Drill pilot holes through the side flanges.
- Drive color-matched screws into the side flanges.
 It is recommended that the screws be hand tightened.




5 FINALIZE INSTALLATION

- Turn power on at the source. The interior light should come on when the door is opened.
- Refer to Owner's Manual for operating instructions.

Notes

Printed in China





NOTE: Product improvement is a continuing endeavor at GE Appliances. Therefore, materials, appearance and specifications are subject to change without notice.

Documents / Resources

INSTALLATION INSTRUCTIONS Advantum' Built-In Microwave Oven cosed 199700 Built-In Convection

Design on the

CAFE CSB913P2VS1 Built In Convection Microwave Oven [pdf] Instruction Manual CSB913P2VS1, PSB9120, CWB713, PWB7030, CSB913P2VS1 Built In Convection Microwave Oven, CSB913P2VS1, Built In Convection Microwave Oven, Convection Microwave Oven, Microwave Oven, Oven

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.